



InnoTAB[®] MAX



User's Manual

For troubleshooting tips, visit: www.vtechkids.com/tutorials/innotabmax

Register Now!

Register your InnoTab® MAX to receive:

- A one year limited warranty¹
- Two FREE VTech downloads
- One Toca Boca bonus app



- (1) CHARGE²** your **InnoTab® MAX** using the included USB cable and adapter. A green light will turn on to indicate charging is in progress. The light will turn off when the tablet is fully charged. A full charge takes about 4.5 hours.
- (2) SET** the date and time, and establish a Wi-Fi connection. Touch the check mark when the Wi-Fi setup is done.
- (3) REGISTER³** your **InnoTab® MAX** by creating a Parent Account and assigning Kid Connect IDs for yourself and your child. Then, choose one Toca Boca bonus app⁴.
- (4) BROWSE** the Learning Lodge® and select an additional two free VTech apps⁴ to download.
- (5) PLAY, LEARN & CONNECT!** Have fun with your **InnoTab® MAX!**

¹ Please see the Warranty Sheet for details.

² The battery should be fully charged before the first use. See the **Charging the Tablet** section for details.

³ Firmware update may be required before registration.

⁴ For first-time registration and designated content only.

Key Features



⁵ The terms HDMI and HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing LLC in the United States and other countries.

Charging the Tablet

The battery will be partially charged when the tablet is first opened from the box. It should be fully charged before the first use. To charge and recharge the battery, please follow the instructions below.

Note: Do not try to disassemble the product to replace the battery.

1. Insert the larger end of the USB cable (included) into the USB socket of the Power Adapter and insert the other end into the USB port on your **InnoTab® MAX**. Then, plug the Power Adapter into a wall socket.

Note: The Power Adapter is not a toy and should only be handled by an adult.

2. The green light on the tablet will turn on to indicate charging is in progress. When the battery is fully charged, the light will turn off. A full charge takes about 4.5 hours with the USB Power Adapter.

Turning Your InnoTab® MAX On or Off

To turn on your tablet, press and hold the Power button for 3 seconds. You will see the **VTech®** logo. See the **Register Now!** section for instructions on your first start up.

You may turn off the tablet if it will not be used for an extended period of time. To turn off your tablet, press and hold the Power button and touch the prompt to confirm.

Locking and Unlocking the Tablet



By default, the **InnoTab® MAX** screen will be locked when it is not in use for a while.

To unlock the tablet's screen, press the Power button to wake it up. Then drag your profile icon to the circle at the center of the screen.

To lock the tablet's screen, press the Power button once. The display will go black.

Inserting a microSD Card

You can insert a microSD memory card (not included) into your **InnoTab® MAX** to expand available memory for downloaded content, photos, videos or music. The **InnoTab® MAX** is compatible with microSD memory cards up to 32GB.



- Make sure the tablet is turned off.
- Turn the **InnoTab® MAX** over, and locate the microSD card slot on the back. Insert the microSD card as shown above.

Connecting to a TV

In order to connect the **InnoTab® MAX** to your TV, you'll need a mini-HDMI to HDMI cable – also known as an HDMI type A to type C cable (not included). Locate the mini-HDMI port on the back of your **InnoTab® MAX** and insert the mini-HDMI end of the cable into your tablet. Plug the HDMI end of the cable into the HDMI jack on your TV.


Using the Stand

The cover can protect the screen of your **InnoTab® MAX** when flipped to the front. Flipping the cover to the back makes a stand to provide a better viewing angle for watching videos or a photo slide show.



Detaching the Cover

The cover can be removed to make the **InnoTab® MAX** slimmer and more lightweight.



Repeat the steps on the other side.

Attaching the Cover




1) Pull out on one of the hinges of the cover.

2) Insert the valve into one of the sockets and push in until you hear and feel a "click."

Repeat the steps on the other side.

Wi-Fi Setup

If you want to set up a new Wi-Fi network after registration, follow the steps below:

1. From the Lock screen, drag the Parental Controls icon  to the circle at the center of the screen. Then, enter your Parental Controls passcode.


2. Touch the Wi-Fi icon .



3. Make sure Wi-Fi is on. The tablet will list the available networks. Touch the network that you would like to connect to, and enter a password if needed. When the connection is set up, touch the check mark to return to the Parental Controls menu.

Note: The **InnoTab® MAX** supports 802.11 b/g/n wireless standards.

Touch here first to turn on Wi-Fi.



The Desktop



Profile Picture

Touch this image or press the menu button next to the screen to switch profiles or go to Parental Controls.

Cartridge

Touch this image to play an inserted **InnoTab®** cartridge.

System Status

Shows the time, Wi-Fi status and battery power.

Built-in Apps

There are many built-in apps including games, media players, tools and shelves. Flick left or right to see more.

Learning Lodge®

Download more content from VTech's online store.

Kid Connect

With this app, your child can send text messages, voice messages, photos, and more to your smartphone.

Downloads

Find all the apps downloaded from Learning Lodge® here.



VTech Kid Connect™ allows you to share text messages, voice messages, photos, drawings, and stickers between your **InnoTab® MAX** and a smartphone or tablet.

Getting Started

1. Make sure your child's **InnoTab® MAX** is registered. During registration you and your child will both receive a Kid Connect ID. This is a unique username that helps identify people on the network.

(See the **Register Now!** section for more information about registration.)

2. Download and install the Kid Connect app on your mobile device. It can be found at the App Store for iPhone or the Google Play Store for Android.

(Kid Connect works with iPhone4 or above, iOS5.x or above; Android 2.3.3 or above, minimum resolution: 320x480. Some functions are only available on Android 4.0.3 or above).

3. Launch the app on your mobile device and log in with your Kid Connect ID.

Managing Your Child's Contacts

You can manage your child's contact list with the mobile version of Kid Connect.

- **Viewing Your Child's Contacts**

Go to your contact list and touch the icon to the far right of your child's name to see all of your child's contacts.



Click to view your child's contact list.

- **Adding or Removing Contacts from Your Child's List.**

- Immediate Family**

- Your name and any other children registered under your account will appear in this section. These are added automatically and cannot be removed.

- Other Family & Friends**

- Any other contacts on your child's list will appear here.



- Remove contacts**

- Touch the wrench to enter edit mode, then touch the delete icon  next to any contacts you wish to remove.

- Add Contacts**

- Touch the plus sign to add a new contact.

- **Sending Friend Requests and Invitations**

Touch the plus icon next to "Other Family & Friends" to go to the Add New Friend screen:



- Search**

- To search for someone who has already joined Kid Connect, type in their name or Kid Connect ID and touch the "Search" button.

- Search Results**

- Once the search is done, touch the correct profile, then follow the on-screen instructions to send a friend request.


- Invite New User**

- Click here to invite any family or friends who have not joined Kid Connect.

Notes:

VTech recommends searching by the Kid Connect ID. Your child's Kid Connect ID can be found underneath their name in your contact list. Friend requests from smartphone to smartphone are prohibited. The app can only be used to communicate with **InnoTab®** users.

The "Invite New User" button can be used to invite a family member or friend who has not already joined Kid Connect. Keep in mind the invitee must have a smartphone or tablet to be able to install the Kid Connect app.



- **Accepting or Rejecting Friend Requests**

Touch the Friend Requests icon  to view any pending friend requests for you or your children. Select a request to accept or reject it.



Touch here to view Friend Requests.

- **Family Group Chat**

You and any children who are registered under your account are automatically entered into your family group. Anyone in your group can communicate in the group chatroom, where all members can see and post messages.


To see who's in your family group touch the icon to the far right of your family icon in your contact list.



Touch to see the members of your family group.

To add or remove members from your family group, follow the same steps outlined in the sections above.







Parental Controls






From the Parental Controls screen, you can access all of the kid-safe settings available on the **InnoTab® MAX**. From the lock screen, access Parental Controls by dragging the Parental Controls icon  to the circle at the middle of the screen.

Touch this image or press the menu key to the left to exit Parental Controls.




Parental Control Settings

	Wi-Fi	Touch this icon to set up a Wi-Fi connection.
	Time Controls	Touch this icon to limit the amount of time your child is allowed to play with the tablet.
	Content Lock	Touch this icon to lock specific content from being accidentally deleted.
	Web Browser Controls	Touch this icon to add or remove sites from each child's approved list. Navigation to sites that have not been approved is prohibited.
	Profile Manager	Touch this icon to add or remove user profiles from the tablet.
	Parent Account	Touch this icon to view or edit Parent Account information, including My Wishes settings.

 Progress Log	Touch this icon to view your child's learning progress. Note: The Progress Log can only track progress on InnoTab [®] cartridge games.
 Tablet Settings	Touch this icon to configure the tablet's system settings.
 Learning Lodge [®]	Touch this icon to browse Learning Lodge [®] and purchase games, e-books, music, videos and apps.
 Gift Gallery	Touch this icon to reward your child with extra Kid Connect stickers, desktop themes and My Magic Beanstalk gifts.
 Download Manager	Use this to install or uninstall apps that you bought from Learning Lodge [®] . See the Managing Apps section for more details.

To exit from Parental Controls, press the Menu key  and then touch Lock Out to exit to the lock screen.

Managing Apps

From the Parental Controls screen touch the Download Manager icon  to manage the apps you have purchased from Learning Lodge[®] for your **InnoTab**[®] MAX.

- **Downloading or Removing Apps**

From the Download Manager menu, touch any of the category tabs to view the apps in the selected category.



The screenshot shows the Download Manager interface with a grid of app cards. Each card displays the app name, icon, and file size. The cards are arranged in a grid with a 'Get More' button at the top right. The status of each app is indicated by a circular icon in the bottom right corner of the card: a trash can for 'Color & Pop 2', a play button for 'In Escape', a play button for 'Letter Pouch', a play button for 'Peek-a-Monster', a play button for 'Pinball Letters', a play button for 'Numberic Magazines', a play button for 'Alphabet Train', a play button for 'Alphabet Bubbles', a play button for 'God Did Smart Whoa's', a play button for 'Laf's Jam', a play button for 'Place the Face', and a play button for 'Twinkl HD'. A 'Trash Can' icon is also visible in the top left corner of the app grid.


Trash Can
Touch to remove an installed app.

Stop
Touch to stop downloading an app.

Download
Touch to download and install an app.

- **Automatic Download Settings**

By default, newly purchased apps or updated apps will be downloaded automatically. If they do not automatically download, make sure automatic downloading is turned on in Tablet Settings.




Turn this on to download newly purchased apps automatically.

Turn this on to download app updates automatically.

Get More from Learning Lodge®

You can visit Learning Lodge® to expand the content on your child's **InnoTab® MAX** anytime you have a Wi-Fi connection. To access Learning Lodge® from the **InnoTab® MAX** just touch the Learning Lodge® icon at the bottom of the Parental Controls desktop. To visit from a personal computer, go to <http://www.vtechkids.com> and click Downloads on the top menu bar.

By default, when an internet connection is available on your child's **InnoTab® MAX**, any recently purchased apps will download automatically even if you purchased them from another device.




My Wishes

With My Wishes, your child can view apps that are available in our Learning Lodge® library and let you know what apps they like by making a "wish". The wish list will then be sent to the email address you used to register for a VTech Parent Account.

Managing Your Child's Wishes

To view the apps your child has wished for, click on the link in the email we send you. The Wish List Manager will open in a web browser. Follow the prompts on screen if you want to purchase the app.



Purchased apps will be downloaded to **InnoTab® MAX** using the Wi-Fi Connection. See the **Managing Apps** section for more details about downloading purchased apps.

Pop-Ups on InnoTab® Desktop

Pop-ups will occasionally appear on the **InnoTab®** desktop with recommendations for apps your child might like. To turn off these pop-ups, go to the My Wishes settings in the Parent Account section of Parental Controls.

My Wishes Settings

To access the My Wishes settings, go into Parental Controls and select Parent Account.



The settings are available at the bottom of the screen. You can use the My Wishes settings to:

- Turn the pop-up that appears on the **InnoTab®** desktop on or off.
- Choose whether or not to receive notification e-mails when your child makes a wish.



Playing InnoTab Cartridges on the InnoTab® MAX

The **InnoTab® MAX** can play most cartridges designed for earlier **InnoTab®** models. However, because of the **InnoTab® MAX**'s larger screen, in order to play these older cartridges, you must first download updated versions to the tablet. To download an updated version of a cartridge, make sure your **InnoTab® MAX** is connected to the Internet and then insert the cartridge into the tablet. When you touch the cartridge icon on the desktop, **InnoTab® MAX** will prompt you to download the updated program.



Once the program finishes downloading, an image of the cartridge will appear at the bottom of the desktop whenever the cartridge is inserted. Touch the cartridge icon to play. (The physical cartridge must be inserted to play.)

For a complete list of titles that are compatible with the **InnoTab® MAX** and their estimated availability dates, please visit: <http://www.innotabsoftware.com>

Note: The **InnoTab® MAX** can store up to three **InnoTab®** cartridges. Additional update files will overwrite the older ones. Resetting the tablet to factory settings will also clear the updated versions of the cartridges. In this case, the programs will need to be downloaded again.


Transferring Pictures, Movies and Songs

You can transfer your own pictures, movies and MP3 songs from your computer to your **InnoTab® MAX**. However, the **InnoTab® MAX** will not be detected by some computer operating systems. For PC users we recommend using a computer with Windows 7 or later.

Transferring from a Windows Computer

Connect the **InnoTab® MAX** to your computer using the included USB cable. Use the File Transfer window that pops up on your computer to drag and drop files to their corresponding folders on the **InnoTab® MAX** or an inserted microSD card.

Earlier generations of Microsoft Windows such as Windows XP may not detect the tablet. This can be resolved by using third party file transfer software (not included) for Android devices.



Transferring from a Macintosh Computer

Visit the official Android website below to download the Android File Transfer software. Follow the instructions on the website to install the software and transfer files:

<https://www.android.com/filetransfer/>

Converting Videos for the InnoTab® MAX

To convert your video content for the **InnoTab® MAX**, use the following recommended settings:

Format: H.264 main profile video and AAC audio in an MP4 file.

Resolution: 1024x578 if source is 16:9. Other resolutions are supported but are not optimal for the device.

Video bitrate: 2000kbps. Other bitrates are supported but are not optimal for the device.

Audio bitrate: 128kbps constant bitrate. Other bitrates are supported but are not optimal for the device.


Maximum file size: 4GB (over 4 hours of play time using the recommended settings).


Notes:

- There may be legal restrictions associated with the use of commercial video files, movies, programs and other content for which VTech® accepts no responsibility or liability. Users should take responsibility for observing relevant copyright law in their country for this type of media.
- VTech® does not endorse, support or accept any liability for any third party software for file transfer or media conversion.


Updating the Firmware

To manually download and install the latest firmware:

1. Go to Parental Controls.
2. Make sure your **InnoTab® MAX** is connected to the Internet.
3. Select Tablet Settings . Then select Firmware Update.



4. The **InnoTab® MAX** will check for the latest firmware. If there is a newer version of the firmware, follow the on-screen instructions to complete the download and installation.



Care & Maintenance

1. Keep your **InnoTab® MAX** out of direct sunlight and away from direct sources of heat.
2. Turn off your **InnoTab® MAX** when not using it for an extended period of time.
3. Avoid dropping your **InnoTab® MAX** and NEVER try to dismantle it.
4. Always keep your **InnoTab® MAX** away from water.

5. Examine the power adapter periodically for conditions that may result in the risk of fire, electric shock, or injury to persons (such as damage to the output cord, blades, housing, or other parts). In the event of such conditions, the adapter should not be used until properly repaired.

Using the InnoTab® MAX Touch Screen and Stylus:

- Use your finger or the included stylus to operate the tablet. Be careful not to press down too hard, as too much pressure may damage the touch screen.
- Do not use the stylus if it is broken.
- Do not use any other stylus on the touch screen other than the **InnoTab® MAX** stylus.
- Put the stylus back in the stylus holder when not in use.

Cleaning the InnoTab® MAX Touch Screen

- Slightly dampen a soft, lint-free cloth with a little water and wipe the screen to loosen dirt.
- Use a clean and dry cloth to wipe the screen dry. Repeat these two steps as needed.

Cleaning the InnoTab® MAX Cabinet

- Keep your **InnoTab® MAX** clean by wiping it with a slightly damp cloth. Never use solvents or abrasives.

WARNING

A very small percentage of the public, due to an existing condition, may experience epileptic seizures or momentary loss of consciousness when viewing certain types of flashing colors or patterns, especially on television. While the **InnoTab® MAX** does not contribute to any additional risks, we do recommend that parents supervise their children while they play video games. If your child experiences dizziness, altered vision, disorientation, or convulsions, discontinue use immediately and consult your physician. Please note that focusing on an LCD screen at close range for a prolonged period of time may cause fatigue or discomfort. We recommend that children take a 15-minute break for every hour of play.

Troubleshooting

Problem	Possible Reason	Solution
"Not enough battery power." message shown during firmware update.	Battery power is low.	Connect the unit to a wall outlet using the included USB cable and AC adapter. A green light on the unit will turn on to indicate charging is in progress. When the battery bar on screen is full, the firmware update will continue automatically.
When registering for a new Parent Account during setup, the unit reports the email address has already been used.	The email address was used to register another Vtech product on Learning Lodge.	Use another valid email address. Turn the unit off and back on to start registration over. Select "Log In With Existing Parent Account" and log in with the email address you entered before. If you forgot your password, touch "Forgot Password."
When creating a Kid Connect account, the unit reports the email address has already been used.	The email address was already used to register for Kid Connect on a smartphone.	If you have already signed up for Kid Connect, enter your password and touch "Verify" to continue. If you forgot your password, touch "Forgot password?" and follow the instructions in the email to reset your password. Touch "here" in the link under the password field and use another valid email address.
Kid Connect will not load.	The profile needs to be reset.	From the Parental Controls screen, open the Profile Manager program. Touch the picture of the profile that will not load, and then touch the wrench to enter edit mode. Touch the trash can at the bottom-left corner of the screen and then confirm deleting the profile. After the profile is deleted, add the child's profile back by touching the plus sign. Select the same child's name from the name drop-down menu. Touch OK when you're done."
Screen displays with no sound	Volume is turned down.	Adjust the volume control.
	Headphones are connected.	Unplug headphones from headphone jack.

Screen turns on, then immediately off.	Battery power is low.	Connect the unit to a wall outlet using the included USB cable and AC adapter. A green light on the unit will turn on to indicate charging is in progress. When the battery is fully charged, the light will turn off.
No picture (or incorrect picture) displays on screen, and pressing the Power button has no effect.	Battery power is low.	Connect the unit to a wall outlet using the included USB cable and AC adapter. A green light on the unit will turn on to indicate charging is in progress. When the battery is fully charged, the light will turn off.
	The unit needs to be restarted.	Make sure the unit is off by holding the power button down for 10 seconds and then releasing it. Touch the Power button again for 3 seconds to power the unit on.
There is picture on screen, but the unit is not responding.	The unit needs to be restarted.	Make sure the unit is off by pressing the power button for 10 seconds and then release it. Hold the Power button again for 3 seconds to power on the unit.
No Wi-Fi network can be detected.	The unit needs to be reset.	Restore the unit to factory settings by holding the LEFT key, UP key and HELP key at the same time while turning the power on. You will see a factory reset confirmation screen. Touch Yes to confirm that you want to reset the unit. All user data will be lost after a factory reset.
"Safe mode" appears at the bottom-left corner of the screen."	The unit is in Safe Mode.	Power off the unit by pressing the power button for 3 seconds, and then touch the on-screen "Power off" pop-up window. Power on the unit again by holding the power button for 3 seconds. Make sure not to press the "Menu" key while turning the power on or off.
The unit will not charge.	The power source is not properly connected.	Make sure the unit is plugged in to a wall outlet using the included USB cable and AC adapter.

Touch screen is inaccurate or it is impossible to select the correct icon on the screen.	An incompatible stylus is being used.	Only use your fingers or the included InnoTab® MAX stylus on the screen.
A cartridge is inserted, but the cartridge icon does not appear on the desktop.	There is a poor cartridge connection.	Remove the cartridge, clean it if necessary, and then re-insert it into the InnoTab® MAX . For detailed instructions on cleaning a cartridge please see below.
	The cartridge is not compatible.	Check the InnoTab® MAX desktop for a message saying that the cartridge is not compatible with the InnoTab® MAX . To view a list of cartridges that are compatible with InnoTab® MAX visit http://www.innotabsoftware.com

If your **InnoTab® MAX** does not respond to an inserted cartridge, please carefully try the following:


- Turn off the **InnoTab® MAX** and unplug all wiring.
- Use a cotton swab dipped in rubbing alcohol or an alcohol-based window cleaner to gently clean the contact area of the cartridge slot.
- If necessary, dry all the clean contact areas with a soft, lint-free cloth.
- Make sure that all parts are completely dry before restoring electricity.

Static electricity may cause the **InnoTab® MAX** to malfunction. In some cases, the game play score stored in the tablet memory may be lost. In cases where the **InnoTab® MAX** is malfunctioning due to static electricity, reset the tablet by pressing and holding the Power button for 10 seconds until the unit turns off. Then press and hold the Power button for 3 seconds to turn on the unit again. Or, if the static electricity malfunction occurred during the downloading process, disconnect the USB cable, delete the corrupted file, and reset the tablet as described above. Then reconnect the USB cable and restart the download process.

For more information and troubleshooting tips, visit www.vtechkids.com/tutorials/innotabmax

Resetting the Tablet to Factory Settings

You can reset your tablet to factory settings by following the steps below.

1. Make sure the tablet is turned off.
2. Hold down the left and up arrows on the d-pad and the Help button  while turning the power on. You will see a screen with the VTech logo. Keep holding left, up, and Help until the Factory Reset screen appears. If you are having trouble, you can try pressing the d-pad diagonally between the left and up arrows instead of pressing both the left and up arrows individually.
3. A message will appear asking you to confirm that you want to reset the tablet to factory settings. Select “Yes” to continue.

WARNING: Resetting the tablet to factory settings will erase all data stored on the tablet including any apps you have installed and the progress made on any games. (Apps downloaded from Learning Lodge can be reinstalled by going to the Download Manager in Parental Controls.)

Safety Precautions for Using the Battery and Charger

Important Notes:

- This charger is not a toy. This charger is not intended for use by children.
- The tablet will charge at temperatures between 41°F-95°F(5°C-35°C). If the tablet is not charging properly, please move it to a location with a suitable temperature.
- The battery is not removable.
- Disconnect the tablet from the Power Adapter and turn off the tablet before cleaning.
- Only use the Power Adapter that is included with this package.
- To prevent fire or electric shock, do not expose the unit to rain or moisture.
- To preserve battery life, the **InnoTab® MAX** will go into a sleep mode automatically when there is no input for a few minutes. The Wi-Fi connection will also be disconnected when the battery power is low.

Standard guidelines for adapter toys and electrically operated products

- As with all electrical products, precautions should be used and observed during handling and use to prevent electric shock.
- Do not leave the toy plugged in for extended periods of time.
- The toy shall only be used with the included adapter.
- Never clean a plugged-in toy with liquid.
- Never use more than one adapter.
- The adapter is not a toy.
- Parents should periodically examine the adapter for conditions that may result in the risk of fire, electric shock, or injury to persons. In the event of such conditions, the adapter should not be used until properly repaired.

Caution

When not charging the battery or connected to a computer, close the USB port cover on the **InnoTab® MAX** for safety.

Only use the **InnoTab® MAX** Power Adapter and Micro-USB cable to charge your device.

Using a different charger may damage your **InnoTab® MAX**.

Please note: VTech is the only service provider that is authorized to replace the battery on your **InnoTab® MAX**. Any attempt to remove or replace the battery by a third party or by yourself may damage your **InnoTab® MAX** and will void your warranty. If you feel your battery needs service, please contact VTech's Consumer Services Department.

Technical Support

- If you have a problem that cannot be solved by using this manual, we encourage you to visit us online or contact our Consumer Services Department with any problems and/or suggestions that you might have. A support representative will be happy to assist you. Before requesting support, please be ready to provide or include the information below:
- The name of your product or model number (the model number is located on the back of the display panel).
- The actual problem you are experiencing.
- The actions you took right before the problem started.

Internet : www.vtechkids.com

Phone : 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada

Copyright Notices

© 2014 **VTech**[®]. All Rights Reserved. **InnoTab**[®], **Learning Lodge**[®], **VTech**[®] and the **VTech**[®] logo are registered trademarks of VTech. All other trademarks are property of their respective owners. The terms HDMI and HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing LLC in the United States and other countries.

IMPORTANT NOTE:

Creating and developing the **InnoTab**[®] **MAX** is accompanied by a responsibility that we at **VTech**[®] take very seriously. We make every effort to ensure the accuracy of the information that forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada, with any problems and/or suggestions that you might have. A service representative will be happy to help you. This product is licensed under the AVC patent portfolio license for the personal use of a consumer or other uses in which it does not receive remuneration to

(i) encode video in compliance with the AVC standard (“AVC video”) and/or

(ii) decode AVC video that was encoded by a consumer engaged in a personal activity and/or was obtained from a video provider licensed to provide AVC video.

No license is granted or shall be implied for any other use. Additional information may be obtained from MPEG LA, L.L.C. See

<http://www.mpegla.com>

Disclaimer and Limitation of Liability

VTech[®] Electronics North America, L.L.C. and its suppliers assume no responsibility for any damage or loss resulting from the use of this handbook. **VTech**[®] Electronics North America, L.L.C. and its suppliers assume no responsibility for any loss or claims by third parties that may arise through the use of this software. **VTech**[®] Electronics North America, L.L.C. and its suppliers assume no responsibility for any damage or loss caused by deletion of data as a result of malfunction, dead battery, or repairs. Be sure to make backup copies of important data on other media to protect against data loss. Company: **VTech**[®] Electronics North America, L.L.C.

Address: 1156 W. Shure Drive, Suite 200, Arlington Heights, IL 60004 USA
Phone : 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

THIS DEVICE COMPLIES WITH PART 15 OF FCC RULES AND INDUSTRY CANADA LICENCE-EXEMPT RSS STANDARD(S). OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION OF THE DEVICE.

LE PRÉSENT APPAREIL EST CONFORME AUX CNR D'INDUSTRIE CANADA APPLICABLES AUX APPAREILS RADIO EXEMPTS DE LICENCE. L'EXPLOITATION EST AUTORISÉE AUX DEUX CONDITIONS SUIVANTES: (1) L'APPAREIL NE DOIT PAS PRODUIRE DE BROUILLAGE, ET (2) L'UTILISATEUR DE L'APPAREIL DOIT ACCEPTER TOUT BROUILLAGE RADIOÉLECTRIQUE SUBI, MÊME SI LE BROUILLAGE EST SUSCEPTIBLE D'EN COMPROMETTRE LE FONCTIONNEMENT.

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

A USB cable with a ferrite core must be used with this equipment to ensure compliance with the Class B FCC limits.

Use of VTech Kid Connect™

- VTech Kid Connect™ is a subscription-based service. The VTech Kid Connect™ service included with this purchase is free for one year from the date of registration of this **InnoTab® MAX**.
- The VTech Kid Connect™ app is available through the Apple App Store and Google Play and comes with a one year free VTech Kid Connect™ subscription. Mobile data service and an Internet connection are required.

