

vtech[®]

User's Manual

Bizzy the Mix & Move Bot™



© 2016 VTech
All rights reserved
Printed in China
91-003230-005 US

Dear Parent,

At VTech®, we know how important the first day of school is for your child. To help prepare preschoolers for this important event, *VTech®* has developed the **Preschool Learning™** series of interactive toys.

Preschool Learning™ features fun characters and inviting school themes that use technology to capture a child's attention and teach important preschool skills like spelling, counting and the alphabet. These vital skills are taught in a way that's both fun and highly engaging to maintain a child's interest. Children will also be introduced to fun school subjects such as art class, music class and even recess! With **Preschool Learning™**, learning is fun from day one!

At VTech®, we know that a child has the ability to do great things. That's why all of our electronic learning products are uniquely designed to develop a child's mind and allow them to learn to the best of their ability. We thank you for trusting *VTech®* with the important job of helping your child learn and grow!

Sincerely,


Your friends at VTech®

To learn more about other VTech® toys, visit vtechkids.com

INTRODUCTION

Thank you for purchasing **Bizzy the Mix & Move Bot™** by **VTech®**.


Programmed for fun, **Bizzy the Mix & Move Bot™** is a robot buddy that responds to his 10 included accessories for role-play fun and plays a variety of activities. Bizzy can also move and dance on his wheels or his legs.



OFF/VOLUME SWITCH



10 ACCESSORIES



INCLUDED IN THIS PACKAGE

- One VTech® Bizzy the Mix & Move Bot™
- Ten accessories
- User's manual

WARNING:

All packing materials, such as tape, plastic sheets, packaging locks and tags are not part of this toy, and should be discarded for your child's safety.



ATTENTION

Pour la sécurité de votre enfant, débarrassez-vous de tous les produits d'emballage tels que rubans adhésifs, feuilles de plastique, attaches et étiquettes. Ils ne font pas partie du jouet.

NOTE: Please keep this user's manual as it contains important information.

Note:


The cable ties are not part of this toy. For your child's safety, please cut and discard the cable ties before letting them play with the product.



GETTING STARTED

BATTERY INSTALLATION

1. Make sure the unit is turned **OFF**.
2. Locate the battery cover on the bottom of the unit.
3. Use a screwdriver to loosen the screw and open the battery cover.
4. Install 3 new “AA” size (LR6/AM-3) batteries following the diagram inside the battery box. (The use of new alkaline batteries is recommended for maximum performance.)
5. Replace the battery cover and tighten the screw to secure.



BATTERY NOTICE

- Use new alkaline batteries for maximum performance.
- Use only batteries of the same or equivalent type as recommended.
- Do not mix different types of batteries: alkaline, standard (carbon-zinc) or rechargeable (Ni-Cd, Ni-MH), or new and used batteries.
- Do not use damaged batteries.
- Insert batteries with the correct polarity.
- Do not short-circuit the battery terminals.
- Remove exhausted batteries from the toy.
- Remove batteries during long periods of non-use.
- Do not dispose of batteries in fire.
- Do not charge non-rechargeable batteries.
- Remove rechargeable batteries from the toy before charging (if removable).
- Rechargeable batteries are only to be charged under adult supervision.

PRODUCT FEATURES

1. OFF/VOLUME SWITCH

To turn the unit **ON** or adjust the volume, slide the switch to **LOW** or **HIGH**. To turn the unit **OFF**, slide the switch to **OFF**.



2. MODE SWITCH

Slide the **MODE SWITCH** to choose an activity.



3. GEARS BUTTON

Press the **GEARS BUTTON** on Bizzy's tummy for a variety of responses.



4. LIGHT-UP BUTTONS

Press the **LIGHT-UP BUTTONS** to interact with the activities.



5. 10 ACCESSORIES

Attach the **10 ACCESSORIES** to the correct places and hear fun phrases. Watch Bizzy roll around on his wheels or you can put on his legs and watch him dance.



6. AUTOMATIC SHUT-OFF

To preserve battery life, **Bizzy the Mix & Move Bot™** will automatically power down after several minutes without input. The robot can be turned on again by pressing the **LIGHT-UP BUTTONS**, **GEARS BUTTON** or sliding the **MODE SWITCH**.

Note: If the unit repeatedly powers down or the lights flash then fade out, replace the batteries.

ACTIVITIES

Robot Creativity



Choose the **Robot Creativity** mode and use the **10 ACCESSORIES** to dress-up Bizzy in more than 90 silly combinations. Press the **GEARS BUTTON** and **LIGHT-UP BUTTONS** to hear songs, fun responses and to see Bizzy move around.



Challenge Time





Choose the **Challenge Time** mode and answer questions by attaching the correct accessory to the right place. Press the **GEARS BUTTON** or a **LIGHT-UP BUTTON** to repeat the question.



Robot Symphony



Choose the **Robot Symphony** mode and press the **GEARS BUTTON** to listen to fun music and watch Bizzy dance. Press the **LIGHT-UP BUTTONS** or attach one of the **10 ACCESSORIES** to create a funny remix.



SONG LIST

CHEF'S HAT SONG

Roll it, mix it, flip it, bake!
So many snacks for us to make!

PIRATE'S HAT SONG

Searching for treasure across the open sea
Yo Ho Ho, the pirate's life for me! [Wahoo!]

KITTEN HAT SONG

Kittens meow. Cows moo. Puppies bark. Monkeys say “oo oo oo”

PARTY HAT SONG

It's party time, let's boogie down!
Move it, groove it, shake it all around!

BASEBALL MITT SONG

Batter up. I swing and WHAM
Look at that, I hit a grand slam!

MAGIC WAND SONG

With a wave of my wand and a flick of my wrist, I can do magic tricks!

CAMERA SONG

Say cheese and snap a pic.
Strike a pose and click, click, click!

TAMBOURINE SONG

Jingle, jangle, shake it all around!
Listen to that beat, and boogie down!

CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat source.
3. Remove the batteries when the unit is not in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

TROUBLESHOOTING

If for some reason the program/activity stops working or malfunctions, please follow these steps:

1. Turn the unit **OFF**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit back **ON**. The unit will now be ready to play again.
5. If the product still does not work, replace with a new set of batteries.

If the problem persists, please call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada, or by going to our web site at www.vtechkids.com and filling out our Contact Us form located under the Customer Support link. A service representative will be happy to help you.

IMPORTANT NOTE:

Creating and developing **VTech**[®] products is accompanied by a responsibility that we at **VTech**[®] take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada, or by going to our web site at www.vtechkids.com and filling out our Contact Us form located under the Customer Support link with any problems and/or suggestions that you might have. A service representative will be happy to help you.

Note:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRABLE OPERATION.

CAN ICES-3 (B)/NMB-3(B)



CLASS 1
LED PRODUCT



PRODUCT WARRANTY

This Warranty is applicable only to the original purchaser, is non-transferable and applies only to "VTech" products or parts. This product is covered by a 3-month Warranty from the original purchase date, under normal use and service, against defective workmanship and materials. This Warranty does not apply to (a) consumable parts, such as batteries; (b) cosmetic damage, including but not limited to scratches and dents; (c) damage caused by use with non-VTech products; (d) damage caused by accident, misuse, unreasonable use, immersion in water, neglect, abuse, battery leakage, or improper installation, improper service, or other external causes; (e) damage caused by operating the product outside the permitted or intended uses described by VTech in the owner's manual; (f) a product or part that has been modified (g) defects caused by normal wear and tear or otherwise due to the normal aging of the product; or (h) if any VTech serial number has been removed or defaced.

Prior to returning a product for any reason, please notify the VTech Consumer Services Department by going to our web site at www.vtechkids.com, filling out our Contact Us form located under the Customer Support link or calling 1-800-521-2010.

If the service representative is unable to resolve the issue, you will be provided instructions on how to return the product and have it replaced under Warranty. Return of the product under Warranty must adhere to the following rules: If VTech believes that there may be a defect in the materials or workmanship of the product and can confirm the purchase date and location of the product, we will at our discretion replace the product with a new unit or product of comparable value. A replacement product or parts assumes the remaining Warranty of the original product or 30 days from the date of replacement, whichever provides longer coverage.

THIS WARRANTY AND THE REMEDIES SET FORTH ABOVE ARE EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES, REMEDIES AND CONDITIONS, WHETHER ORAL, WRITTEN, STATUTORY, EXPRESS OR IMPLIED. IF VTECH CANNOT LAWFULLY DISCLAIM STATUTORY OR IMPLIED WARRANTIES THEN TO THE EXTENT PERMITTED BY LAW, ALL SUCH WARRANTIES SHALL BE LIMITED TO THE DURATION OF THE EXPRESS WARRANTY AND TO THE REPLACEMENT SERVICE AS DETERMINED BY VTECH IN ITS SOLE DISCRETION.

To the extent permitted by law, VTech will not be responsible for direct, special, incidental or consequential damages resulting from any breach of Warranty.

This Warranty is not intended to persons or entities outside the United States of America. Any disputes resulting from this Warranty shall be subject to the final and conclusive determination of VTech.