

User's Manual

Turn-A-Word Apple[™]



© 2004 VTech Printed in China 91-02111-000(美)



Ever notice the look on your baby's face when they learn something new through their own discovery? These self-accomplished moments are a parent's greatest reward. To help fulfill them, **VTech**® created the **Infant Learning** series of toys.

These unique interactive learning toys directly respond to what children do naturally - play! Using innovative technology, these toys react to baby's interactions, making each play experience fun and unique as they learn age-appropriate concepts like first words, numbers, shapes, colors and music. More importantly, VTech®'s Infant Learning toys develop baby's mental and physical abilities by inspiring, engaging and teaching.

At VTech®, we know that a child has the ability to do great things. That's why all of our electronic learning products are uniquely designed to develop a child's mind and allow them to learn to the best of their ability. We thank you for trusting VTech® with the important job of helping your child learn and grow!

Sincerely,

Your Friends at VTech®

To learn more about **Infant Learning** and other **VTech**® toys, visit www.vtech.com




63100 manual 1 9/16/04, 8:49 AM

INTRODUCTION

Thank you for purchasing the VTech® Turn-A-Word Apple™ learning toy!

The VTech® Turn-A-Word Apple™ is an interactive learning toy for toddlers 12 months and up. Spin the blocks and start learning! Each block teaches letters, colors, animals, sounds and silly sentences. The brightly colored graphics help reinforce the learning with printed letters and characters related to the silly sentences. The friendly insect characters play fun sounds, sing the alphabet song and encourage your child to find animals.



63100 manual

2

9/16/04, 8:49 AM



INCLUDED IN THIS PACKAGE

- One VTech® Turn-A-Word Apple™ learning toy
- One instruction manual

WARNING: All packing materials, such as tape, plastic sheets, wire ties and tags are not part of this toy, and should be discarded for your child's safety.

GETTING STARTED

BATTERY INSTALLATION

- 1. Make sure the unit is turned OFF.
- 2. Locate the battery cover on the back of the unit.Use a screwdriver to loosen the screw.
- 3. Install 2 new "AA" (UM-3/LR6) batteries following the diagram inside the battery box. (The use of new alkaline batteries is recommended for maximum performance.)
- 4. Replace the battery cover and tighten the screw to secure the battery cover.

BATTERY NOTICE

- Install batteries correctly observing the polarity (+, -) signs to avoid leakage.
- Do not mix old and new batteries.
- Do not use batteries of different types.
- Remove batteries from the equipment when the unit will not be used for an extended period of time.



63100 manual

3

9/16/04, 8:49 AM



- Do not dispose of batteries in fire.
- · Do not attempt to recharge ordinary batteries.
- The supply terminals are not to be short-circuited.
- Only batteries of the same and equivalent type as recommended are to be used.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickelcadmium) batteries.

WE DO NOT RECOMMEND THE USE OF RECHARGEABLE BATTERIES.

PRODUCT FEATURES





2. VOLUME CONTROL SWITCH

To adjust the volume, slide the **VOLUME CONTROL SWITCH** on the back of the unit to the (**)** position for **HIGH VOLUME** or the (**)** for **LOW VOLUME**.

3. AUTOMATIC SHUT-OFF

To preserve battery life, the VTech® Turn-A-Word Apple™ learning toy will automatically power-down after several seconds without input. The unit can be turned on by pressing the on/off button.




63100 manual 4 9/16/04, 8:49 AM



ACTIVITIES

 Press the on/off button to turn the unit on. You will hear a friendly phrase and song. The worm will flash with the sound.



Spin the blocks to hear a variety of responses, including letters, silly sentences, colors, animals, and sounds. The worm will flash with the sounds.





 Spin more than one block at the same time to hear a portion of The Alphabet Song. The worm will flash with the sounds.



4. Press one of the three **insect buttons** to hear random sounds, questions or The Alphabet Song. The worm will flash with the sounds.









Slide the worm up and down to hear fun phrases or sounds. The worm will flash with the sounds.



6. If there is no input to the unit after approximately 5 seconds, you will hear a sung song. If there is no input after another 5 seconds, you will hear questions such as "Can you find the brown bear?" or "Can you find the elephant with the flute?" If there is no input after another 5 seconds, you will hear a silly sound. If there continues to be no input, the unit will automatically power-down.



SUNG SONG LYRICS - The Alphabet Song

A-B-C-D-E-F-G H-I-J-K-L-M-N-O-P Q-R-S-T-U-V W-X-Y and Z

Now I know my ABC's, next time won't you sing with me!





- 1. Keep the unit clean by wiping it with a slightly damp cloth.
- Keep the unit out of direct sunlight and away from any direct heat source.
- 3. Remove the batteries when the unit is not in use for an extended period of time.
- 4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

TROUBLESHOOTING

If for some reason the program/activity stops working or malfunctions, please follow these steps:



- 1. Please turn the unit OFF.
- 2. Interrupt the power supply by removing the batteries.
- 3. Let the unit stand for a few minutes, then replace the batteries.
- 4. Turn the unit **ON**. The unit should now be ready to play again.
- 5. If the product still does not work, replace with a new set of batteries.

If the problem persists, please call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada, and a service representative will be happy to help you.

For information on this product warranty, please call **VTech®** at 1-800-520-2010 in the U.S. or 1-877-352-8697 in Canada.



IMPORTANT NOTE:

Creating and developing Infant Learning products is accompanied by a responsibility that we at VTech® take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada, with any problems and/or suggestions that you might have. A service representative will be happy to help you.

Note:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- · Consult the dealer or an experienced radio/TV technician for help





9

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1)THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2)THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRED OPERATION.

THIS CLASS B DIGITAL APPARATUS COMPLIES WITH CANADIAN ICES-003.

CET APPAREIL NUMÉRIQUE DE LA CLASSE B EST CONFORME À LA NORME NMB-003 DU CANADA.