

vtech[®]

User's Manual

Count & Dive Penguins™



© 2012 VTech
Printed in China
91-002763-000  

Dear Parent,

Ever notice the look on your baby's face when they learn something new through their own discovery? These self-accomplished moments are a parent's greatest reward. To help fulfill them, **VTech**® created the **Infant Learning**® series of toys.

These unique interactive learning toys directly respond to what children do naturally – play! Using innovative technology, these toys react to baby's interactions, making each play experience fun and unique as they learn age-appropriate concepts like first words, numbers, shapes, colors and music. More importantly, **VTech**®'s **Infant Learning**® toys develop baby's mental and physical abilities by inspiring, engaging and teaching.

At **VTech**®, we know that a child has the ability to do great things. That's why all of our electronic learning products are uniquely designed to develop a child's mind and allow them to learn to the best of their ability. We thank you for trusting **VTech**® with the important job of helping your child learn and grow!

Sincerely,

Your friends at **VTech**®

To learn more about the **Infant Learning**® series and other **VTech**® toys, visit www.vtechkids.com

INTRODUCTION

Thank you for purchasing the **VTech® Count & Dive Penguins™** learning toy!

With the **Count & Dive Penguins™**, mommy and her ten baby penguins are ready to jump into the tub for some learning fun! Each baby easily snaps onto the mommy penguin's tummy. Once in place, the baby responds by identifying its special number and sings out fun phrases. For added fun, your child can tap the mommy's feet and the baby will release and dive into the tub! A fishing net is also included and is perfectly sized for catching, scooping and storing the penguin babies.




INCLUDED IN THIS PACKAGE


- One mommy penguin



- One fishing net



- Ten baby penguins



- One instruction manual

WARNING:

All packing materials, such as tape, plastic sheets, packaging locks and tags are not part of this toy, and should be discarded for your child's safety.


ATTENTION:

Pour la sécurité de votre enfant, débarrassez-vous de tous les produits d'emballage tels que rubans adhésifs, feuilles de plastique, attaches et étiquettes. Ils ne font pas partie du jouet.

NOTE:

Please keep this instruction manual as it contains important information.

Unlock the packaging locks:



- ① Rotate the packaging locks 90 degrees counter-clockwise.
- ② Pull out the packaging locks.


Please cut and discard the cord between the mommy penguin and the baby penguin before playing with the unit. This cord is not part of the product and should be discarded for your child's safety.




GETTING STARTED

BATTERY INSTALLATION

1. Make sure the unit is turned **OFF** and the battery cover, battery box and unit are all dry.
2. Locate the battery cover on the bottom of the unit. Use a screwdriver to loosen the two screws and unlock the fastener.



3. Install 2 new 'AAA' (AM-4/LR03) batteries following the diagram inside the battery box. (The use of new alkaline batteries is recommended for maximum performance.)




4. When closing the battery cover ensure that the two screws are tightened securely. This will avoid any water leakage.

BATTERY NOTICE

- Use new alkaline batteries for maximum performance.
- Use only batteries of the same or equivalent type as recommended.
- Do not mix different types of batteries: alkaline, standard (carbon-zinc) or rechargeable (Ni-Cd, Ni-MH), or new and used batteries.
- Do not use damaged batteries.
- Insert batteries with the correct polarity.
- Do not short-circuit the battery terminals.
- Remove exhausted batteries from the toy.
- Remove batteries during long periods of non-use.
- Do not dispose of batteries in fire.
- Do not charge non-rechargeable batteries.
- Remove rechargeable batteries from the toy before charging (if removable).
- Rechargeable batteries are only to be charged under adult supervision.

PRODUCT ASSEMBLY


1. Choose a location on the bath tub wall where the **VTech® Count & Dive Penguins™** can be mounted securely. The area should be clean and dry before suctioning the unit to the wall. For better suction, we suggest wetting the suction cups before attaching the unit to the wall. Once the unit is fastened to the wall, test the strength of the suction by pulling gently on the unit. The suction cups may not stick properly to some textured tiles.
2. To remove the unit from the wall, pull on the tabs on the back of the suction cups. We recommend that the unit be removed from the wall after each use as the strength of the suction cups cannot support prolonged use.



PRODUCT FEATURES

1. ON/OFF/VOLUME CONTROL SWITCH

To turn the unit **ON**, slide the **ON/OFF/VOLUME CONTROL SWITCH** to the **LOW VOLUME** (🔊) or **HIGH VOLUME** (🔊) position. To turn the unit **OFF**, slide the **ON/OFF/VOLUME CONTROL SWITCH** to the **OFF** (●) position.



2. AUTOMATIC SHUT-OFF


To preserve battery life, the **VTech® Count & Dive Penguins™** will automatically power-down after approximately 45 seconds without input. The unit can be turned on again by pressing any button or by inserting a baby penguin.

WARNING:


- **Batteries must be changed by an adult.**
- **We do not recommend submerging the unit in the water.**
- **This product cannot be used in salt water.**
- **This product should only be operated in water when fully assembled in accordance with the instructions.**
- **To prevent drowning, never leave a child unattended in the bath.**
- **Use a thermometer to check the temperature of the water before sitting a child in the bath. Toddlers have very sensitive skin and can burn easily if the water is too hot.**
- **Please check the suction cups periodically as they may detach after prolonged use.**
- **Children should not play with the suction cups when the unit is fastened to the wall as the unit may detach and cause injuries.**

ACTIVITIES


1. Slide the **on/off/volume control switch** to turn the unit on. You will hear a fun song and a playful phrase. The light will flash with the sound.




2. Press the **light-up music note button** to hear a sing-along song or a random melody. The light will flash with the sound.




3. Insert the **baby penguins** into the slot on the mommy's tummy, you will hear the number on the baby penguin's tummy identified, a fun phrase or a melody. The light will flash with the sound.



4. Press the mommy's **feet** to release the baby penguins. You will hear a fun phrase and a short tune. The light will flash with the sound.



If there is no baby inserted into the mommy's tummy, press the feet to hear a random question. Insert the baby penguins to answer the question. The light will flash with the sound.



MELODY LIST

1. Row, Row, Row Your Boat
2. One, Two, Buckle My Shoe
3. My Bonnie Lies Over the Ocean
4. Chicken Reel
5. Sailing, Sailing
6. This Old Man
7. Alouette
8. Jack and Jill
9. Turkey in the Straw
10. For He's a Jolly Good Fellow

SUNG SONG LYRICS

SONG 1 (to the tune of “Ten Little Indians”)

One little, two little, three little penguins.
Four little, five little, six little penguins.
Seven little, eight little, nine little penguins.
Ten little penguin babies!

SONG 2 (to the tune of “London Bridge”)

Hopped into my mommy's arms,
Where it's safe, and it's warm.
Playing with my mom is fun.
She loves me!

CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat source.
3. Make sure to empty the water out of all the elements of the unit and rinse thoroughly before drying so no sediment or cleaning products are left on the unit.
4. Make sure to dry all the elements of the unit before storing.
5. Remove the batteries when the unit is not in use for an extended period of time.
6. Do not drop the unit on hard surfaces.

TROUBLESHOOTING

If for some reason the program/activity stops working or malfunctions, please follow these steps:

1. Please turn the unit **OFF**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit **ON**. The unit should now be ready to play again.
5. If the product still does not work, replace with a new set of batteries.

If the problem persists, please call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada, and a service representative will be happy to help you.

For information on this product's warranty, please call **VTech®** 1-800-521-2010 in the U.S., or 1-877-352-8697 in Canada.

IMPORTANT NOTE:

Creating and developing **Infant Learning** products is accompanied by a responsibility that we at **VTech**® take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada, with any problems and/or suggestions that you might have. A service representative will be happy to help you.

Note:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS:
(1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND
(2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION.

THIS CLASS B DIGITAL APPARATUS COMPLIES WITH CANADIAN ICES-003.

CET APPAREIL NUMÉRIQUE DE LA CLASSE B EST CONFORME À LA NORME NMB-003 DU CANADA.

CLASS 1
LED PRODUCT