

**vtech**<sup>®</sup>

User's Manual

# Roll & Learn Activity Suitcase<sup>™</sup>



© 2013 VTech  
Printed in China  
91-002847-000 US CN

Dear Parent,

Ever notice the look on your baby's face when they learn something new through their own discovery? These self-accomplished moments are a parent's greatest reward. To help fulfill them, VTech® created the **Infant Learning**® series of toys.

These unique interactive learning toys directly respond to what children do naturally – play! Using innovative technology, these toys react to baby's interactions, making each play experience fun and unique as they learn age-appropriate concepts like first words, numbers, shapes, colors and music. More importantly, VTech®'s **Infant Learning**® toys develop baby's mental and physical abilities by inspiring, engaging and teaching.

At VTech®, we know that a child has the ability to do great things. That's why all of our electronic learning products are uniquely designed to develop a child's mind and allow them to learn to the best of their ability. We thank you for trusting VTech® with the important job of helping your child learn and grow!

Sincerely,


Your friends at VTech®

To learn more about the **Infant Learning**® series and other VTech® toys, visit [www.vtechkids.com](http://www.vtechkids.com)

# INTRODUCTION

Thank you for purchasing the **VTech® Roll & Learn Activity Suitcase™** learning toy!

The **Roll & Learn Activity Suitcase™** by **VTech®** teaches your child as they travel around the world! Children learn language and motor skills as they discover and explore through imaginative travel play. Pack your bag, it's time for learning fun ... on the road!



# INCLUDED IN THIS PACKAGE

- One VTech® Roll & Learn Activity Suitcase™
- Three clothes shapes
- Phone accessory
- Handle
- One instruction manual

**WARNING:** All packing materials, such as tape, plastic sheets, packaging locks and tags are not part of this toy, and should be discarded for your child's safety.


**Attention :** Pour la sécurité de votre enfant, débarrassez-vous de tous les produits d'emballage tels que rubans adhésifs, feuilles de plastique, attaches et étiquettes. Ils ne font pas partie du jouet.

**NOTE:** Please keep this instruction manual as it contains important information.

## GETTING STARTED

### BATTERY INSTALLATION

1. Make sure the unit is turned **OFF**.
2. Locate the battery cover inside the suitcase. Use a coin or a screwdriver to loosen the screw.
3. Install 2 new 'AA' (AM-3/LR6) batteries following the diagram inside the battery box. (The use of new alkaline batteries is recommended for maximum performance.)
4. Replace the battery cover and tighten the screw to secure.



## BATTERY NOTICE

- Use new alkaline batteries for maximum performance.
- Use only batteries of the same or equivalent type as recommended.
- Do not mix different types of batteries: alkaline, standard (carbon-zinc) or rechargeable (Ni-Cd, Ni-MH), or new and used batteries.
- Do not use damaged batteries.
- Insert batteries with the correct polarity.
- Do not short-circuit the battery terminals.
- Remove exhausted batteries from the toy.
- Remove batteries during long periods of non-use.
- Do not dispose of batteries in fire.
- Do not charge non-rechargeable batteries.
- Remove rechargeable batteries from the toy before charging (if removable).
- Rechargeable batteries are only to be charged under adult supervision.

## ASSEMBLY INSTRUCTIONS

With the **Roll & Learn Activity Suitcase™**, safety comes first. To ensure your child's safety, adult assembly is required.

1. Please remove the label that covers the hole for the handle, then remove the plastic beneath it. Keep both out of reach of children.



2. To attach the handle to the suitcase, insert the handle into the hole on top of the suitcase. You will hear it click into place. Please ensure the handle is attached securely to the suitcase. Once the handle has been attached, it cannot be removed.



## ATTENTION!

The cord attached to the t-shirt is not part of the toy. For your child's safety, please cut and discard the cord before assembly.



The cord attached to the phone accessory is also used to keep the suitcase securely closed in the package and is not part of this toy. For your child's safety, please cut and discard the cord before assembly.



# PRODUCT FEATURES

## 1. OFF/MODE SELECTOR

To turn the unit **ON**, slide the **OFF/MODE SELECTOR** to the **Travel Mode** (✈️) or **Music Mode** (🎵) position. To turn the unit **OFF**, slide the **OFF/MODE SELECTOR** to the **OFF** (●) position.



## 2. VOLUME CONTROL SWITCH

To turn the unit **ON**, slide the **VOLUME CONTROL SWITCH** to the Low (🔊) or High (🔊🔊) Volume position.



## 3. AUTOMATIC SHUT-OFF

To preserve battery life, the **VTech® Roll & Learn Activity Suitcase™** will automatically power-down after approximately 42 seconds without input. The unit can be turned on again by pressing any button and rolling the wheels.

# ACTIVITIES


1. Turn on the unit in Travel Mode or Music Mode. You will hear a variety of fun sounds, a sung song and playful phrase. The lights will flash with the sounds.




2. In Travel Mode, press the **dog/plane button** to hear about traveling to different places in the world. In Music Mode, press the **dog/plane button** to hear music. The lights will flash with the sounds.



3. **Spin the gears** to hear boat sounds in Travel Mode. Melodies will play in Music Mode. The lights will flash with the sounds.



4. Pick up or hang up the **phone** in Travel Mode to learn “Hello” and “Goodbye” in Spanish. In Music Mode, you’ll hear fun sound effects and music. The lights will flash with the sounds.




5. Press the **light-up piano buttons** to learn about things to pack in Travel Mode and to play piano notes in Music Mode. The lights will flash with the sounds.



6. Insert the **clothes shapes** into the correct places on the front panel to learn colors and clothes in Travel Mode. Hear music in Music Mode. The lights will flash with the sounds.



7. Spin the **rollers** to hear numbers and fun sounds in Travel Mode and melodies in Music Mode. The lights will flash with the sounds.





8. Turn the **sun** and slide the **moon** to learn “Good Morning” and “Good Night” in Spanish in Travel Mode. You’ll learn “sun” and “moon” in English in Music Mode. The lights will flash with the sounds.
9. Open or close the suitcase to learn “open” and “close” in English in both modes. The lights will flash with the sounds.



## MELODY LIST:

1. Jack and Jill
2. My Bonnie Lies Over the Ocean
3. London Bridge
4. Aloha Oe
5. Can Can
6. Daisy Bell
7. Oh, Dear, What Can the Matter Be?
8. Yankee Doodle
9. Humpty Dumpty
10. Mexican Hat Dance
11. This Old Man
12. I've Been Working on the Railroad
13. Twinkle, Twinkle, Little Star
14. Toyland
15. Ten Little Indians

16. Swanee
17. Chicken Reel
18. Sailor's Hornpipe
19. Oh! Susanna
20. Bill Bailey, Won't You Please Come Home?

## **SUNG SONG LYRICS**

### **SUNG SONG 1**

I'm a little traveler,  
pulling my suitcase here and there.  
I'm a great visitor,  
enjoying trips everywhere.

### **SUNG SONG 2**

Open my suitcase.  
Put my things in.  
Close my suitcase.  
Won't you take an adventure with me?

### **SUNG SONG 2**

I like to travel with my suitcase,  
by boat or plane.  
They take me a thousand miles away!

## **CARE & MAINTENANCE**

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat source.
3. Remove the batteries when the unit is not in use for an extended period of time.
4. Do not drop the unit on hard surfaces.

# TROUBLESHOOTING

If for some reason the program/activity stops working or malfunctions, please follow these steps:

1. Please turn the unit **OFF**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit **ON**. The unit should now be ready to play again.
5. If the product still does not work, replace with a new set of batteries.

If the problem persists, please call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada, and a service representative will be happy to help you.

## **IMPORTANT NOTE:**

Creating and developing **Infant Learning** products is accompanied by a responsibility that we at **VTech**<sup>®</sup> take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department at 1-800-521-2010 in the U.S., or 1-877-352-8697 in Canada, with any problems and/or suggestions that you might have. A service representative will be happy to help you.

## FCC Notice:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

Caution : Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

