

vtech[®]

User's Manual

A-Z Mouse Pad[™]



© 2008 VTech
Printed in China
91-002274-003-000 (美)

Dear Parent:

Ever notice the look on your baby's face when they learn something new through their own discovery? These self-accomplished moments are a parent's greatest reward. To help fulfill them, **VTech®** created the **Infant Learning** series of toys.

These unique interactive learning toys directly respond to what children do naturally – play! Using innovative technology, these toys react to baby's interactions, making each play experience fun and unique as they learn age-appropriate concepts like first words, numbers, shapes, colors and music. More importantly, **VTech®**'s **Infant Learning** toys develop baby's mental and physical abilities by inspiring, engaging and teaching.

At **VTech®**, we know that a child has the ability to do great things. That's why all of our electronic learning products are uniquely designed to develop a child's mind and allow them to learn to the best of their ability. We thank you for trusting **VTech®** with the important job of helping your child learn and grow!

Sincerely,


Your Friends at **VTech®**

To learn more about **Infant Learning** and other **VTech®** toys, visit www.vtechkids.com

INTRODUCTION

Thank you for purchasing the **VTech® A-Z Mouse Pad™** learning toy.

The **VTech® A-Z Mouse Pad™** is designed with curious toddlers in mind. With three modes of play, there's lots to see and learn. Flip the cell phone to call a friend, press the nose to sniff around for a tasty treat and twist the cheese for some fun phrases. The mouse in the tummy moves in all directions and teaches about numbers and letters. The large light-up screen provides a variety of animations that bring this mouse to life!



INCLUDED IN THIS PACKAGE


- One VTech® A-Z Mouse Pad™ learning toy
- One instruction manual

WARNING: All packing materials, such as tape, plastic sheets, wire ties and tags are not part of this toy, and should be discarded for your child's safety.

GETTING STARTED

BATTERY INSTALLATION

1. Make sure the unit is turned **OFF**.
2. Locate the battery cover on the back of the unit. Use a coin or a screwdriver to loosen the screw.
3. Install 3 new “AA” (UM-3/LR6) batteries following the diagram inside the battery box. (The use of new alkaline batteries is recommended for maximum performance.)
4. Replace the battery cover and tighten the screw to secure the battery cover.



BATTERY NOTICE


- Install batteries correctly observing the polarity (+, -) signs to avoid leakage.
- Do not mix old and new batteries.
- Do not mix batteries of different types: alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium).


- Remove the batteries from the equipment when the unit will not be used for an extended period of time.
- Always remove exhausted batteries from the equipment.
- Do not dispose of batteries in fire.
- Do not attempt to recharge ordinary batteries.
- The supply terminals are not to be short-circuited.
- Only batteries of the same and equivalent type as recommended are to be used.

WE DO NOT RECOMMEND THE USE OF RECHARGEABLE BATTERIES.

PRODUCT FEATURES

1. ON/OFF SWITCH


To turn the unit **ON**, press the **ON/OFF SWITCH** to the **ON** () position.

To turn the unit **OFF**, press the **ON/OFF SWITCH** to the **OFF** () position.



2. MODES OF PLAY

The three modes of play include **LETTER**, **NUMBER** and **MUSIC**. Slide the **MODE SELECTOR SWITCH** to choose a mode of play.





3. AUTOMATIC SHUT-OFF

To preserve battery life, the **VTech® A-Z Mouse Pad™** will automatically power-down after approximately 30 seconds without input. The unit can be turned on again by pressing any button or by moving the mouse.


ACTIVITIES

1. Slide the **mode selector switch** to choose a mode of play. You will hear a mouse squeak, a song related to the selected mode and a fun phrase. The light-up screen will show a variety of fun animations with the sound.
2. Move the **mouse** in the letter mode to learn letters, learn numbers in the number mode and hear random melodies in the melody mode. The songs and melodies will play one section at a time, continue moving the mouse to hear the complete melody or song. Move the mouse while a song or melody is playing to hear sound effects play over the voice or melody. The light-up screen will show a variety of fun animations with the sound.







3. Click the **mouse button** to hear the alphabet song or the number song, depending on the selected mode. Click the mouse button while a song is playing to hear random sounds play over the melody. The light-up screen will show a variety of fun animations with the sound.




4. Press the **nose button** to hear fun phrases and short tunes, depending on the selected mode. The light-up screen will show a variety of fun animations with the sound.



5. Twist the **cheese button** to hear colors, shapes, numbers and random melodies, depending on the selected mode. The light-up screen will show a variety of fun animations with the sound.



6. Open or close the **cell phone** to hear phone sounds, phone related phrases and short tunes. The light-up screen will show a variety of fun animations with the sound.





MELODY LIST

1. Farmer in the Dell
2. Three Blind Mice
3. Teddy Bears' Picnic
4. Skip to My Lou
5. Old MacDonald Had a Farm
6. Bear Went Over the Mountain
7. Ta-Ra-Ra-Boom-De-Ay
8. Home on the Range
9. London Bridge
10. Take Me Out to the Ball Game



SUNG SONG LYRICS

SONG 1: (To the tune of “Sailing, Sailing”)

Learning letters, won't it be so much fun.

We'll play and learn all through the day and sing the alphabet song.

SONG 2: (To the tune of “The Alphabet Song”)

A-B-C-D

E-F-G

H-I-J-K

L-M-N-O-P

Q-R-S

T-U-V

W-X

Y and Z



SONG 3: (To the tune of “Sailing, Sailing”)

Learning numbers, won't it be so much fun?

We'll sing and learn and play all day and count from one to ten.

SONG 4: (To the tune of “Here Were Go Round the Mulberry Bush”)

Look at me, I'm number 1, number 1, number 1.

Here's my friend the number 2, and here comes number 3.

Joining us now is 4, 5, 6, and don't forget about 7 and 8.

Finish up now with 9 and 10, why don't we count again!

SONG 5: (To the tune of “Twinkle, Twinkle, Little Star”)

Flashing lights and music too,

It's fun playing games with you.

CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat source.
3. Remove the batteries when the unit is not in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.




TROUBLESHOOTING

If for some reason the program/activity stops working or malfunctions, please follow these steps:

1. Please turn the unit **OFF**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit sit for a few minutes, then replace the batteries.
4. Turn the unit **ON**. The unit should now be ready to play again.
5. If the product still does not work, replace with a new set of batteries.

If the problem persists, please call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada, and a service representative will be happy to help you.

For information on this product's warranty, please call **VTech**® 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada.



THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS:
(1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND
(2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION.

THIS CLASS B DIGITAL APPARATUS COMPLIES WITH CANADIAN ICES-003.

CET APPAREIL NUMÉRIQUE DE LA CLASSE B EST CONFORME À LA NORME NMB-003 DU CANADA.





IMPORTANT NOTE:

Creating and developing **Infant Learning** products is accompanied by a responsibility that we at **VTech**® take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada, with any problems and/or suggestions that you might have. A service representative will be happy to help you.



Note:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

Caution: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.