

vtech[®]

User's Manual

Stacking Animal Squares™



© 2012 VTech
Printed in China
91-002683-000 (S)(A)

Dear Parent,

*Ever notice the look on your baby's face when they learn something new through their own discovery? These self-accomplished moments are a parent's greatest reward. To help fulfill them, VTech® created the **Infant Learning**® series of toys.*

*These unique interactive learning toys directly respond to what children do naturally – play! Using innovative technology, these toys react to baby's interactions, making each play experience fun and unique as they learn age-appropriate concepts like first words, numbers, shapes, colors and music. More importantly, VTech®'s **Infant Learning**® toys develop baby's mental and physical abilities by inspiring, engaging and teaching.*

At VTech®, we know that a child has the ability to do great things. That's why all of our electronic learning products are uniquely designed to develop a child's mind and allow them to learn to the best of their ability. We thank you for trusting VTech® with the important job of helping your child learn and grow!

Sincerely,


Your friends at VTech®

*To learn more about the **Infant Learning**® series and other VTech® toys, visit www.vtechkids.com*

INTRODUCTION

Thank you for purchasing the **VTech® Stacking Animal Squares™** learning toy!

The **VTech® Stacking Animal Squares™** are fun, interactive stacking blocks that encourage your baby to build and learn. These three stacking blocks feature a variety of buttons, gears, and other manipulative elements that teach animals, counting, colors and more! For added fun, the electronic block has built-in triggers that recognize the other blocks to create stories. With 24 possible combinations, your child can stack the blocks to hear a variety of phrases!



INCLUDED IN THIS PACKAGE

- VTech® Stacking Animal Squares™ (includes three blocks)
- One User's Manual

WARNING:

All packing materials, such as tape, plastic sheets, packaging locks and tags are not part of this toy, and should be discarded for your child's safety.

ATTENTION:

Pour la sécurité de votre enfant, débarrassez-vous de tous les produits d'emballage tels que rubans adhésifs, feuilles de plastique, attaches et étiquettes. Ils ne font pas partie du jouet.

NOTE:

Please keep this instruction manual as it contains important information.

Please cut and discard the cord between the upper block and the electronic block before playing with the unit. This cord is not part of the product and should be discarded for your child's safety.



INSTRUCTIONS

BATTERY INSTALLATION

1. Make sure the unit is turned **OFF**.
2. Locate the battery cover on the back of the unit. Use a screwdriver to loosen the screw.
3. Install 2 new 'AAA' (AM-4/LR03) batteries following the diagram inside the battery box. (The use of new alkaline batteries is recommended for maximum performance.)
4. Replace the battery cover and tighten the screw to secure.



BATTERY NOTICE


- Use new alkaline batteries for maximum performance.
- Use only batteries of the same or equivalent type as recommended.
- Do not mix different types of batteries: alkaline, standard (carbon-zinc) or rechargeable (Ni-Cd, Ni-MH), or new and used batteries.
- Do not use damaged batteries.
- Insert batteries with the correct polarity.
- Do not short-circuit the battery terminals.
- Remove exhausted batteries from the toy.
- Remove batteries during long periods of non-use.
- Do not dispose of batteries in fire.
- Do not charge non-rechargeable batteries.
- Remove rechargeable batteries from the toy before charging (if removable).
- Rechargeable batteries are only to be charged under adult supervision.

WE DO NOT RECOMMEND THE USE OF RECHARGEABLE BATTERIES.

PRODUCT FEATURES

1. OFF/VOLUME CONTROL SWITCH

To turn the unit **ON**, slide the **OFF/VOLUME CONTROL SWITCH** to the **LOW VOLUME** () or **HIGH VOLUME** () position. To turn the unit **OFF**, slide the **OFF/VOLUME CONTROL SWITCH** to the **OFF** (●) position.




2. AUTOMATIC SHUT-OFF


To preserve battery life, the **VTech® Stacking Animal Squares™** will automatically power-down after approximately 45 seconds without input. The unit can be turned on again by pressing any button on the electronic block, stacking the blocks or removing a stacked block.

ACTIVITIES


1. Slide the **OFF/VOLUME CONTROL SWITCH** on the electronic block to turn the unit **ON**. You will hear a song, a friendly phrase and sounds. The light will flash with the sounds.




2. When using the electronic block alone, press the DOG BUTTON to hear a song, melody and a question. Flip up the DOOR to see the dog's tail. Spin the CIRCLE to learn a number and shape. The light will flash with the sounds.




3. Stack the upper block on top of the electronic block. Depending on the side, you'll learn about shapes, numbers and colors and meet two animals. The light will flash with the sounds.



4. Stack the electronic block on top of the lower block. Depending on the side, you'll learn about numbers, colors and places and meet three animals. The light will flash with the sounds.



5. Stack the blocks. In a possible 24 combinations, you'll hear different stories about animals and places. The light will flash with the sounds.



6. If there is no input for approximately 10 seconds, you will hear a tune, a phrase and a sound. If there continues to be no input for another 10 seconds, you will hear a song. If there is no input for an additional 10 seconds, you will hear a short tune and the unit will power down. The unit can be turned on again by pressing any button on the electronic block or by stacking the blocks or removing the stacked block.

MELODY LIST

1. Bingo
2. The Entertainer
3. Shoo, Fly, Don't Bother Me
4. Three Little Kittens
5. Three Blind Mice
6. Here We Go Round the Mulberry Bush
7. Animal Fair
8. Pop! Goes the Weasel
9. Polly Wolly Doodle

SING-ALONG SONG LYRICS

I'm a friendly puppy.
Won't you come play with me?
Stacking blocks, meeting friends,
Fun with blocks never ends!

CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat source.
3. Remove the batteries when the unit will not be in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

TROUBLESHOOTING

If for some reason the program/activity stops working or malfunctions, please follow these steps:

1. Please turn the unit **OFF**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit **ON**. The unit should now be ready to play again.
5. If the product still does not work, replace with a new set of batteries.

If the problem persists, please call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada, and a service representative will be happy to help you.

IMPORTANT NOTE:

Creating and developing **Infant Learning** products is accompanied by a responsibility that we at **VTech**® take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada, with any problems and/or suggestions that you might have. A service representative will be happy to help you.

Note:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

Caution: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS:
(1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND
(2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION.

THIS CLASS B DIGITAL APPARATUS COMPLIES WITH CANADIAN ICES-003.

CET APPAREIL NUMÉRIQUE DE LA CLASSE B EST CONFORME À LA NORME NMB-003 DU CANADA.

