

**vtech**<sup>®</sup>

Instruction Manual

# KidiGo<sup>™</sup>

## BASKETBALL HOOP



# INTRODUCTION

Thank you for purchasing the **KidiGo™ Basketball Hoop**. Make playtime a slam dunk with this digital scoreboard and basketball. Five games that can be played solo or with up to five players get a boost from lights and encouraging phrases from the interactive scoreboard. Game on!

**NOTE: In order for accurate scoring the ball may need to be additionally inflated.**



# INCLUDED IN THIS PACKAGE

- KidiGo™ Basketball Hoop
- Basketball
- 2 Padded door hooks
- Quick Start Guide

## WARNING

All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties, cords and packaging screws are not part of this toy, and should be discarded for your child's safety.

## NOTE

Please keep the guide as it contains important information.

## ATTENTION


Pour la sécurité de votre enfant, débarrassez-vous de tous les produits d'emballage tels que rubans adhésifs, feuilles de plastique, attaches, étiquettes et vis d'emballage. Ils ne font pas partie du jouet.

## NOTE

Il est conseillé de conserver ce guide des parents car il comporte des informations importantes.

## Unlock the Packaging Locks


- ① Rotate the packaging lock counter-clockwise for 90 degrees.
- ② Pull out the packaging lock.



# INSTRUCTIONS

## Battery Removal and Installation

1. Make sure the unit is turned **Off**.
2. Find the battery cover on the back of the unit, use a screwdriver to loosen the screw and then open the battery box.
3. Remove old batteries by pulling up on one end of each battery.
4. Install 4 new AA (AM-3/LR6) batteries following the diagram inside the battery box. (For best performance, alkaline batteries or fully charged Ni-MH rechargeable batteries are recommended).
5. Replace the battery cover and tighten the screw to secure.



### WARNING:

Adult assembly required for battery installation.  
Keep batteries out of reach of children.



### ATTENTION :

Les piles ou accumulateurs doivent être installés par un adulte.  
Tenir les piles ou accumulateurs hors de portée des enfants.

## **IMPORTANT: BATTERY INFORMATION**

- Insert batteries with the correct polarity (+ and -).
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Do not short-circuit the supply terminals.
- Remove batteries during long periods of non-use.
- Remove exhausted batteries from the toy.
- Dispose of batteries safely. Do not dispose of batteries in fire.

## **RECHARGEABLE BATTERIES**

- Remove rechargeable batteries from the toy before charging.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not charge non-rechargeable batteries.

## **IMPORTANT : INFORMATIONS CONCERNANT LES PILES**

Les piles fournies avec le produit permettent de tester le jouet en magasin mais ne sont pas des piles longue durée.



- Mettre en place les piles ou les accumulateurs en respectant les polarités + et –.
- Ne pas mélanger des piles ou des accumulateurs neufs avec des usagés.
- Ne pas mélanger différents types de piles : alcalines, zinc-carbone et rechargeables.
- Seules des piles du type recommandé doivent être utilisées.
- Ne pas mettre les bornes d'une pile ou d'un accumulateur en court-circuit (en reliant directement le + et le –).
- Retirer les piles ou les accumulateurs en cas de non-utilisation prolongée.
- Enlever les piles ou les accumulateurs usagés du jouet.
- Ne les jeter ni au feu ni dans la nature.

## **PILES RECHARGEABLES**



- Enlever, lorsque c'est possible, les accumulateurs du jouet pour les recharger.
- Les accumulateurs ne doivent être chargés que sous la surveillance d'un adulte.
- Ne pas tenter de recharger des piles non rechargeables.

# GETTING STARTED

With the **KidiGo™ Basketball Hoop**, safety comes first. To ensure your child's safety, please only allow an adult to assemble this product.



1. Hold the rim vertically and slide it down into the backboard as shown. Then rotate it away from the backboard until you hear it click into place.



2. Place the loops at the ends of the net over the hooks on the bottom of the rim.

## NOTE



This product is in Try-Me mode in the packaging. To enter normal play mode, first switch on the unit. Then press and hold the **Restart Button** for a few seconds to proceed with normal play. If the unit powers down or if the light fades out during play, please install a new set of batteries.

## MOUNTING THE BACKBOARD

The included door hooks are designed to fit over most doors. To mount them over a door, follow these steps:

1. Insert hooks into the backboard.
2. Slide the hooks down over the top of the door.

**Note:** If you're unable to hang the backboard over a door or would rather it be lower, you can also use your own mounting hardware and the keyed holes on the back of the backboard to hang it.



# PRODUCT FEATURES

## 1. Power Button

Press the **Power Button** to turn the system **On**. Press the button again to turn it **Off**.



## 2. Volume Button

Press the **Volume Button** repeatedly to choose from four volume settings.



## 3. Game Selector

Press the **Game Selector** to choose between the five game modes.




## 4. Player Selection Button

Press the **Player Selection Button** to select up to five players in multiplayer game modes.



## 5. Restart Button

Press the **Restart Button** to restart a game.



## 6. Automatic Shut-Off

To preserve battery life, the **KidiGo™ Basketball Hoop** will automatically shut off after approximately 10 minutes without input. The system can be turned on again by pressing the **Power Button**.

# GAME MODES

## Free Play

Create with your own games! Lights and sounds play as the scoreboard counts your baskets.

## Score Challenge

Press the Player Selection Button to set the number of players and see who can make the most baskets in one minute.

## Time Challenge

Make a basket before all the backboard lights go out! As you keep going and level up, the lights will start to go out faster and faster.

## Color Challenge

Time your shot to turn on the right color lights. As you make more baskets and level up, the lights will switch on and off faster and faster.

## Hot Potato

Press the Player Selection Button to set the number of players, then shoot until you make a basket and quickly pass the ball to the next player. Whoever has the ball when the music stops is out! Keep playing until you have a winner.


# CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat sources.
3. Remove the batteries if the unit will not be in use for an extended period of time.
4. Do not drop the unit on a hard surface and do not expose the unit to moisture or water.
5. The unit is surface washable. Remove the electronic module before wiping down the unit.

# TROUBLESHOOTING

If the unit doesn't keep score properly, please try any of the following:

- Pump up the ball to ensure it is fully inflated.
- Replace the batteries
- Raise the hoop above your head.
- Stay back 2' or further from the hoop.
- Reposition the backboard so it is not in direct sunlight.



**Note:** The score counting sensor on KidiGo Basketball Hoop works best in indoor environments.

If for some reason the unit stops working or malfunctions, please follow these steps:

1. Turn the unit **Off**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit **On**. The unit should now be ready to use again.
5. If the unit still does not work, install a new set of batteries.

## IMPORTANT NOTE:

If the problem persists, please call our **Consumer Services Department** at **1-800-521-2010** in the U.S. **1-877-352-8697** in Canada, or visit our website **vtechkids.com** and fill out our Contact Us form located under the Customer Support link. Creating and developing VTech products is accompanied by a responsibility that we take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to contact us with any problems and/or suggestions you might have. A service representative will be happy to help you.

## **CAUTION**

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

## **NOTE**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## **Supplier's Declaration of Conformity**

### **47 CFR § 2.1077 Compliance Information**

Trade Name: VTech®  
Model: 5416  
Product Name: KidiGo™ Basketball Hoop  
Responsible Party: VTech Electronics North America, L.L.C.  
Address: 1156 W. Shure Drive, Suite 200  
Arlington Heights, IL 60004  
Website: vtechkids.com

**THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRED OPERATION.**

*CAN ICES-3 (B)/NMB-3(B)*

**Visit our website for more  
information about our products,  
downloads, resources and more.**

***vtechkids.com***

***vtechkids.ca***

Read our complete warranty policy online at  
*vtechkids.com/warranty*  
*vtechkids.ca/warranty*

