

vtech[®]

User's Manual

Roll 'n Learn Caterpillar™



© 2004 VTech

Printed in China

91-61570-000 (美)

Dear Parent:

*Ever notice the look on your baby's face when they learn something new through their own discovery? These self-accomplished moments are a parent's greatest reward. To help fulfill them, VTech® created the **Infant Learning** series of toys.*

*These unique interactive learning toys directly respond to what children do naturally – play! Using innovative technology, these toys react to baby's interactions, making each play experience fun and unique as they learn age-appropriate concepts like first words, numbers, shapes, colors and music. More importantly, VTech®'s **Infant Learning** toys develop baby's mental and physical abilities by inspiring, engaging and teaching.*

At VTech®, we know that a child has the ability to do great things. That's why all of our electronic learning products are uniquely designed to develop a child's mind and allow them to learn to the best of their ability. We thank you for trusting VTech® with the important job of helping your child learn and grow!

Sincerely,

Your Friends at VTech®

*To learn more about **Infant Learning**, and other VTech® toys, visit www.vtech.com*

INTRODUCTION


Thank you for purchasing the **VTech® Roll 'n Learn Caterpillar™**.

The **VTech® Roll 'n Learn Caterpillar™** is designed for babies aged six months and up. Bright, colorful shape buttons teach letters and shapes, while the silly caterpillar plays a sing-along song to keep little ones entertained. The rolling design encourages crawling and fun floor play!

TRIANGLE-SHAPED
BUTTON

CIRCLE-SHAPED
BUTTON

SQUARE-SHAPED
BUTTON



LIGHT-UP
ANTENNAE

OFF/LOW/HIGH VOLUME
CONTROL SWITCH

INCLUDED IN THIS PACKAGE

- One VTech® Roll 'n Learn Caterpillar™
- One instruction manual

WARNING: All packing materials, such as tape, plastic sheets, wire ties and tags are not part of this toy, and should be discarded for your child's safety.

BATTERY INSTALLATION

1. Make sure the unit is turned **OFF**.
2. Locate the battery cover on the bottom of the unit. Use a screwdriver to loosen the screw.
3. Install 2 new 'AAA' batteries following the diagram inside the battery box.
4. Replace the battery cover and tighten the screw to secure the battery cover.



BATTERY NOTICE

- Install batteries correctly observing the polarity (+, -) signs to avoid leakage.
- Do not mix old and new batteries.
- Do not use batteries of different types.
- Remove batteries from the equipment when the unit will not be used for an extended period of time.
- Do not dispose of batteries in fire.
- Do not attempt to recharge ordinary batteries.


- The supply terminals are not to be short-circuited.
- Only batteries of the same and equivalent type as recommended are to be used.

WE DO NOT RECOMMEND THE USE OF RECHARGEABLE BATTERIES.

PRODUCT FEATURES

1. OFF/LOW/HIGH VOLUME CONTROL SWITCH

To turn the unit on, slide the off/low/high volume control switch to the right. To turn the unit off, slide the switch back to the off (•) position.




2. AUTOMATIC SHUT-OFF


To preserve battery life, the **VTech® Roll 'n Learn Caterpillar™** will automatically power-down after approximately 30 seconds without input. The unit can be turned on again by pressing any button.

ACTIVITIES

1. Slide the off/low/high volume control switch to the low volume or high volume position. You will hear “Let’s roll” followed by a giggle sound effect, then a song will play. The light will flash with the song.



2. Press a shaped button to hear the letter identified followed by a random melody. The light will flash with the melody. Press the same shaped button again to hear a phrase followed by a giggle sound effect. The light will flash with the sound.



3. Roll the caterpillar to activate the motion sensor to hear “Let’s roll” followed by a song. The light will flash with the sound.
4. If there is no input for around 10 seconds, a random phrase will be heard. If there is no input for around 30 seconds, the unit will go into sleep mode.

MELODY LIST

- 1. Row, Row, Row Your Boat**
Row, row, row your boat,
Gently up the stream,
Merrily merrily merrily merrily,
Life is but a dream.
- 2. Merrily We Roll Along**
Merrily we roll along,
Roll along, roll along,
Merrily we roll along,
All the live-long day.
- 3. London Bridge**
London Bridge is falling down,
Falling down, falling down,
London Bridge is falling down,
My fair lady.
- 4. Twinkle, Twinkle, Little Star**
Twinkle, twinkle, little star,
How I wonder what you are,
Up above the world you fly,
Like a diamond in the sky,
Twinkle, twinkle, little star,
How I wonder what you are.
- 5. Rock-a-bye Baby**
Rock-a-bye baby,
On a tree-top,
When the wind blows,
The cradle will rock.
When the bough breaks,
The cradle will fall,
And down will come baby,
Cradle and all.

CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat source.
3. Remove the batteries when the unit is not in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

TROUBLESHOOTING

If for some reason the program/activity stops working, please follow these steps:

1. Please turn the unit **OFF**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit **ON**. The unit should now be ready to play again.

If the problem persists, please call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada, and a service representative will be happy to help you.

For information on this product warranty, please call **VTech**® at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada.

IMPORTANT NOTE:

Creating and developing **Infant Learning** products is accompanied by a responsibility that we at **VTech**® take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada with any problems and/or suggestions that you might have. A service representative will be happy to help you.

Note:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION.

THIS CLASS B DIGITAL APPARATUS COMPLIES WITH CANADIAN ICES-003.

CET APPAREIL NUMÉRIQUE DE LA CLASSE B EST CONFORME À LA NORME NMB-003 DU CANADA.