



**vtech**<sup>®</sup>

Parent's Guide


# Batter Up & Bowl Sports Arena™



91-003493-004 

# INTRODUCTION

Thank you for purchasing the **VTech® Batter Up & Bowl Sports Arena™**. Press the baseball or bowling button to hear playful songs and music to start playing. Grab the bat to hit the baseball or roll the bowling ball to hit the pins. Sports time is so much fun!



# INCLUDED IN THIS PACKAGE




- One **Batter Up & Bowl Sports Arena™** activity panel



- One baseball bat holder



- One arm with swinging baseball



- Two support feet



- One bowling ball
- One parent's guide



- One baseball bat

**WARNING:** All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties and packaging screws are not part of this toy, and should be discarded for your child's safety.

**NOTE:** Please keep this parent's guide as it contains important information.


**ATTENTION :** Pour la sécurité de votre enfant, débarrassez-vous de tous les produits d'emballage tels que rubans adhésifs, feuilles de plastique, attaches, étiquettes et vis d'emballage. Ils ne font pas partie du jouet.

**NOTE :** Il est conseillé de conserver ce guide des parents car il comporte des informations importantes.

## GETTING STARTED

### BATTERY INSTALLATION

1. Make sure the unit is turned **OFF**.
2. Locate the battery cover on the back of the sports arena. Use a coin or a screwdriver to loosen the screw.
3. Install 3 new AA (AM-3/LR6) batteries following the diagram inside the battery box. (The use of new alkaline batteries is recommended for maximum performance.)
4. Replace the battery cover and tighten the screw to secure.




## BATTERY NOTICE


- Use new alkaline batteries for maximum performance.
- Use only batteries of the same or equivalent type as recommended.
- Do not mix different types of batteries: alkaline, standard (carbon-zinc) or rechargeable, or new and used batteries.
- Do not use damaged batteries.
- Insert batteries with the correct polarity.
- Do not short-circuit the battery terminals.
- Remove exhausted batteries from the toy.
- Remove batteries during long periods of non-use.
- Do not dispose of batteries in fire.
- Do not charge non-rechargeable batteries.
- Remove rechargeable batteries from the toy before charging (if removable).
- Rechargeable batteries are only to be charged under adult supervision.

With the **Batter Up & Bowl Sports Arena™**, safety comes first. To ensure your child's safety, adult assembly is required.

## ASSEMBLY INSTRUCTIONS



1. Insert the baseball bat holder into the slot on the left side of the activity panel. You will hear it click into place when inserted correctly.



2. Insert the arm of the swinging baseball into the round slot on the top of the activity panel. You will hear it click into place when inserted correctly.




3. Insert the left and right legs of the activity panel into the blue support feet. You will hear the support feet click into place when the activity panel is inserted correctly.

4. The bowling pins may come loose with prolonged use. If the bowling pins become loose or come apart from the activity panel, please screw them back on to the main unit by twisting the bowling pin to the right.





5. The swinging baseball can detach if pulled on. If the swinging baseball detaches, it can be reattached by snapping it back into place.



# PRODUCT FEATURES

## 1. On/Off/Volume Control Switch

To turn the unit **ON**, slide the **On/Off/Volume Control Switch** to the **Low Volume** (  ) or the **High Volume** (  ) position. You will hear a song. To turn the unit **OFF**, slide the **On/Off/Volume Control Switch** to the **OFF** ( ● ) position.



**NOTE:** If the unit repeatedly powers down while playing, we suggest changing the batteries.

## 2. Automatic Shut Off

To preserve battery life, the **Batter Up & Bowl Sports Arena™** will automatically power down after 60-100 seconds without input. The unit can be turned on again by pressing the baseball or bowling button, by knocking down the bowling pins, pressing down on the peek-a-boo animals, pulling the bowling reset lever or by sliding the on/off/volume control switch.

# ACTIVITIES


## 1. Bowling Button

Press the **Bowling Button** to hear fun phrases about bowling, a song and music. The lights will flash and the light-up scoreboard will play fun light effects.



## 2. Bowling Pins

Roll the bowling ball to knock down the **Bowling Pins**. When the bowling pins are knocked down you will hear the number of pins knocked down or hear the peek-a-boo animal identified. If not all the pins are knocked down, you will hear phrases encouraging you to keep playing. The lights will flash and the light-up scoreboard will play fun light effects.




## 3. Bowling Reset Lever

Pull the **Bowling Reset Lever** to reset the bowling pins and the peek-a-boo animals. You will hear a fun phrase or animal sounds. The lights will flash and the light-up scoreboard will play fun light effects.



## 4. Peek-a-Boo Animals

When the bowling pins are knocked down, the corresponding **Peek-a-Boo Animals** will pop up. Press down on the Peek-a-Boo Animals to reset the bowling pins and hear a fun phrase or animal sounds. The lights will flash and the light-up scoreboard will play fun light effects.






## 5. Baseball Button

Press the **Baseball Button** to hear fun phrases about baseball, a song and music. The lights will flash and the light-up scoreboard will play fun light effects.



## 6. Swinging Baseball

Press the baseball button to start. Use the bat to hit the **Swinging Baseball** and you will hear a baseball sound effect followed by cheerful and encouraging phrases. If you hit the swinging baseball before pressing the baseball button, you will hear a variety of playful sounds. The lights will flash and the light-up scoreboard will play fun light effects.



**NOTE:** The light sensors behind the swinging baseball are sensitive to sunlight. The light sensors may not perform properly in brightly lit, sunny rooms or under direct sunlight.

# SONG LYRICS

## SONG 1

Play hard, swinging at the baseball,  
Roll the ball down the lane.  
We're superstars in training,  
Let the fun begin!

## **SONG 2**

Rollin', we're bowlin',  
Throw that ball right down the lane.  
See those pins, we'll knock 'em down!  
Bowling is a really fun game!

## **SONG 3**

Take me out to the ball game,  
Take me out with the crowd.  
For it's one, two, three strikes you're out,  
At the old ball game!

## **MELODY LIST**

1. The Daring Young Man on the Flying Trapeze
2. Boys and Girls Come Out to Play
3. Georgie Porgie
4. Goosey, Goosey Gander
5. Polly Put the Kettle On
6. Pop! Goes the Weasel
7. Old King Cole
8. Yankee Doodle
9. Ring Around the Rosy
10. Take Me Out to the Ball Game
11. Skip To My Lou
12. One, Two, Buckle My Shoe

## CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat sources.
3. Remove the batteries when the unit is not in use for an extended period of time.
4. Do not drop the unit on a hard surface and do not expose the unit to excess moisture.

## TROUBLESHOOTING

If for some reason the program/activity stops working, please follow these steps:

1. Turn the unit **OFF**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit **ON**. The unit will now be ready to play again.
5. If the unit still does not work, replace with an entire set of new batteries.

If the problem persists, please call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada, or by going to our website at [vtechkids.com](http://vtechkids.com) and filling out our Contact Us form located under the Customer Support link. A service representative will be happy to help you.

**IMPORTANT NOTE:**

Creating and developing **VTech®** products is accompanied by a responsibility that we at **VTech®** take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada, or by going to our website at [vtechkids.com](http://vtechkids.com) and filling out our Contact Us form located under the Customer Support link with any problems and/or suggestions that you might have. A service representative will be happy to help you.

**Note:**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION.

*CAN ICES-3 (B)/NMB-3(B)*

**Caution :** Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



CLASS 1  
LED PRODUCT

**Visit our website for more  
information about our products,  
downloads, resources and more.**

***vtechkids.com***

Read our complete warranty policy online at  
*vtechkids.com/warranty*

