

vtech

User's Manual



**GO! GO!
Smart Wheels**
Playtime with miles of learning™

Busy Day in Alphabet Town



THE LEARNING TABLET

InnoTAB[®]

Dear Parent,

At VTech®, we know how much you enjoy staying on top of the hottest trends and having the most high-tech gadgets around. We also know that your kids feel the same way. With that in mind, we developed InnoTab®, a multi-function tablet just for kids that brings all the magic of Mom's and Dad's tablets into a fun-filled learning experience that fits their active lifestyles.

InnoTab® is the next generation of learning toys for children that has a rich library of cartridge software with interactive animated e-books, learning games, creative activities along with a wide variety of additional apps. It features a brilliant color LCD touch screen, a tilt-sensor for game control, as well as a USB port for downloads, SD card slot for memory expansion and a headphone jack, all housed in a sleek, durable and compact design for easy portability.

When playing with InnoTab®, kids can look, listen, touch, and tilt their way through activities to discover a world of fun whenever they want and wherever they go. Through interactive play, your child will develop skills in reading, math, social studies, science, music, creativity, and more—which we know is important to you.

At VTech®, we are dedicated to helping your children uncover their talents. We thank you for your trust in our products that encourage active minds through imaginative play.

Sincerely,

Your friends at VTech®

To learn more about VTech® toys, visit www.vtechkids.com

INTRODUCTION

It's a busy day in Alphabet Town and the residents have a lot to do! Join Paul the Police Car, Cyrus the Cement Mixer, Casey the Car, and Frank the Fire Truck as they build roads, rescue kittens, race across town, and more in fun learning games. Or, read the e-Book to hear about an exciting adventure. Learn about letters, numbers, handwriting, vocabulary and more while exploring Alphabet Town!

INCLUDED IN THIS PACKAGE

- 1 InnoTab® cartridge – Go! Go! Smart Wheels®: Busy Day in Alphabet Town
- 1 InnoTab® cartridge user's manual

WARNING: All packing materials, such as tape, plastic sheets, packaging locks and tags are not part of this toy, and should be discarded for your child's safety.

ATTENTION: Pour la sécurité de votre enfant, débarrassez-vous de tous les produits d'emballage tels que rubans adhésifs, feuilles de plastique, attaches et étiquettes. Ils ne font pas partie du jouet.

Note: Please keep the user's manual as it contains important information.

GETTING STARTED

STEP 1: Insert the InnoTab® Cartridge

Make sure the unit is turned off. Insert the InnoTab® cartridge firmly down into the cartridge slot located on the back of the unit and push until it clicks into place as shown in the below.



STEP 2: Select the Cartridge Icon

Touch the cartridge icon on the **InnoTab®** desktop.

Note: Your **InnoTab®** desktop may look slightly different from the image on the right, depending on which version of **InnoTab®** you own.



STEP 3: Choose How You Want to Play

Touch an icon to choose an activity.

Mechanic Shop: Play a game with Casey the Car.

Catch the Letter Thief: Play a game with Paul the Police Car.

Fire Truck Rescue: Play a game with Frank the Fire Truck.

Letter Construction: Play a game with Cyrus the Cement Mixer.

Alphabet Town: Unlock the map to explore Alphabet Town.

E-Book: Read or listen to the interactive e-Book.

Body Shop: Create your own vehicle!

Photo Fun*: Take fun pictures of your friends and yourself.

Alphabet Review: Look at all the letters you've learned.



*If your version of **InnoTab®** has a built-in camera, a camera activity will appear in the cartridge menu.

If your version of **InnoTab®** does not have a built-in camera, this activity will not be available.

THE HARD KEYS



HOME

Exit the current activity and return to the **InnoTab®** desktop.



HELP BUTTON

Replay instructions, or ask for a hint.

SETTINGS

Music On/Off

To turn the background music on or off, touch the **Music On/Off** icon on the cartridge menu.



Music On/Off icon

NOTE: If your version of **InnoTab®** has a built-in camera, a camera activity will appear in the cartridge menu. If your version of **InnoTab®** does not have a built-in camera, this activity will not be available.

Levels

Select the level before each game starts.



ACTIVITIES

E-Book

Menu Page

The e-Book menu offers the following options:

Touch:

- **Read the Story:** Touch this icon to read the story.
- **Story Dictionary:** Learn new vocabulary in the Story Dictionary.
- **Settings:** Use the Settings menu to turn the background music or the vocabulary highlight on or off.

Index Page

After touching the “Read the Story” icon, you will see an index page. You can start the story from the beginning or choose any page to start reading. You can also touch the “Whole Story” icon to read the complete story from the beginning.


Story Page

In each story page, touch anywhere on the screen to stop the story narration and enter **Free Play**. When the story narration has finished, you will enter **Free Play** automatically.

In **Free Play**, you can touch the words one by one to read the story at your own pace, touch highlighted vocabulary words to hear their definitions, or touch images in the art to hear fun voices and sounds. If you don't touch the screen for a while, the story narration will continue automatically to the next page.

Click the screen left or right or touch the left or right arrow to play the previous or next page.

To listen to the story narration again, touch the **Replay** icon  on the screen. To go back to the index page, touch the **Index** icon  on the screen.



Story Dictionary

After touching the “Story Dictionary” icon, you will see a selection page. You can touch on the vocabulary words to see their definitions.



Mechanic Shop

Casey the Car needs a quick tune-up, so he's off to the mechanic shop. First, help put all the cars in the correct repair bays by matching the letters and numbers. Then, fix each car by counting out the correct number of parts that it needs.

Curriculum: Letter matching, Numbers, Counting



Catch the Letter Thief



Paul the Police Car is hot on the trail of the letter thief. First, help Paul drive through Alphabet Town while picking up clues. Then, go back to the station to look at the evidence by correctly spelling a word that has a missing letter.

Curriculum: Letters, Phonics, Vocabulary, Beginning Letters



Fire Truck Rescue



Oh no! There's an emergency across town! First, help Frank the Fire Truck get kittens out of a tree by correctly matching letters to their phonics sounds. Then, help him speed towards the scene to the next rescue while picking up letters and pictures.

Curriculum: Letters, Phonics, Vocabulary



Letter Construction

Cyrus the Cement Mixer loves his job at the construction site. First, help him prepare the construction site for a big project by tracing letters. Then, help him pour concrete into the bin with the correct number of sections.

Curriculum: Numbers, Counting, Letters, Handwriting



Alphabet Review

Review what you've learned. Tap a letter to see a picture that starts with that letter and hear the phonics sound.

Curriculum: Letters, Phonics, Vocabulary



Alphabet Town

Drive around the map to see everything in Alphabet Town! Play the learning games to earn points and unlock new pieces of the map.



Body Shop

Create your own vehicle! Choose a color, design, wheels, decorations, and a background. Then, take a picture of your creation and save it in the gallery.



Photo Fun

Put yourself in the driver's seat! Take photos of yourself and your friends in your favorite Go! Go! Smart Wheels®.



NOTE: If your version of **InnoTab®** has a built-in camera, a camera activity will appear in the cartridge menu. If your version of **InnoTab®** does not have a built-in camera, this activity will not be available.

ONLINE FEATURES

Register online to keep track of your child's learning journey with personalized recommendations. You can also connect to our **Learning Lodge™** to download great apps, games, e-Books and more!

If you have not already installed the **InnoTab®** version of the **Learning Lodge™** software on your computer, go to www.vtechkids.com/download to download and install it.

CARE & MAINTENANCE

1. Keep **InnoTab**® cartridge clean by wiping it with a slightly damp cloth. Never use solvents or abrasives.
2. Keep it out of direct sunlight and away from direct sources of heat.
3. Avoid dropping it. **NEVER** try to dismantle it.
4. Always keep **InnoTab**® cartridge away from water.

WARNING

A very small percentage of the public, due to an existing condition, may experience epileptic seizures or momentary loss of consciousness when viewing certain types of flashing colors or patterns. While **InnoTab**® **The Learning Tablet** does not contribute to any additional risks, we do recommend that parents supervise their children while they play video games. If your child experiences dizziness, altered vision, disorientation, or convulsions, discontinue use immediately and consult your physician. Please note that focusing on an LCD screen at close range and handling touch screen or g.sensor controls for a prolonged period of time may cause fatigue or discomfort. We recommend that children take a 15-minute break for every hour of play.

TROUBLESHOOTING

Please note that if you try to insert or remove an **InnoTab**® cartridge without first turning the unit **OFF**, you may experience a malfunction. If this happens, and the unit does not respond to pressing the **ON/OFF** button, disconnect the AC adaptor from the main unit or remove the batteries. Then, reconnect the adaptor, or reinstall the batteries.

TECHNICAL SUPPORT

If you have a problem that cannot be solved by using this manual, we encourage you to visit us online or contact our Consumer Services Department with any problems and/or suggestions that you might have. A support representative will be happy to assist you.

Before requesting support, please be ready to provide or include the information below:

- The name of your product or model number (the model number is typically located on the back or bottom of your product).
- The actual problem you are experiencing.
- The actions you took right before the problem started.

Internet: www.vtechkids.com

Phone: 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada

COPYRIGHT NOTICES

© VTech. All Rights Reserved. **VTech**® and the **VTech**® logo are registered trademarks of VTech. **InnoTab**® is a registered trademark of VTech. **Learning Lodge**™ is a trademark of VTech. **Go! Go! Smart Wheels**® is a registered trademark of VTech.

IMPORTANT NOTE:

Creating and developing **InnoTab**® **The Learning Tablet** products is accompanied by a responsibility that we at **VTech**® take very seriously. We make every effort to ensure the accuracy of the information that forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada, with any problems and/or suggestions that you might have. A service representative will be happy to help you.

OTHER INFO

DISCLAIMER AND LIMITATION OF LIABILITY

VTech® Electronics North America, L.L.C. and its suppliers assume no responsibility for any damage or loss resulting from the use of this handbook. **VTech**® Electronics North America, L.L.C. and its suppliers assume no responsibility for any loss or claims by third parties that may arise through the use of this software. **VTech**® Electronics North America, L.L.C. and its suppliers assume no responsibility for any damage or loss caused by deletion of data as a result of malfunction, dead battery, or repairs. Be sure to make backup copies of important data on other media to protect against data loss.

COMPANY : **VTech**® Electronics North America, L.L.C.

ADDRESS : 1156 W. Shure Drive, Suite 200, Arlington Heights, IL 60004 USA

TEL NO.: 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada

NOTE:

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAN ICES-3 (B)/NMB-3(B)

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.