



## Parent's Guide

# Peppa Pig


## Learn & Go Alphabet Car



# INTRODUCTION

Thank you for purchasing the **Peppa Pig Learn & Go Alphabet Car**.

Hop in and cruise through the alphabet with Peppa Pig and her family. Explore phonics, words and names of objects with each letter of the alphabet. Peppa Pig talks about safety rules like obeying traffic lights and buckling up your seatbelt. Grab the handle of this take-along teaching toy, and let's go!



- |                    |                         |
|--------------------|-------------------------|
| ① Volume Button    | ⑥ Four Activity Buttons |
| ② On/Off Button    | ⑦ Peppa Pig Button      |
| ③ Daddy Pig Button | ⑧ George Pig Button     |
| ④ Mummy Pig Button | ⑨ 26 Letter Buttons     |
| ⑤ LED Car Lights   | ⑩ Family Car Button     |

# INCLUDED IN THIS PACKAGE

- Peppa Pig Learn & Go Alphabet Car
- Parent's guide

## WARNING

All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties and packaging screws are not part of this toy and should be discarded for your child's safety.

## NOTE

Please keep this parent's guide as it contains important information.


## ATTENTION

Pour la sécurité de votre enfant, débarrassez-vous de tous les produits d'emballage tels que rubans adhésifs, feuilles de plastique, attaches, étiquettes et vis d'emballage. Ils ne font pas partie du jouet.

## NOTE

Il est conseillé de conserver ce guide des parents car il comporte des informations importantes.

## Unlock the Packaging Locks




- ① Rotate the packaging locks 90 degrees counterclockwise.
- ② Pull out the packaging locks and discard.

# GETTING STARTED

## Battery Removal and Installation

**Note:** For best performance, remove all factory-installed batteries from the Peppa Pig Learn & Go Alphabet Car and use new, alkaline batteries.

1. Make sure the unit is turned **Off**.
2. Find the battery cover on the back of the unit and use a screwdriver to loosen the screw and open the battery cover.
3. Remove old batteries by pulling up on one end of each battery.
4. Install 2 new AA size batteries following the diagram inside the battery compartment.
5. Replace the battery cover and tighten the screw to secure.



## BATTERY NOTICE

- Use new alkaline batteries for maximum performance.
- Use only batteries of the same or equivalent type as recommended.
- Do not mix different types of batteries: alkaline, standard (carbon-zinc) or rechargeable, or new and used batteries.
- Do not use damaged batteries.
- Insert batteries with the correct polarity (+ and -).
- Do not short-circuit the battery terminals.
- Remove exhausted batteries from the toy.
- Remove batteries during long periods of non-use.
- Do not dispose of batteries in fire.
- Do not charge non-rechargeable batteries.
- Remove rechargeable batteries from the toy before charging.
- Rechargeable batteries are only to be charged under adult supervision.


## MISE EN GARDE

- Utiliser des piles alcalines neuves pour des performances maximales.
- Seules des piles du type recommandé doivent être utilisées.
- Ne pas mélanger différents types de piles ou d'accumulateurs, ne pas mélanger des piles ou des accumulateurs neufs avec des usagés.
- Ne pas utiliser des piles ou des accumulateurs endommagés.
- Mettre en place les piles ou les accumulateurs en respectant les polarités + et - .
- Ne pas mettre les bornes d'une pile ou d'un accumulateur en court-circuit (en reliant directement le + et le -) .
- Enlever les piles ou les accumulateurs usagés du jouet.
- Retirer les piles ou les accumulateurs en cas de nonutilisation prolongée.
- Ne les jeter ni au feu ni dans la nature.
- Ne pas tenter de recharger des piles non rechargeables.
- Enlever les accumulateurs du jouet pour les recharger.
- Les accumulateurs ne doivent être chargés que sous la surveillance d'un adulte.

# PRODUCT FEATURES

## 1. On/Off Button

Press the **On/Off Button**  to turn the unit **On**. To turn the unit **Off**, press the **On/Off Button** again.



## 2. Volume Button

Press the **Volume Button**  to adjust the sound level.



## 3. Four Activity Buttons

Press any of the four **Activity Buttons** to learn and explore.




## 4. Letter Buttons

Press any of the 26 **Letter Buttons** to learn about letters or to answer questions about letters.



## 5. Four Character Buttons

Press the Peppa Pig, Daddy Pig, Mummy Pig and George Pig Buttons to hear popular phrases from each of the characters.



## 6. Two LED Car Lights

Watch the LED Car Lights flash with the sounds.



## 7. Family Car Button

Press the Family Car Button to learn about safety rules like obeying traffic lights and buckling up your seatbelt.



## 8. Automatic Shut-Off

To preserve battery life, the Peppa Pig Learn & Go Alphabet Car will automatically shut off after approximately 30 seconds without input. The unit can be turned on again by pressing the On/Off Button.

## NOTE

If the unit powers down or if the light fades out during play, please install a new set of batteries.

# ACTIVITIES

## 1. A-Z Letter Sounds



Press the **ABC Activity Button** and then press any of the **26 Letter Buttons** to learn about letters and phonics with Peppa Pig.

## 2. Learning Words With Peppa Pig



Press the **Aa Activity Button** and then press any of the **26 Letter Buttons** to learn about words and objects associated with a specific letter.

## 3. Let's Explore



Press the magnifying glass **Activity Button** to explore with Peppa Pig by answering questions about letters, objects and characters.

## 4. Music Time



Listen to music and fun sound effects. Press the musical note **Activity Button** and then press any letter, car and character buttons to jam funny sounds with the music!



## CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth. Never use solvents or abrasives.
2. Keep the unit out of direct sunlight and away from any direct heat sources.
3. Remove the batteries if the unit will not be in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

## TROUBLESHOOTING

If for some reason the unit stops working or malfunctions, please follow these steps:

1. Please turn the unit **Off**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit back **On**. The unit should now be ready to play again.
5. If the unit still does not work, install a new set of batteries.

## IMPORTANT NOTE:

If the problem persists, please call our **Consumer Services Department** at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada, or by going to our website at [vtechkids.com](http://vtechkids.com) and filling out our **Contact Us** form located under the **Customer Support** link. A service representative will be happy to help you. Creating and developing **VTech**® products is accompanied by a responsibility that we at **VTech**® take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to contact us with any problems and/or suggestions that you might have. A service representative will be happy to help you.

## Supplier's Declaration of Conformity

<b>Trade Name:</b>	VTech®
<b>Model:</b>	5306
<b>Product name:</b>	Peppa Pig Learn & Go Alphabet Car
<b>Responsible Party:</b>	VTech Electronics North America, LLC
<b>Address:</b>	1156 W. Shure Drive, Suite 200 Arlington Heights, IL 60004
<b>Website:</b>	<a href="http://vtechkids.com">vtechkids.com</a>

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRABLE OPERATION.

*CANICES-3(B)/NMB-3(B)*

## CAUTION

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

## NOTE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the distance between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



**CLASS 1  
LED PRODUCT**

Visit our website for more  
information about our products,  
downloads, resources and more.

*vtechkids.com*

Read our complete warranty policy online at  
[vtechkids.com/warranty](http://vtechkids.com/warranty)

