

**vttech**<sup>®</sup>

User's Manual

# Spin & Discover Globe<sup>™</sup>



© 2006 VTech

Printed in China

91-02165-003 (美)

**Dear Parent:**

*Ever notice the look on your baby's face when they learn something new through their own discovery? These self-accomplished moments are a parent's greatest reward. To help fulfill them, VTech® created the **Infant Learning**, series of toys.*

*These unique interactive learning toys directly respond to what children do naturally – play! Using innovative technology, these toys react to baby's interactions, making each play experience fun and unique as they learn age-appropriate concepts like first words, numbers, shapes, colors and music. More importantly, VTech®'s **Infant Learning** toys develop baby's mental and physical abilities by inspiring, engaging and teaching.*

*At VTech®, we know that a child has the ability to do great things. That's why all of our electronic learning products are uniquely designed to develop a child's mind and allow them to learn to the best of their ability. We thank you for trusting VTech® with the important job of helping your child learn and grow!*

*Sincerely,*


*Your Friends at VTech®*

*To learn more about **Infant Learning**, and other VTech® toys, visit  
[www.vtech.com](http://www.vtech.com)*

# INTRODUCTION

Thank you for purchasing the VTech® Spin & Discover Globe™ learning toy.

The VTech® Spin & Discover Globe™ is a whole new world of fun to be explored! Spin the globe and press the animal characters to hear fun phrases and melodies that teach colors and animal facts through 4 modes of play. Light-up button on top of the globe plays fun sound effects and tunes as well as flashes along with the responses to captivate toddlers attention. Pushing, sliding and twisting the buttons develops different manipulative motor skills while a variety of phrases teach early words. Press the animal buttons while the melodies play to jam sound effects into the tunes!



# INCLUDED IN THIS PACKAGE


- One VTech® Spin & Discover Globe™
- One instruction manual

**WARNING:** All packing materials, such as tape, plastic sheets, wire ties and tags are not part of this toy, and should be discarded for your child's safety.

## GETTING STARTED

### BATTERY INSTALLATION

1. Make sure the unit is turned **OFF**.
2. Locate the battery cover on the bottom of the unit. Use a coin or screwdriver to loosen the screw.
3. Install 2 new "AA" size (UM3/LR6) batteries following the diagram inside the battery box. (The use of new alkaline batteries is recommended for maximum performance.)
4. Replace the battery cover and tighten the screw to secure the battery cover.



## BATTERY NOTICE


- Install batteries correctly observing the polarity (+, -) signs to avoid leakage.
- Do not mix old and new batteries.
- Do not use batteries of different types.
- Remove batteries from the equipment when the unit will not be used for an extended period of time.
- Do not dispose of batteries in fire.
- Do not attempt to recharge ordinary batteries.
- The supply terminals are not to be short-circuited.
- Only batteries of the same and equivalent type as recommended are to be used.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.

**WE DO NOT RECOMMEND THE USE OF RECHARGEABLE BATTERIES.**

## PRODUCT FEATURES


### 1. ON/OFF BUTTON

To turn the unit **ON**, press the **ON/OFF BUTTON (●/●)**. Press the **ON/OFF BUTTON** again to turn the unit **OFF**.




## 2. VOLUME CONTROL SWITCH

To adjust the volume, locate the **VOLUME CONTROL SWITCH** on the bottom of the unit. Slide it to the (  ) position for **LOW VOLUME** or the (  ) position for **HIGH VOLUME**.



## 3. ACTIVITY SELECTOR

Slide the activity selector to choose a mode of play.



## 4. ANIMAL BUTTONS

Press the animal buttons to hear fun phrases, sound effects and melodies, depending on the selected mode.



## 5. LIGHT-UP BUTTON

Press the light-up button on the top of the globe to hear fun phrases and sound effects.



## 6. AUTOMATIC SHUT-OFF

To preserve battery life, the VTech® Spin & Discover Globe™ will automatically power-down after approximately 30 seconds without input. The unit can be turned on again by pressing the light-up button.

## ACTIVITIES

### Animal Mode

Press, twist or slide the animals to hear them introduce themselves with fun phrases and animal sound effects.

Press the light-up button on top of the globe to hear an airplane sound effect and "Look at all the animals I've discovered". The light will flash with sounds.



### Color Mode

Press, twist or slide the animals to learn colors through fun phrases.

Press the light-up button on top of the globe to hear "The world is such a colorful place, look at all the colors" and an airplane sound effect. The light will flash with the sounds.



## Instructions & Activities


7

### Animal Actions Mode



Press, twist or slide the animals to learn fun facts about animals and their movement.

Press the light-up button on top of the globe to hear "Let's explore the world" and an airplane sound effect. The lights will flash with the sounds.




### Music & Sounds Mode



Press, twist or slide the animals to hear fun melodies. Press the animal buttons while a melody is playing to jam the animal sound effect into the tune.

Press the light-up button on top of the globe to hear the theme song. The light will flash with the sounds.



### THEME SONG LYRICS (To the tune of Farmer in the Dell )

Let's travel around the world  
What animals will we see?  
A panda bear, a kangaroo  
Are some of who we'll meet

## CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat source.
3. Remove the batteries when the unit is not in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

## TROUBLESHOOTING

If for some reason the program/activity stops working, please follow these steps:

1. Turn the unit off.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit on. The unit should now be ready to play again.
5. If the product still does not work, replace with a new set of batteries.

If the problem persists, please call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada, and a service representative will be happy to help you.

For information on this product warranty, please call VTech® at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada.

**IMPORTANT NOTE:**

Creating and developing **Infant Learning** products is accompanied by a responsibility that we at **VTech®** take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada, with any problems and/or suggestions that you might have. A service representative will be happy to help you.

**Note:**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help



## Other Info

10



THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES.  
OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1)  
THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS  
DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING  
INTERFERENCE THAT MAY CAUSE UNDESIRED OPERATION.  
THIS CLASS B DIGITAL APPARATUS COMPLIES WITH CANADIAN ICES-  
003.  
CET APPAREIL NUMÉRIQUE DE LA CLASSE B EST CONFORME À LA  
NORME NMB-003 DU CANADA.

Caution: changes or modifications not expressly approved by the party  
responsible for compliance could void the user's authority to  
operate the equipment.