



CoComelon™

Instruction Manual

Go!Go! Smart Wheels®


Treehouse Track Set



INTRODUCTION

Thank you for purchasing the **Cocomelon™ Go! Go! Smart Wheels® Treehouse Track Set**.

Get ready to play in and around the treehouse. Place the JJ's Off-Road Vehicle on the **SmartPoint®** locations to hear fun phrases and sounds. Then, roll the car along to the spiral track to have sliding fun.



INCLUDED IN THE PACKAGE



One **Go! Go!**
Smart Wheels® JJ
Off-Road Vehicle



One treehouse
top



One rotating
antenna




One treehouse left



One treehouse right



One tree trunk right



One tree trunk left



One spiral track



One sliding track



One **SmartPoint®**
treehouse platform



One **SmartPoint®**
tree root plate

- Sticker sheet
- Quick Start Guide

WARNING:

All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties, cords and packaging screws are not part of this toy, and should be discarded for your child's safety.

NOTE:

Please save this manual as it contains important information.

ATTENTION :


Pour la sécurité de votre enfant, débarrassez-vous de tous les produits d'emballage tels que rubans adhésifs, feuilles de plastique, attaches, étiquettes, cordons et vis d'emballage. Ils ne font pas partie du jouet.

NOTE :

Il est conseillé de sauvegarder ce manuel d'utilisation car il comporte des informations importantes.

Unlock the Packaging Locks

- ① Rotate the packaging locks counterclockwise several times.
- ② Pull out the packaging locks and discard.



GETTING STARTED

Battery Removal and Installation

JJ's Off-Road Vehicle

1. Make sure the unit is turned **Off**.
2. Find the battery cover located on the back of the unit, use a screwdriver to loosen the screw and then open the battery cover.
3. Remove old batteries by pulling up on one end of each battery.
4. Install 2 new AAA (AM-4/LR03) batteries following the diagram inside the battery box. (For best performance, alkaline batteries or fully charged Ni-MH rechargeable batteries are recommended).
5. Replace the battery cover and tighten the screw to secure.



WARNING:

Adult assembly required for battery installation.
Keep batteries out of reach of children.



ATTENTION :

Les piles ou accumulateurs doivent être installés par un adulte.
Tenir les piles ou accumulateurs hors de portée des enfants.

IMPORTANT: BATTERY INFORMATION


- Insert batteries with the correct polarity (+ and -).
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Do not short-circuit the supply terminals.
- Remove batteries during long periods of non-use.
- Remove exhausted batteries from the toy.
- Dispose of batteries safely. Do not dispose of batteries in fire.

RECHARGEABLE BATTERIES

- Remove rechargeable batteries (if removable) from the toy before charging.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not charge non-rechargeable batteries.

LABEL APPLICATION


Please securely place the stickers on the playset as indicated on the following pages below:




ASSEMBLY INSTRUCTIONS

With the CoComelon™ Go! Go! Smart Wheels® Treehouse Track Set, safety comes first. To ensure your child's safety, adult assembly is required.


1. Assemble and attach the **Spiral Track** to the left and right **Tree Trunk** components as shown below. A clicking sound will confirm the pieces are firmly connected.




2. Assemble and attach the **Treehouse Platform** to the **Tree Trunk** components as below shown. Listen for the clicking sound to confirm the pieces are firmly connected.



3. Assemble and attach the **Treehouse** to the **Treehouse Platform** as below. A clicking sound will confirm they are firmly connected.




4. Place the **Rotating Antenna** on the **Treehouse Top**, then attach the **Treehouse Top** to the left and right **Treehouse** components as shown below. Clicking sounds will confirm the top is firmly connected.



5. Assemble and attach **Tree Root Plate** to the **Tree Trunk Right** as shown below: Make sure you hear a click sound to confirm they are firmly connected.



6. Connect the **Sliding Track** to the **Treehouse Platform** as shown below: Make sure you hear a click sound to confirm they are firmly connected.



Once you've completed the above steps, you are ready to play! You can also connect the track set to other **CoComelon™ Go! Go! Smart Wheels®** track sets to expand the CoComelon world (each sold separately). Recreate JJ's house and backyard by connecting the Treehouse Track Set and JJ's House Track Set (sold separately).




PRODUCT FEATURES

JJ's Off-Road Vehicle

1. On/Off Switch

To turn the unit **On**, slide the **On/Off Switch** to the **On** (⏻) position. To turn the unit **Off**, slide the **On/Off Switch** to the **Off** (●) position.



2. Automatic Shut-Off

To preserve battery life, the **JJ's Off-Road Vehicle** will automatically power down after approximately 60 seconds without input. The unit can be turned on again by pressing the character button, pushing the **JJ's Off-Road Vehicle** quickly, or triggering a **SmartPoint**® location.


Note: This product is in Try-Me mode in the packaging. After opening the package, turn the vehicle off and on again to proceed with normal play. If the unit powers down while playing, we suggest changing the batteries.

ACTIVITIES

JJ's Off-Road Vehicle

1. JJ Character Button

Press the character button to hear fun sounds, songs, phrases and melodies. The light will flash with the sounds.



2. SmartPoint® Locations

For added fun, **JJ's Off-Road Vehicle** interacts with the **Cocomelon™ Go! Go! Smart Wheels® Treehouse Track Set**. Simply place the vehicle on one of the two **SmartPoint®** locations to see the car's lights flash and to hear fun sounds and music.

The car even interacts with other **CoComelon™ Go! Go! Smart Wheels®** track sets (sold separately).



Treehouse Track Set

1. Spiral and Sliding Track

Place the **JJ's Off-Road Vehicle** on the **Treehouse Platform**. Roll **JJ's Off-Road Vehicle** down and around the **Spiral Track** or down the **Sliding Track**.



MELODY LIST

1. Itsy Bitsy Spider
2. Hickory Dickory Dock
3. 12345 Once I Caught a Fish Alive
4. If You're Happy and You Know It
5. This Is the Way
6. The Ants Go Marching

SONG LYRICS

Song 1

The ants go marching two by two.
Hurrah, hurrah.
The ants go marching two by two.
Hurrah, hurrah.

Song 2

It's better to work together,
Because it's double the fun.
I have fun when you have fun. Yes!
Share when you only have one.

Song 3

12345,
Once I caught a fish alive.

Song 4

Sharing makes us all happy.
We can share.
Sharing makes us all happy.

Song 5

It's the animal dance,

Let's all stand up.

And move around, and clap our hands.

CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat sources.
3. Remove the batteries if the unit will not be in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

TROUBLESHOOTING

If for some reason the unit stops working, please follow these steps:

1. Please turn the unit **Off**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit **On**. The unit should now be ready to play again.
5. If the product still does not work, replace with a new set of batteries.

NOTE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

IMPORTANT NOTE:

If the problem persists, please call our **Consumer Services Department** at **1-800-521-2010** in the U.S., **1-877-352-8697** in Canada, or by going to our website **vtechkids.com** and filling out our **Contact Us** form located under the **Customer Support** link. Creating and developing VTech products is accompanied by a responsibility that we take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to contact us with any problems and/or suggestions you might have. A service representative will be happy to help you.

Supplier's Declaration of Conformity 47 CFR § 2.1077 Compliance Information

Trade Name: VTech®
Model: 5615
Product Name: CoComelon™ Go! Go! Smart Wheels®
Treehouse Track Set
Responsible Party: VTech Electronics North America, L.L.C.
Address: 1156 W. Shure Drive, Suite 200
Arlington Heights, IL 60004
Website: vtechkids.com

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION.
CAN ICES-003(B)/NMB-003(B)

**Visit our website for more
information about our products,
downloads, resources and more.**

vtechkids.com
vtechkids.ca

Read our complete warranty policy online at
vtechkids.com/warranty
vtechkids.ca/warranty

