

nickelodeon



Parent's Guide

Marshall's Read-to-Me Adventure™




© 2018 Spin Master PAW Productions Inc. All Rights Reserved. PAW Patrol and all related titles, logos and characters are trademarks of Spin Master Ltd. Nickelodeon and all related titles and logos are trademarks of Viacom International Inc.

91-003513-000 

INTRODUCTION

Thank you for purchasing the **VTech® PAW Patrol Marshall's Read-to-Me Adventure™!**

Read exciting stories with your favorite PAW Patrol fire pup, Marshall. Follow along as Marshall reads tales of adventure, teamwork and friendship. Pretend to chat with Marshall when he asks you questions and tells you about himself. Enjoy listening to upbeat music with your favorite fire pup!



Four Included Books



INCLUDED IN THIS PACKAGE

- One **PAW Patrol Marshall's Read-to-Me Adventure™** plush
- Four books
- One parent's guide

WARNING: All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties and packaging screws are not part of this toy, and should be discarded for your child's safety.

NOTE: Please keep this parent's guide as it contains important information.


ATTENTION. Pour la sécurité de votre enfant, débarrassez-vous de tous les produits d'emballage tels que rubans adhésifs, feuilles de plastique, attaches, étiquettes et vis d'emballage. Ils ne font pas partie du jouet.

NOTE. Il est conseillé de conserver ce guide des parents car il comporte des informations importantes.

GETTING STARTED

BATTERY INSTALLATION

1. Open fabric on the back of the plush.
2. Make sure the unit is turned **OFF**.
3. Locate the battery cover and open it with a screwdriver.
4. Install 2 new AA (AM-3/LR6) batteries following the diagram inside the battery box. (The use of new, alkaline batteries is recommended for maximum performance.)
5. Replace the battery cover and tighten the screw to secure.



Note: If there is no response when the unit is switched on, please insert new batteries and try switching it on again.

BATTERY NOTICE

- Use new alkaline batteries for maximum performance.
- Use only batteries of the same or equivalent type as recommended.
- Do not mix different types of batteries: alkaline, standard (carbon-zinc) or rechargeable, or new and used batteries.
- Do not use damaged batteries.
- Insert batteries with the correct polarity.
- Do not short-circuit the battery terminals.
- Remove exhausted batteries from the toy.
- Remove batteries during long periods of non-use.
- Do not dispose of batteries in fire.
- Do not charge non-rechargeable batteries.
- Remove rechargeable batteries from the toy before charging (if removable).
- Rechargeable batteries are only to be charged under adult supervision.

PRODUCT FEATURES

1. Volume/On/Off Switch

Slide the **Volume/On/Off Switch** to the desired volume level to turn the unit **ON** or adjust the volume. To turn the unit **OFF**, slide the switch to **OFF**.



2. Fun Facts Button

Press the **Fun Facts Button** to hear Marshall tell you about himself and his tools.

3. Challenge Mode Button

Press the **Challenge Mode Button** and Marshall will ask you questions about the four included books. Once you find the answer, press Marshall's **Light-Up Badge Button** to hear his response.

4. Talk-with-Me Button

Press the **Talk-with-Me Button** and Marshall will ask you some questions.

5. Music Mode Button

Press the **Music Mode Button** to hear exciting music.

6. Light-Up Badge Button

Press the **Light-Up Badge Button** to hear Marshall's favorite phrases.

In Challenge Mode, press the **Light-Up Badge Button** when you find the answer to Marshall's question.

In Talk-with-Me mode, press the **Light-Up Badge Button** to hear Marshall read all four stories consecutively.

7. Four Book Buttons

Press the Book Button on Marshall that matches the cover of the book you want to read.

8. Automatic Shut off

To preserve battery life, the unit will automatically power down after several minutes without input. The unit can be turned on again by pressing any button.

ACTIVITIES

1. Read-to-Me Mode

Marshall reads the four included books to your child. Press one of the **Book Buttons** on Marshall's chest to hear him read the corresponding book.

2. Fun Facts Mode

Marshall tells you fun facts about being a firefighter.

3. Challenge Mode

Marshall will ask you questions about the four storybooks. Press his **Light-Up Badge Button** when you find each answer to hear a response.

4. Talk-with-Me Mode

Press the **Talk-with-Me Button** and Marshall will ask you some questions about yourself and respond.

5. Music Mode

Listen to fun music with Marshall.



CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat sources.
3. Remove the batteries when the unit is not in use for an extended period of time.
4. Do not drop the unit on a hard surface and do not expose the unit to excess moisture.

TROUBLESHOOTING

If for some reason the program/activity stops working, please follow these steps:

1. Turn the unit **OFF**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit back **ON**. The unit will now be ready to play again.
5. If the unit still does not work, replace with an entire set of new batteries.



If the problem persists, please call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada, or by going to our website at vtechkids.com and filling out our Contact Us form located under the Customer Support link. A service representative will be happy to help you.



IMPORTANT NOTE:

Creating and developing **VTech**[®] products is accompanied by a responsibility that we at **VTech**[®] take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada, or by going to our website at vtechkids.com and filling out our Contact Us form located under the Customer Support link with any problems and/or suggestions that you might have. A service representative will be happy to help you.

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION.
CAN ICES-3 (B)/NMB-3(B)



**Visit our website for more
information about our products,
downloads, resources and more.**

vtechkids.com

Read our complete warranty policy online at
vtechkids.com/warranty



TM & © 2018 VTech Holdings Limited.
All rights reserved.
Printed in China.
91-003513-000 