

Parent's Guide


Lil' Critters Soothing Starlight Polar Bear™



91-003334-0156

INTRODUCTION

Thank you for purchasing the Lil' Critters Soothing Starlight Polar Bear™. Soothe your baby to sleep while the soft polar bear projects stars onto the ceiling in four different colors while playing calming sounds, songs and seven nursery rhymes.



INCLUDED IN THIS PACKAGE

- Lil' Critters Soothing Starlight Polar Bear™
- · Parent's guide

WARNING

All packing materials, such as tape, plastic sheets, packaging locks, removable tags, cable ties, cords and packaging screws are not part of this toy, and should be discarded for your child's safety.

NOTE

Please keep this parent's guide as it contains important information.

ATTENTION

Pour la sécurité de votre enfant, débarrassez-vous de tous les produits d'emballage tels que rubans adhésifs, feuilles de plastique, attaches, étiquettes et vis d'emballage. Ils ne font pas partie du jouet.


NOTE

Il est conseillé de conserver ce guide des parents car il comporte des informations importantes.

GETTING STARTED

Battery Removal and Installation

- 1. Make sure the unit is turned Off.
- Find the battery cover located on the bottom of the unit, use a screwdriver to loosen the screw and then open the battery cover.
- 3. Remove old batteries by pulling up on one end of each battery.
- Install 2 new AA (AM-3/LR6) batteries following the diagram inside the battery box. (For best performance, alkaline batteries or fully charged Ni-MH rechargeable batteries are recommended.)



5. Replace the battery cover and tighten the screw to secure.

WARNING/ATTENTION :

Adult assembly required for battery installation. Keep batteries out of reach of children.

Les piles ou accumulateurs doivent être installés par un adulte. Tenir les piles ou accumulateurs hors de portée des enfants.

IMPORTANT: BATTERY INFORMATION

- Insert batteries with the correct polarity (+ and -).
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Do not short-circuit the supply terminals.
- Remove batteries during long periods of non-use.
- Remove exhausted batteries from the toy.
- Dispose of batteries safely. Do not dispose of batteries in fire.

RECHARGEABLE BATTERIES

- Remove rechargeable batteries from the toy before charging.
- · Rechargeable batteries are only to be charged under adult supervision.
- Do not charge non-rechargeable batteries.

IMPORTANT: INFORMATIONS CONCERNANT LES PILES

- Mettre en place les piles ou les accumulateurs en respectant les polarités + et –.
- Ne pas mélanger des piles ou des accumulateurs neufs avec des usagés.
- Ne pas mélanger différents types de piles : alcalines, zinc-carbone et rechargeables.
- Seules des piles du type recommandé doivent être utilisées.
- Ne pas mettre les bornes d'une pile ou d'un accumulateur en court-circuit (en reliant directement le + et le –).

- Retirer les piles ou les accumulateurs en cas de non-utilisation prolongée.
- Enlever les piles ou les accumulateurs usagés du jouet.
- Ne les jeter ni au feu ni dans la nature.

PILES RECHARGEABLES

- Enlever, lorsque c'est possible, les accumulateurs du jouet pour les recharger.
- Les accumulateurs ne doivent être chargés que sous la surveillance d'un adulte.
- Ne pas tenter de recharger des piles non rechargeables.

PRODUCT FEATURES

1. On/Off Switch


To turn the unit **On**, slide the **On/Off Switch** to the **On** \bigcirc position. To turn the unit **Off**, slide the **On/Off Switch** to the **Off** \bigcirc position.

2. Timer Switch

Slide the **Timer Switch** to select the length of time the unit will play. When the time is up, the unit will automatically shut down.

3. Volume Control Dial Turn the Volume Control Dial to select the desired volume.





4. Light Control Button Press the Light Control Button to select one of six light effects. Press the button until you find the desired setting.

5 Mode Buttons

Press one of the four **Mode Buttons** to choose a mode of play.

6. Sound Sensor


The Lil' Critters Soothing Starlight Polar Bear™ is equipped with a special sound sensor. Once the selected time setting has ended, the unit will automatically shut down. The sensor will reactivate the program if it detects that your baby's cry has continued for approximately four seconds without interruption. The unit will reactivate and play lullables and nature sounds.


7. Automatic Shut-Off

To preserve battery life, the Lil' Critters Soothing Starlight Polar Bear[™] will automatically shut down after the selected time. The unit can be turned on again by pressing any button or will turn on automatically when the sound sensor detects your baby's cry.

NOTE

If the unit powers down or if the light fades out during play, please install a new set of batteries.





NOTE

This product is in Try Me mode in the packaging. After opening the package, remove the Try Me tag from the bottom of the product, and then turn the unit off and on again to proceed with normal play. If the unit powers down or if the light fades out during play, please install a new set of batteries.



ACTIVITIES


1. Story Button

Press the **Story Button** to hear seven stories with fun sounds followed by soft melodies. Press the **Story Button** again to hear the next story or melody. The light pattern will fade in and fade out slowly with the sounds if the **Light Control Button** has not been pressed.


2. Lullaby Button

Press the **Lullaby Button** to hear three soothing songs followed by soft melodies. Press the **Lullaby Button** again to hear the next song or melody. The light pattern will fade in and fade out slowly with the sounds if the **Light Control Button** has not been pressed.





3. Nature Sounds Button Press the Nature Sounds Button to hear a combination of soothing nature sounds. Press the Nature Sounds Button again to hear the next sound. The light pattern will fade in and fade out slowly with the sounds if the Light Control Button has not been pressed.



4. Lullaby & Nature Sounds Button

Press the Lullaby & Nature Sounds Button to hear soothing melodies with nature sounds. Press the Lullaby & Nature Sounds Button again to hear the next melody. The light pattern will fade in and fade out slowly with the sounds if the Light Control Button has not been pressed.

SONG LYRICS

SONG 1

Row, row, row your boat, Gently down the stream. Merrily, merrily, merrily, merrily, Life is but a dream.

SONG 2

Rock-a-bye, baby, On the treetop. When the wind blows, The cradle will rock.



SONG 3

Twinkle, twinkle, little star, How I wonder what you are. Up above the world so high, Like a diamond in the sky. Twinkle, twinkle, little star, How I wonder what you are.

MELODY LIST

- 1. Diddle, Diddle, Dumpling
- 2. Hey, Diddle, Diddle
- 3. Roses Are Red
- 4. Jack Be Nimble
- 5. Polly Put the Kettle On
- 6. Hickory, Dickory, Dock
- 7. Little Bo Peep
- 8. Frère Jacques
- 9. Oh, Dear! What Can the Matter Be?
- 10. Where Has My Little Dog Gone?
- 11. Nocturne op.9 No.2
- 12. Good Morning Merry Sunshine
- 13. Teddy Bears' Picnic
- 14. Toyland
- 15. Bicycle Built for Two
- 16. Go Tell Aunt Rhody
- 17. Ride a Cock Horse to Banbury Cross
- 18. Sailing, Sailing
- 19. Grandfather's Clock
- 20. One Man Went to Mow a Meadow
- 21. The Red River Valley
- 22. I'm Forever Blowing Bubbles
- 23. Sugar Plum Fairy
- 24. Au Claire de la Lune

- 25. Home Sweet Home
- 26. Serenade
- 27. Menuet
- 28. Sur la Pont d'Avignon
- 29. Magic Flute
- 30. Irish Lullaby
- 31. New World Symphony
- 32. Rondo a Capriccio
- 33. To a Wild Rose
- 34. Canon in D
- 35. Happy Farmer
- 36. Lullaby
- 37. Hush Little Baby
- 38. Swan Lake Waltz
- 39. Berceuse
- 40. Winkum, Winkum
- 41. Für Elise
- 42. Klipp Klopp Gallop
- 43. Four Seasons Winter
- 44. Four Seasons Fall
- 45. Four Seasons Spring
- 46. Four Seasons Summer
- 47. Twinkle, Twinkle Little Star
- 48. Rock-a-Bye Baby
- 49. Air for the G String
- 50. A Thousand Stars
- 51. Piano Sonata in C, K545, 1st Movement
- 52. Minuet in G
- 53. Kinderscene
- 54. Spring Song
- 55. Waltz of the Flowers
- 56. Sleeping Beauty Waltz
- 57. Eine Kleine Nachtmusik
- 58. Greensleeves
- 59. Moonlight Sonata
- 60. Ode to Joy

CARE & MAINTENANCE

- 1. Keep the unit clean by wiping it with a slightly damp cloth.
- 2. Keep the unit out of direct sunlight and away from any direct heat sources.
- 3. Remove the batteries if the unit will not be in use for an extended period of time.
- 4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

TROUBLESHOOTING

If for some reason the unit stops working or malfunctions, please follow these steps:

- 1. Please turn the unit Off.
- 2. Interrupt the power supply by removing the batteries.
- 3. Let the unit sit for a few minutes, then replace the batteries.
- 4. Turn the unit **On**. The unit should now be ready to play again.
- 5. If the unit still does not work, replace with an entire set of new batteries.

IMPORTANT NOTE:

If the problem persists, please call our **Consumer Services Department** at **1-800-521-2010** in the U.S. or **1-877-352-8697** in Canada, or by going to our website at **vtechkids.com** and filling out our **Contact Us** form located under the **Customer Support** link. Creating and developing **VTech®** products is accompanied by a responsibility that we take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to contact us with any problems and/or suggestions that you might have. A service representative will be happy to help you.

CAUTION

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- · Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Supplier's Declaration of Conformity

47 CFR § 2.1077 Compliance Information

Trade Name:	VTech [®]
Model:	5069
Product Name:	Lil' Critters Soothing Starlight Polar Bear™
Responsible Party:	VTech Electronics North America, LLC
Address:	1156 W. Shure Drive, Suite 200
	Arlington Heights, IL 60004
Website:	vtechkids.com

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRED OPERATION.

CAN ICES-3 (B)/NMB-3(B)

Visit our website for more information about our products, downloads, resources and more.

vtechkids.com vtechkids.ca

Read our complete warranty policy online at vtechkids.com/warranty vtechkids.ca/warranty



TM & © 2017 VTech Holdings Limited. All rights reserved. **Printed in China.** 91-003334-015 (S)