

**vtech**<sup>®</sup>

User's Manual

# Spin & Learn Top™



© 2010 VTech  
Printed in China  
91-002402-007-000

*Dear Parent,*

*Ever notice the look on your baby's face when they learn something new through their own discovery? These self-accomplished moments are a parent's greatest reward. To help fulfill them, **VTech**® created the **Infant Learning**® series of toys.*

*These unique interactive learning toys directly respond to what children do naturally – play! Using innovative technology, these toys react to baby's interactions, making each play experience fun and unique as they learn age-appropriate concepts like first words, numbers, shapes, colors and music. More importantly, **VTech**®'s **Infant Learning**® toys develop baby's mental and physical abilities by inspiring, engaging and teaching.*

*At **VTech**®, we know that a child has the ability to do great things. That's why all of our electronic learning products are uniquely designed to develop a child's mind and allow them to learn to the best of their ability. We thank you for trusting **VTech**® with the important job of helping your child learn and grow!*

*Sincerely,*

*Your friends at **VTech**®*

*To learn more about the **Infant Learning**® series and other **VTech**® toys, visit [www.vtechkids.com](http://www.vtechkids.com)*

# INTRODUCTION

Thank you for purchasing the **VTech® Spin & Learn Top™** learning toy! Learning makes waves with the **VTech® Spin & Learn Top™**. Baby develops an awareness of cause-and-effect while spinning the top and pushing the buttons. 3D characters and light-up buttons teach animals, colors and counting. Fun music and friendly phrases encourage discovery in the deep sea!

STARFISH SPINNER

4 SEA ANIMALS

ROLLING BEADS

OFF/MODE SELECTOR SWITCH

3 COLOR BUTTONS



# INCLUDED IN THIS PACKAGE

One VTech® Spin & Learn Top™


One user's manual

**WARNING: All packing materials, such as tape, plastic sheets, wire ties and tags are not part of this toy, and should be discarded for your child's safety.**

## GETTING STARTED

### BATTERY INSTALLATION

1. Make sure the unit is turned **OFF**.
2. Locate the battery cover on the bottom of the unit. Use a coin or a screwdriver to loosen the screw.
3. Install 2 new 'AA' (AM-3/LR6) batteries following the diagram inside the battery box. (The use of new alkaline batteries is recommended for maximum performance.)
4. Replace the battery cover and tighten the screw to secure.





## BATTERY NOTICE


- Install batteries correctly observing the polarity (+, -) signs to avoid leakage.
- Do not mix old and new batteries.
- Do not mix batteries of different types: alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium).
- Remove the batteries from the equipment when the unit will not be used for an extended period of time
- Always remove exhausted batteries from the equipment.
- Do not dispose of batteries in fire.
- Do not attempt to recharge ordinary batteries.
- The supply terminals are not to be short-circuited.
- Only batteries of the same and equivalent type as recommended are to be used.

**WE DO NOT RECOMMEND THE USE OF RECHARGEABLE BATTERIES.**

## PRODUCT FEATURES

### 1. OFF/MODE SELECTOR SWITCH

To turn the unit **ON**, slide the **OFF/MODE SELECTOR SWITCH** to the Music Mode (🎵) or the Learning Mode (📖) position. To turn the unit **OFF**, slide the **OFF/MODE SELECTOR SWITCH** to the **OFF** position.




## 2. AUTOMATIC SHUT-OFF

To preserve battery life, the **VTech® Spin & Learn Top™** will automatically power-down after approximately 30 seconds without input. The unit can be turned on again by pressing any button.

## ACTIVITIES

1. Slide the **OFF/MODE SELECTOR SWITCH** to the Learning Mode or Music Mode position to turn the unit **ON**. You will hear a fun sing-along song and friendly phrases. The lights will flash with the sounds.



2. In Learning Mode, press the Starfish Spinner to spin the top and learn its color. In Music Mode, press the Starfish Spinner to spin the top and hear music. When a melody is playing, press the Starfish Spinner continuously to increase the tempo. Stop pressing the Starfish Spinner and the melody will return to the original tempo. When a melody is playing, press the Sea Animals to jam the corresponding animal sounds on top of the melody. Press the Color Buttons to jam other fun sounds on top of the melody.





3. In Learning Mode, press the Sea Animals to hear fun sounds and to learn about their colors. In Music Mode, press the Sea Animals to hear their sounds and music.



4. In Learning Mode, the 3 light-up Color Buttons teach colors. Press the blue button for a question about counting. Press the orange button for a question about an animal. Press the purple button for a question about an animal's color. In Music Mode, press the Color Buttons to hear music.



5. In Learning Mode, when a question is asked, if there is no answer after 5 seconds, the question will repeat. If there is no answer for another 5 seconds, you will hear the corresponding animal sound and its color.

**MELODY LIST:**

1. Row, Row, Row, Your Boat
2. Sailing, Sailing
3. Animal Fair
4. My Bonnie Lies Over the Ocean
5. Twinkle, Twinkle, Little Star
6. Alouette
7. Bingo
8. Hickory Dickory Dock



### **SUNG SONG LYRICS (to the tune of “London Bridge”)**

Take a spin around the sea!  
Meet new friends,  
Feel the breeze.  
Take a spin around the sea!  
Come, let's play!

## **CARE & MAINTENANCE**

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat source.
3. Remove the batteries when the unit will not be in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

## **TROUBLESHOOTING**

If for some reason the program/activity stops working, please follow these steps:

1. Please turn the unit **OFF**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit **ON**. The unit should now be ready to play again.
5. If the product still does not work, replace with an entire set of new batteries.



If the problem persists, please call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada, and a service representative will be happy to help you.

For information on this product's warranty, please call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada.

**IMPORTANT NOTE:**



Creating and developing **Infant Learning** products is accompanied by a responsibility that we at **VTech®** take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department at 1-800-521-2010 in the U.S., or 1-877-352-8697 in Canada, with any problems and/or suggestions that you might have. A service representative will be happy to help you.





## Note:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
  - Increase the separation between the equipment and receiver
  - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
  - Consult the dealer or an experienced radio/TV technician for help
- 

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION.

THIS CLASS B DIGITAL APPARATUS COMPLIES WITH CANADIAN ICES-003.

CET APPAREIL NUMÉRIQUE DE LA CLASSE B EST CONFORME À LA NORME NMB-003 DU CANADA.

**Caution:** Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

