

vtech®

User's Manual

Sit-to-
Stand™

Alphabet Train™



© 2012 VTech
Printed in China
91-002305-035 US ©

Dear Parent,

*Ever notice the look on your baby's face when they learn something new through their own discovery? These self-accomplished moments are a parent's greatest reward. To help fulfill them, VTech® created the **Infant Learning**® series of toys.*

*These unique interactive learning toys directly respond to what children do naturally – play! Using innovative technology, these toys react to baby's interactions, making each play experience fun and unique as they learn age-appropriate concepts like first words, numbers, shapes, colors and music. More importantly, VTech®'s **Infant Learning**® toys develop baby's mental and physical abilities by inspiring, engaging and teaching.*

At VTech®, we know that a child has the ability to do great things. That's why all of our electronic learning products are uniquely designed to develop a child's mind and allow them to learn to the best of their ability. We thank you for trusting VTech® with the important job of helping your child learn and grow!

Sincerely,

Your friends at VTech®

*To learn more about the **Infant Learning**® series and other VTech® toys, visit www.vtechkids.com*

INTRODUCTION

Thank you for purchasing the **VTech® Sit-to-Stand Alphabet Train™** learning toy!

The **VTech® Sit-to-Stand Alphabet Train™** will take your child on a journey through letters, numbers, music and more. Entertaining sound effects, dancing lights and fun melodies reward your child's curiosity while taking baby on the ride of a lifetime!

VOLUME
CONTROL
SWITCH

BLOCK
CHUTE

NUMBER
BUTTONS

ATTACHABLE
CARRIAGE WITH
BLOCK STORAGE

OFF/MODE
SELECTOR
SWITCH

BLOCK
RECOGNITION
SLOTS

BOOK WITH
6 PAGES

13 LETTER
BLOCKS

INCLUDED IN THIS PACKAGE


- One engine




- One engine handle



- Two back engine wheels



- One soft hinge with two screws




- One instruction manual


- One carriage



- Two front engine wheels



- Four carriage wheels on axles, four axle covers and eight screws



- 13 alphabet blocks



WARNING: All packing materials, such as tape, plastic sheets, packaging locks and tags are not part of this toy, and should be discarded for your child's safety.


Attention : Pour la sécurité de votre enfant, débarrassez-vous de tous les produits d'emballage tels que rubans adhésifs, feuilles de plastique, attaches et étiquettes. Ils ne font pas partie du jouet.

NOTE: Please keep this instruction manual as it contains important information.

GETTING STARTED

BATTERY INSTALLATION

1. Make sure the unit is turned **OFF**.
2. Locate the battery cover on the back of the unit. Use a coin or a screwdriver to loosen the screw.
3. Install 3 new 'AA' (AM-3/LR6) batteries following the diagram inside the battery box.
4. Replace the battery cover and tighten the screw to secure the battery cover.



BATTERY NOTICE


- Use new alkaline batteries for maximum performance.
- Use only batteries of the same or equivalent type as recommended.
- Do not mix different types of batteries: alkaline, standard (carbon-zinc) or rechargeable (Ni-Cd, Ni-MH), or new and used batteries.
- Do not use damaged batteries.
- Insert batteries with the correct polarity.
- Do not short-circuit the battery terminals.
- Remove exhausted batteries from the toy.
- Remove batteries during long periods of non-use.

- Do not dispose of batteries in fire.
- Do not charge non-rechargeable batteries.
- Remove rechargeable batteries from the toy before charging (if removable).
- Rechargeable batteries are only to be charged under adult supervision.




With the **VTech® Sit-to-Stand Alphabet Train™**, safety comes first. To ensure your child's safety, adult assembly is required.
Attention: ce jouet doit être assemblé par un adulte !
Assurez-vous que toutes les parties sont correctement assemblées avant usage.

Assembly Instructions

1. Install the two green front wheels onto the front of the engine by placing them over the yellow front axles. Push the wheels onto the axles until you hear a click. Once you have installed the wheels, they cannot be removed.
2. Install the two green back engine wheels onto the back of the engine by inserting them into the yellow sockets at the back of the train. Push the wheels into the sockets until you hear a click. Once you have installed the wheels, they cannot be removed.




3. Insert the green carriage wheels on axles into the corresponding grooves on the bottom of the carriage. Place the blue axle covers over the axles with the flat side up and the notched side between the screw holes and the blue tabs on the bottom of the carriage. Slide the axle covers toward the wheels, making sure the flat side slides under the tabs and the screw holes align with those on the carriage. Insert the screws into the holes and tighten with a screwdriver to secure.




4. Position the handle so that the curved part of the handle faces the back of the engine. Insert the handle into the hole in the top of the engine until you hear a click. Once you have installed the handle, it cannot be removed.





5. Position the soft, blue hinge so that its large hole is facing up and to the front. Insert the hinge into the hole at the front of the carriage, use a screwdriver to tighten the two screws on the bottom of the carriage.



6. To attach the carriage to the engine, insert it into the slot at the back of engine. You will hear a click, which lets you know the carriage is attached correctly.




7. To detach the carriage from the engine, press and hold the blue button under the end of the engine, pull the carriage from the slot.



PRODUCT FEATURES


1. OFF/MODE SELECTOR SWITCH

To turn the unit **ON**, slide the red **OFF/MODE SELECTOR SWITCH** located at the top of the engine to the **Learning Mode** (📖) or **Discovery Mode** (👤) position. To turn the unit **OFF**, slide the **OFF/MODE SELECTOR SWITCH** to the **OFF (OFF)** position.



2. VOLUME CONTROL SWITCH

To adjust the volume, slide the **VOLUME CONTROL SWITCH** to the **LOW VOLUME** or the **HIGH VOLUME** position.




3. AUTOMATIC SHUT-OFF

To preserve battery life, the **VTech® Sit-to-Stand Alphabet Train™** will automatically power-down after approximately 78 seconds without input. The unit can be turned on again by pressing any button.

ACTIVITIES

1. Slide the red **off/mode selector switch** located at the top of the engine to the **Learning Mode** (📖) or **Discovery Mode** (🔑) position to turn the unit on. You will hear a train engine sound, entertaining phrases and music. The lights will flash with the sounds.




2. Press the **elephant button** to hear an elephant sound effect followed by fun phrases and sung songs. The lights will flash with the sounds.



3. Press the **number buttons** to learn about numbers in the **Learning Mode** and learn about colors in the **Discovery Mode**. The lights will flash with the sounds.



4. Turn the **book's pages** to learn about letters and objects and listen to fun stories in both modes. The lights will flash with the sounds.



5. Place the **blocks** onto the train's block recognition slots to learn letters and objects in both modes. Upbeat melodies and fun sounds will accompany the play. The lights will flash with the sounds.



6. Drop the blocks into the chute at the top of the train and they'll slide out the back!



7. If there is no input to the unit after approximately 10 seconds, you will hear a fun sung song. After another 10 seconds if there is still no input, you will hear a question, which will encourage the child to find the correct block according to the book page. After another 10 seconds if there is still no input, you will hear the phrase "Bye-bye," then the unit will automatically power-down.



MELODY LIST

1. Baby Elephant Walk
2. I've Been Working on the Railroad
3. Pop! Goes the Weasel
4. Twinkle, Twinkle, Little Star
5. It's Raining, It's Pouring
6. This Old Man
7. Three Little Kittens
8. Humpty Dumpty
9. Hickory Dickory Dock
10. Mulberry Bush

SUNG SONG LYRICS

SONG 1 (Tune of "London Bridge")

Happily we chug along,
Learning letters, singing songs.
Happily we chug along,
On the train!

SONG 2 (Tune of "Alphabet Song")

A-B-C-D
E-F-G
H-I-J-K
L-M-N-O-P
Q-R-S
T-U-V
W-X
Y and Z.

Now I know my ABCs, come and ride the train with me!





CARE & MAINTENANCE

1. Keep the unit and book pages clean by wiping with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat source.
3. Remove the batteries when the unit is not in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

TROUBLESHOOTING

If for some reason the program/activity stops working or malfunctions, please follow these steps:

1. Please turn the unit **OFF**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit **ON**. The unit should now be ready to play again.
5. If the product still does not work, replace with a new set of batteries.

If the problem persists, please call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada, and a service representative will be happy to help you.

For information on this product's warranty, please call **VTech**[®] 1-800-521-2010 in the U.S., or 1-877-352-8697 in Canada.



IMPORTANT NOTE:

Creating and developing **Infant Learning** products is accompanied by a responsibility that we at **VTech®** take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department at 1-800-521-2010 in the U.S., or 1-877-352-8697 in Canada, with any problems and/or suggestions that you might have. A service representative will be happy to help you.

FCC Information:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

Caution : Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



CLASS 1
LED PRODUCT



WARNING:
Adult assembly required.

ATTENTION !

Ce jouet doit être assemblé
par un adulte.