

vtech[®]


Instruction Manual

Walk & Woof Puppy™



INTRODUCTION

Thank you for purchasing the **Walk & Woof Puppy™** toy!
This playful interactive puppy loves to follow you around. Pull the puppy along or press the buttons to hear letters, parts of the body, and to listen to music.



INCLUDED IN THE PACKAGE

- Walk & Woof Puppy™
- Quick Start Guide

WARNING

All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties, cords and packaging screws are not part of this toy, and should be discarded for your child's safety.

NOTE

Please save this Instruction Manual as it contains important information.


ATTENTION

Pour la sécurité de votre enfant, débarrassez-vous de tous les produits d'emballage tels que rubans adhésifs, feuilles de plastique, attaches, étiquettes, cordons et vis d'emballage. Ils ne font pas partie du jouet.

NOTE

Il est conseillé de sauvegarder ce manuel d'instructions car il comporte des informations importantes.

Unlock the Packaging Locks




- ① Rotate the packaging lock 90 degrees counterclockwise.
- ② Pull out the packaging locks and discard.

GETTING STARTED

Battery Removal and Installation

1. Make sure the unit is turned **Off**.
2. Find the battery cover on the bottom of the unit, use a screwdriver to loosen the screw, and then open the battery cover.
3. Remove old batteries by pulling up on one end of each battery.
4. Install 2 new AAA (AM-4/LR03) batteries following the diagram inside the battery box. (For best performance, alkaline batteries or fully charged Ni-MH rechargeable batteries are recommended.)
5. Replace the battery cover and tighten the screw to secure.



WARNING:

Adult assembly required for battery installation.
Keep batteries out of reach of children.



ATTENTION :

Les piles ou accumulateurs doivent être installés par un adulte.
Tenir les piles ou accumulateurs hors de portée des enfants.

IMPORTANT: BATTERY INFORMATION

- Insert batteries with the correct polarity (+ and -).
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Do not short-circuit the supply terminals.

- Remove batteries during long periods of non-use.
- Remove exhausted batteries from the toy.
- Dispose of batteries safely. Do not dispose of batteries in fire.


RECHARGEABLE BATTERIES:

- Remove rechargeable batteries (if removable) from toy before charging.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not charge non-rechargeable batteries.

PRODUCT FEATURES


1. On/Off/Volume Selector

To turn the unit **On**, slide the **On/Off/Volume Selector** to the Low volume (🔊) or High volume (🔊🔊) position. You will hear a sound, phrases and a song. To turn the unit **Off**, slide the **On/Off/Volume Selector** to the **Off** ● position.



2. Pull Cord Storage

To convert the unit from a pull toy to a push toy, store the pull cord by opening the battery compartment and tucking the cord inside. To use as a pull toy again, open the battery compartment and extend the cord. Lay the cord in the notch and close the battery compartment. For your child's safety, we suggest you store the pull cord in the compartment until your child is walking and to supervise your child when playing with the pull cord.



3. Automatic Shut-Off

To preserve battery life, the **Walk & Woof Puppy™** will automatically shut off after approximately 65 seconds without input. The puppy can be turned on again by pressing any button.

NOTE

If the unit powers down or if the light fades out during play, please install a new set of batteries.

ACTIVITIES

1. Learning Buttons

Press the **Learning Buttons** to learn letters, puppy facts and songs, you will also hear melodies and sounds. The light will flash with the sounds.



2. Pat the Puppy

Press the puppy's **Head** to hear cute sounds and phrases. The light will flash with the sounds, and the ears will move up and down.



3. Pull Along

Pull the puppy to hear fun sounds and phrases to encourage play. The light will flash with the sounds.



MELODIES

1. While Strolling Through the Park
2. The Green Grass Grew All Around
3. Where Has My Little Dog Gone?
4. Skip to My Lou
5. Polly Put the Kettle on
6. Humpty, Dumpty
7. For He's a Jolly Good Fellow
8. On Top of Old Smokey
9. Aiken Drum
10. Diddle, Diddle, Dumpling
11. One, Two, Buckle My Shoe
12. Toyland

SONG LYRICS

Song 1

I'm a puppy, and I like to play.
I walk and run and sleep all day.
Woof, woof, woof, woof, woof.
Woof, woof, woof, woof, woof.
Woof, woof, woof, woof, woof.
I'm ready to go for a walk with you!

Song 2

A B C D E F G,
H I J K L M N O P.
Q R S T U V,
W X Y and Z.
Now I know my ABCs,
Next time won't you sing with me!

Song 3

I love to play with you every day.
We can play fetch or go for a walk.
When we get tired, we can take a nap.
Wherever you go, I wanna be with you.

Song 4

D is for dog.
Duh-duh-duh-duh-dog.
D is for dog. I'm your dog!

Song 5

When we play, I wag my tail,
Wag, wag, wag, wag my tail.
When we play, I wag my tail,
You make me so happy!

CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat sources.
3. Remove the batteries if the unit will not be in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

TROUBLESHOOTING

If for some reason the program/activity stops working or malfunctions, please follow these steps:

1. Please turn the unit **Off**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit **On**. The unit should now be ready to use again.
5. If the unit still does not work, install a new set of batteries.

IMPORTANT NOTE:

If the problem persists, please call our **Consumer Services Department** at **1-800-521-2010** in the U.S. or **1-877-352-8697** in Canada, or by going to our website at **vtechkids.com** and filling out our **Contact Us** form located under the **Customer Support** link. Creating and developing VTech products is accompanied by a responsibility that we take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to contact us with any problems and/or suggestions that you might have. A service representative will be happy to help you.

NOTE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Supplier's Declaration of Conformity

47 CFR § 2.1077 Compliance Information

Trade Name: VTech®
Model: 565000
Product Name: Walk & Woof Puppy™
Responsible Party: VTech Electronics North America, LLC
Address: 1156 W. Shure Drive, Suite 200
Arlington Heights, IL 60004
Website: vtechkids.com

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRED OPERATION.
CAN ICES-003(B)/NMB-003(B)

**Visit our website for more
information about our products,
downloads, resources and more.**

vtechkids.com
vtechkids.ca

Read our complete warranty policy online at
vtechkids.com/warranty
vtechkids.ca/warranty

