


*Dear Parent:*

*At VTech® we know that a child has the ability to do great things. That's why all of our electronic learning products are uniquely designed to develop a child's mind and allow them to learn to the best of their ability. Whether it's introducing numbers and letters, identifying colors and shapes, or stimulating senses with lights and music, all VTech® infant and toddler learning products encourage your child's natural growth and discovery skills. When it comes to providing electronic learning products that enlighten, entertain and develop minds, at VTech® we see the potential in every child.*

# INTRODUCTION

Thank you for purchasing **VTech® Soothing Safari™** learning toy! This product is one of a family of high quality electronic learning toys. We at **VTech®** are committed to providing the best possible products to entertain and educate your child. Should you have any questions or concerns, please call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-800-267-7377 in Canada.

The **VTech® Soothing Safari™** is specifically designed for infants from birth and up. Baby can interact with three friendly animal characters. Each character has a sensor that triggers friendly phrases, lights, sound effects and music. The **VTech® Soothing Safari™** will act as a companion throughout baby's early years of development.




# INCLUDED IN THIS PACKAGE

1. One VTech® Soothing Safari™ learning toy
2. Two plastic straps for hanging up the unit on the bed
3. One soft bumper for covering the unit
4. One instruction manual

**WARNING:** All packing materials, such as tape, plastic sheets, wire ties and tags are not part of this toy, and should be discarded for your child's safety.

## BATTERY INSTALLATION

1. Make sure the unit is turned off.
2. Remove the soft bumper to locate the battery cover on the back of the unit. Use a screwdriver to loosen the screw.
3. Install 3 new “AA” (UM-3/LR6) batteries following the diagram inside the battery box. (The use of new alkaline batteries is recommended for maximum performance.)
4. Replace the battery cover and tighten the screw to secure the battery cover.



## BATTERY NOTICE

- Install batteries correctly observing the polarity (+, -) signs to avoid leakage.
- Do not mix old and new batteries.

- Remove exhausted or new batteries from the equipment when the unit will not be used for an extended period of time.
- Do not dispose of batteries in fire.
- Do not attempt to recharge ordinary batteries.
- The supply terminals are not to be short-circuited.
- Only batteries of the same and equivalent type as recommended are to be used.

## **WE DO NOT RECOMMEND THE USE OF RECHARGEABLE BATTERIES.**


**NOTE:** If for some reason the program/activity stops working, please follow these steps:

1. Please turn the unit **OFF**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit **ON**. The unit should now be ready to play again.


If the problem persists, please call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-800-267-7377 in Canada.

## **ASSEMBLY THE SOFT BUMPER**

1. Place the soft bumper around the main unit.





2. Push the pins on the soft bumper into the main unit. Please note to make sure that all pins are securely fastened to the main unit.





## CRIB ATTACHMENT

1. To attach the **VTech® Soothing Safari™** to the crib, unfasten the straps and attach the unit to the side of the crib.



2. To securely attach the straps to the crib, please make sure the straps are balanced when fastened to the side of the crib.



## IMPORTANT SAFETY NOTICE:

Please make sure the straps are out of reach from children.



# TO BEGIN PLAY

1. Slide the **PLAYTIME/OFF/SOOTHING MODE SELECTOR SWITCH** to the **PLAYTIME MODE**

(☀️) or **SOOTHING MODE** (🌙) position to turn the unit **ON**. You will hear a short tune. The **LIGHT-UP PAWS** will flash with the sound.

2. To adjust the volume, slide the **HIGH / LOW VOLUME CONTROL SWITCH** at the back of the unit to the

(🔊) position for **HIGH VOLUME** or the (🔇) position for **LOW VOLUME**.



3. Slide the **PLAYTIME/OFF/SOOTHING MODE SELECTOR SWITCH** to the **OFF** (●) position to turn the unit **OFF**.


**Note:** The **VTech® Soothing Safari™** learning toy will automatically turn off after **30 seconds** without input. The unit can be turned on again by pressing any button or activating the sound sensor.

## ACTIVITIES

### PLAYTIME MODE

1. Turn on the unit by sliding the **PLAYTIME/SOOTHING/OFF MODE SELECTOR SWITCH** to the **PLAYTIME MODE** position (☀️). You will hear a short tune. The **LIGHT-UP PAWS** will flash with the sound.

2. Wave your hand in front of the bear's head to activate the **PROXIMITY SENSOR**. You will hear a giggle sound effect, elephant sound effect, or purr sound effect. The animal's light will flash accordingly with the sound.




3. Spin the **ROLLER BALL** to the left. You will hear "B, play with me!" and funny ball sound effect. The **LIGHT-UP PAWS** will flash with the sound.




4. Spin the **ROLLER BALL** to the left continuously. You will hear a melody play note by note. You can control the speed of the melody by the speed you spin the ball. The left **LIGHT-UP PAW** will flash with the sound.

5. Spin the **ROLLER BALL** to the right. You will hear a giggle sound effect. The **LIGHT-UP PAWS** will flash with the sound.




6. Spin the **ROLLER BALL** to the right continuously. You will hear a melody play note by note. You can control the speed of the melody by the speed you spin the ball. The right **LIGHT-UP PAW** will flash with the sound.

7. Press the **A BUTTON** or the **C BUTTON**. You will hear the letter identified or a giggle sound effect. The **LIGHT-UP PAWS** will flash with the sound.




8. Pull down on the **ELEPHANT TRUNK**. You will hear "Where's baby?" and "Peek-a-boo!" and an elephant sound effect. The elephant's ears will move open and close. The **LIGHT-UP BIRD** will flash with the sound.



9. Pull down on the **ELEPHANT TRUNK** a second time. You will hear a melody play. All of the lights will flash the sound. Pull down on the **ELEPHANT TRUNK** while a melody is playing to hear the elephant sound effect play over the melody.




10. Spin the **TIGER SPINNER**. You will hear purr sound effect and "Count with me!" and "123!" The butterfly's wings will flap once. The **LIGHT-UP TIGER NOSE** will flash with the sound.




11. Spin the **TIGER SPINNER** a second time. You will hear a melody play. All of the lights will flash with the sound. Spin the **TIGER SPINNER** while a melody is playing to hear the purr sound effect play over the melody.
12. The **VTech Soothing Safari™** will automatically shut-off after several seconds without input. The unit can be re-activated by the sound sensor. When any background noise is detected, you will hear “Where’s baby?”, an elephant sound effect, a purr sound effect, or a giggle sound effect.

## SOOTHING MODE

1. Turn on the unit by sliding the **PLAYTIME/SOOTHING/OFF MODE SELECTOR SWITCH** to the **SOOTHING MODE** (☾). You will hear a short tune, “Night-night!” “Sleep tight!”, and “Be beary quiet!”. The lights will flash with the sound.
2. Wave your hand in front of the bear’s head to activate the **PROXIMITY SENSOR**. You will hear a soothing sound effect, an elephant sound effect, a purr sound effect or a giggle sound effect. The animal’s light will flash accordingly with the sound.
3. Spin the **ROLLER BALL** to the left or right. You will hear a funny ball sound effect or a giggle sound effect. The lights will flash with the sound.



4. Press the **A BUTTON** or **C BUTTON**, pull down on the **ELEPHANT TRUNK**, or spin the **TIGER SPINNER**. You will hear a melody. The lights will flash with the sound.



5. The **VTech Soothing Safari™** will automatically shut-off after several seconds without input. The unit can be re-activated by the sound sensor. When any background noise is detected, you will hear a phrase or sound effect followed by a random melody. The melodies will play for approximately 5 minutes.

## Playtime Mode Melodies

- Rock-A-Bye Baby
- Three Little Kittens
- Sing a Song of Sixpence
- Pop Goes the Weasel

## Soothing Mode Melodies

- Lullaby
- Air for the G String
- Ode to Joy
- Scene

## CARE AND MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit away from direct sunlight and heat source.

3. Remove the batteries when the unit is not in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

### **IMPORTANT NOTE**

Creating and developing infant/toddler products is accompanied by a responsibility that we at **VTech**<sup>®</sup> take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-800-267-7377 in Canada with any problems and/or suggestions that you might have. Our service representative will be happy to help you.

### **NOTE:**

This equipment generates and uses radio frequency energy and if not installed and used properly, that is, in strict accordance with the manufacturer's instructions, it may cause interference to radio and television reception. It has been type tested and found to comply within the limits for a Class B computing device in accordance with the specifications in Sub-part J of Part 15 FCC Rules, which are designed to provide reasonable protection against such interference in a residential installation. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause interference with radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measure:

- reorient the receiving antenna
- relocate this product with respect to the receiver
- move this product away from the receiver