

Dear Parent:

At VTech® we know that a child has the ability to do great things.


That's why all of our electronic learning products are uniquely designed to develop a child's mind and allow them to learn to the best of their ability. Whether it's introducing numbers and letters, identifying colors and shapes, or stimulating senses with lights and music, all VTech® infant and toddler learning products encourage your child's natural growth and discovery skills.

When it comes to providing electronic learning products that enlighten, entertain and develop minds, at VTech® we see the potential in every child.

INTRODUCTION

Thank you for purchasing **VTech® Giggle Lion™** learning toy! This product is one of a family of high quality electronic learning toys. We at **VTech®** are committed to providing the best possible products to entertain and educate your child. Should you have any questions or concerns, please call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-800-267-7377 in Canada.

The **VTech® Giggle Lion™** is a talking, interactive, friendly lion designed for infants 3 months and up. The **VTech® Giggle Lion™** incorporates light, sound, and music to stimulate baby's senses. Sliding beads, a peek-a-boo window, and multiple tactile features will keep baby's little hands busy, helping to develop fine motor skills. The **VTech® Giggle Lion™** will become baby's favorite take along toy.




INCLUDED IN THIS PACKAG

1. One **VTech® Giggle Lion™** learning toy
2. One instruction manual

WARNING: All packing materials, such as tape, plastic sheets, wire ties and tags are not part of this toy, and should be discarded for your child's safety.

BATTERY INSTALLATION

1. Make sure the unit is turned **OFF**.
2. Locate the battery cover on the bottom of the unit. Use a screwdriver to loosen the screw.
3. Install 3 Button Cells batteries following the diagram inside the battery box.
4. Replace the battery cover and tighten the screw to secure the battery cover.



BATTERY NOTICE

- Install batteries correctly observing the polarity (+, -) signs to avoid leakage.
- Do not mix old and new batteries.
- Do not use batteries of different types.
- Remove batteries from the equipment when the unit will not be used for an extended period of time.
- Do not dispose of batteries in fire.
- Do not attempt to recharge ordinary batteries.
- The supply terminals are not to be short-circuited.
- Only batteries of the same and equivalent type as recommended are to be used.

WE DO NOT RECOMMEND THE USE OF RECHARGEABLE BATTERIES.


NOTE: If for any reason the program/activity stops working, please follow these steps:

1. Turn the unit **OFF**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit **ON**. The unit should now be ready to play again.

If the problem persists, please call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-800-267-7377 in Canada, and a service representative will be happy to help you.

TO BEGIN PLAY

1. Slide the **OFF/LOW/HIGH SWITCH** to the **LOW** () or the **HIGH** () position to turn the unit **ON**. You will hear a short tune and a lion roar sound effect. The light-up nose will flash with the music.



2. To adjust the volume, slide the **OFF/LOW/HIGH SWITCH** to the () position for **LOW VOLUME** or the () position for **HIGH VOLUME**.




3. Slide the **OFF/LOW/HIGH SWITCH** to the **OFF** () position to turn the unit **OFF**.




Note: The **VTech® Giggle Lion™** will automatically turn off after several minutes without input. The unit can be turned on again by shaking the unit, pressing the button, or sliding the peek-a-boo window.

ACTIVITIES

1. Press the **ABC BUTTON** to hear talking phrases and sounds. Press the **ABC BUTTON** for the first time to hear "I love kisses!" and a kiss sound. Press the **ABC BUTTON** a second time to hear "Got your nose!" and giggle sound. The light-up nose will flash with the phrases and sounds.




2. Slide the **PEEK-A-BOO WINDOW** to the tickling monkey to hear "That tickles!" and a melody. Slide the **PEEK-A-BOO WINDOW** to the giggling monkey to hear a giggle sound and a melody. The light-up nose will flash with the sound.




3. Squeeze the **RED PETAL** to hear a crinkle sound. The light-up nose will flash.



4. Shake or wiggle the unit to hear one of the four melodies.



5. While a melody is playing, shake or wiggle the unit to hear a lion roar sound effect or a giggle sound play over the melody.



MELODIES:

- Blue Danube Waltz
- Eine Kleine Nachtmusik
- Happy Farmer/Merry Peasant
- Nutcracker Suite

CARE AND MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit away from direct sunlight and heat source.
3. Remove the batteries when the unit is not in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

IMPORTANT NOTE

Creating and developing infant/toddler products is accompanied by a responsibility that we at **VTech®** take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-800-267-7377 in Canada with any problems and/or suggestions that you might have. Our service representative will be happy to help you.

NOTE:

This equipment generates and uses radio frequency energy and if not installed and used properly, that is, in strict accordance with the manufacturer's instructions, it may cause interference to radio and television reception. It has been type tested and found to comply within the limits for a Class B computing device in accordance with the specifications in Sub-part J of Part 15 FCC Rules, which are designed to provide reasonable protection against such interference in a residential installation. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause interference with radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measure:

- reorient the receiving antenna
- relocate this product with respect to the receiver
- move this product away from the receiver