

vtech[®]

User's Manual

Step & Count Kangaroo™



© 2009 VTech
Printed in China
91-002390-005-000 (美)

Dear Parent,

*Ever notice the look on your baby's face when they learn something new through their own discovery? These self-accomplished moments are a parent's greatest reward. To help fulfill them, VTech® created the **Jungle Gym®** series of toys.*

*These unique interactive learning toys directly respond to what children do naturally – play! Using innovative technology, these toys react to baby's interactions, making each play experience fun and unique as they learn age-appropriate concepts like first words, numbers, shapes, colors and music. More importantly, VTech®'s **Jungle Gym®** toys develop baby's mental and physical abilities by inspiring, engaging and teaching.*

At VTech®, we know that a child has the ability to do great things. That's why all of our electronic learning products are uniquely designed to develop a child's mind and allow them to learn to the best of their ability. We thank you for trusting VTech® with the important job of helping your child learn and grow!

Sincerely,

Your friends at VTech®

*To learn more about the **Jungle Gym®** series and other VTech® toys, visit www.vtechkids.com*

INTRODUCTION


Thank you for purchasing the **VTech® Jungle Gym™ Step & Count Kangaroo™**.

The **VTech® Jungle Gym™ Step & Count Kangaroo™** is a fun and interactive learning toy that gets toddlers moving and learning. Step on the platform to hear fun sounds while the kangaroo counts the steps. Three playful songs, a variety of encouraging phrases and fun sounds keep toddlers interested and engaged.



INCLUDED IN THIS PACKAGE


One VTech® Jungle Gym™ Step & Count Kangaroo™




One electronic hat



One body



One stepping platform



Two ring locks


One instruction manual

WARNING: All packing materials, such as tape, plastic sheets, wire ties and tags are not part of this toy, and should be discarded for your child's safety. Please only assemble this product by an adult.

GETTING STARTED

BATTERY INSTALLATION

1. Make sure the unit is turned **OFF**.
2. Locate the battery cover on the back of the electronic head. Use a coin or a screwdriver to loosen the screw.
3. Install 4 new 'AA' batteries following the diagram inside the battery box. (The use of new alkaline batteries is recommended for maximum performance.)
4. Replace the battery cover and tighten the screw to secure.



BATTERY NOTICE

- Install batteries correctly observing the polarity (+, -) signs to avoid leakage.
- Do not mix old and new batteries.
- Do not mix batteries of different types: alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium).
- Remove the batteries from the equipment when the unit will not be used for an extended period of time
- Always remove exhausted batteries from the equipment.
- Do not dispose of batteries in fire.
- Do not attempt to recharge ordinary batteries.
- The supply terminals are not to be short-circuited.
- Only batteries of the same and equivalent type as recommended are to be used.

WE DO NOT RECOMMEND THE USE OF RECHARGEABLE BATTERIES.

ASSEMBLY INSTRUCTIONS

With the VTech® Jungle Gym™ Step & Count Kangaroo™, safety comes first. To ensure your child's safety, please only assemble this product by an adult.


1. Insert the kangaroo body into to the stepping platform.




2. Turn the unit over and attach the ring locks to the bottom of the stepping platform.




3. Turn the ring locks to lock the unit in place.



4. To remove the ring locks for disassembly, pull the tab on the bottom of the unit to release the ring locks. Turn the ring locks counter-clockwise to unlock, then pull off the ring locks.



5. Attach the electronic hat to the head by snapping the hat onto the head. Please ensure the hat is attached securely to the head. Once the hat has been attached, it cannot be removed.




ATTENTION: The maximum weight limit for this product is 42 pounds. It is not recommended for children older than 36 months.

PRODUCT FEATURES

1. MODE SELECTOR SWITCH

To turn the unit **ON**, slide the **MODE SELECTOR SWITCH** to the **LEARNING MODE** (📖123) position or **MUSIC MODE** (🎵) position. To turn the unit **OFF**, slide the **MODE SELECTOR SWITCH** to the **OFF** (🔌) position.




2. AUTOMATIC SHUT-OFF


To preserve battery life, the **VTech® Jungle Gym™ Step & Count Kangaroo™** will automatically power-down after several seconds without input. The unit can be turned on again by pressing any button or stepping on the platform.

ACTIVITIES


1. Slide the **mode selector switch** to turn the unit on. You will hear a song, playful phrase and a short tune. The balls will spin and the screen will flash with the sounds.




2. Press the **music button**, **number button**, **flag button** and **sound effect button** to hear upbeat melodies, numbers, encouraging phrases and fun songs. The balls will spin and the screen will flash with the sounds.



3. Step on the **stepping platform** to hear fun sounds, counting from 1 to 30 and encouraging phrases in the learning mode. In the music mode, you will hear variety of fun sounds and encouraging phrases. The balls will spin and the screen will flash with the sounds.



4. Press the **baby kangaroo** to hear fun sounds and encouraging phrases. Watch the baby bounce up and down!



MELODY LIST

1. Pop! Goes the Weasel
2. Skip to My Lou
3. Yankee Doodle
4. Ring Around the Rosy
5. Peter, Peter, Pumpkin Eater
6. Happy Farmer
7. This Old Man
8. Alphabet Song

SONG LYRICS

SONG 1

Get up on your feet,
Move them to the beat.
You are number one,
You are number one!

SONG 2

You like to move your body,
You can walk, run and count along.

SONG 3 (to the tune of "This Old Man")

1-2-3, 4-5-6, 7-8-9 and 10.
You can count along,
Move your feet you'll see.
Move your body now for me.

CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat source.
3. Remove the batteries when the unit will not be in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

TROUBLESHOOTING

If for some reason the program/activity stops working or malfunctions, please follow these steps:

1. Please turn the unit **OFF**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit sit for a few minutes, then replace the batteries.
4. Turn the unit **ON**. The unit should now be ready to play again.
5. If the product still does not work, replace with a new set of batteries.

If the problem persists, please call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada, and a service representative will be happy to help you.

For information on this product's warranty, please call **VTech®** at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada.

IMPORTANT NOTE:

Creating and developing **Active Play** products is accompanied by a responsibility that we at **VTech®** take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department at 1-800-521-2010 in the U.S., or 1-877-352-8697 in Canada, with any problems and/or suggestions that you might have. A service representative will be happy to help you.

Note:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.