



Smart Start[®]
Baby Drake[™]

USER'S MANUAL



Dear Parent:

At VTECH® we know that a child has the ability to do great things.

That's why all of our electronic learning products are uniquely designed

to develop a child's mind and allow them to learn to the best of their

ability. Whether it's introducing numbers and letters, identifying colors

and shapes, or stimulating senses with lights and music, all VTECH®

infant and toddler learning products encourage your child's natural

growth and discovery skills. When it comes to providing electronic


learning products that enlighten, entertain and develop minds, at

VTECH® we see the potential in every child.

INTRODUCTION

Thank you for purchasing the **Baby Drake™** learning toy! We at **VTECH®** are committed to providing the best possible products to entertain and educate your child. Should you have any questions or concerns, please call our Consumer Services Department at 1-800-521-2010 in the U.S., 1-800-267-7377 in Canada, or 01235-546810 in the U.K.

The **Baby Drake™** learning toy combines sound with visual and tactile stimulation to delight your child for hours. With an easy to grasp body, your child can activate the curriculum of ABC's, numbers and shapes. The **Baby Drake™** learning toy is also equipped with a motion sensor. When your child touches Baby Drake's head, they will hear fun phrases and music. The **Baby Drake™** learning toy will not only provide your child with numerous learning activities, but also act as a companion throughout their early years of development.




INCLUDED IN THIS PACKAGE

- One VTECH® Baby Drake™ learning toy.
- One instruction manual.

WARNING: All packing materials, such as tape, plastic sheets, wire ties and tags are not part of this toy, and should be discarded for your child's safety.

BATTERY INSTALLATION

1. Make sure the unit is turned **OFF**.
2. Locate the battery cover on the bottom of the unit. Use a screwdriver to loosen the screw.
3. Install 2 new “AA” (UM-3/LR6) batteries following the diagram inside the battery box. (The use of new alkaline batteries is recommended for maximum performance.)
4. Replace the battery cover and tighten the screw to secure the battery cover.



BATTERY NOTICE

- Install batteries correctly observing the polarity (+, -) signs to avoid leakage.
- Do not mix old and new batteries.
- Do not use batteries of different types.
- Remove exhausted or new batteries from the equipment when the unit will not be used for an extended period of time.
- Do not dispose of batteries in fire.
- Do not attempt to recharge ordinary batteries.
- The supply terminals are not to be short-circuited.

WE DO NOT RECOMMEND THE USE OF RECHARGEABLE BATTERIES.


NOTE: If for some reason the program/activity stops working, please follow these steps:

1. Please turn the unit **OFF**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit **ON**. The unit should now be ready to play again.

If the problem persists, please call our Consumer Services Department at 1-800-521-2010 in the U.S., 1-800-267-7377 in Canada, or 01235-546810 in the U.K. A service representative will be happy to help you.

TO BEGIN PLAY

1. Press the **ON/OFF BUTTON** on the tail once to turn the unit **ON**. You will hear a dragon sound effect, “I’m Drake the dragon”, a giggle sound effect, and “It’s play time!”. The light will flash with the sound.



2. Press the **ON/OFF BUTTON** again to turn the unit **OFF**. You will hear “It’s sleepy time”, a dragon sound effect, and a short tune. The light will flash with the sound.



AUTOMATIC SHUT-OFF


To preserve battery life, the **VTECH® Baby Drake™** learning toy will automatically turn off after several minutes without input. The unit can be turned on again by pressing any button.

ACTIVITIES

1. Squeeze the **NUMBER** body once to hear “One”, a cute sound effect, and a melody. The light will flash with the sound.

Squeeze the **NUMBER** body a second time to hear “Two”, a cute sound effect, and a melody. The sound effect will play along with the melody. The light will flash with the sound.


Squeeze the **NUMBER** body a third time to hear “Three”, a cute sound effect, and a melody. The light will flash with the sound.



2. Squeeze the **LETTER** body once to hear “A”, a cute sound effect, and a melody. The sound effect will play along with the melody. The light will flash with the sound.

Squeeze the **LETTER** body a second time to hear “B”, a cute sound effect, and a melody. The light will flash with the sound.


Squeeze the **LETTER** body a third time to hear “C”, a cute sound effect, and a melody. The sound effect will play along with the melody. The lights will flash with the sound.



3. Squeeze the **SHAPE** body once to hear “Triangle”, a boing sound effect, and a melody. The sound effect will play along with the melody. The light will flash with the sound.

Squeeze the **SHAPE** body a second time to hear “Square”, a boing sound effect, and a melody. The light will flash with the sound.

Squeeze the **SHAPE** body a third time to hear “Circle”, a boing sound effect, and a melody. The sound effect will play along with the melody. The light will flash with the sound.



4. Touch Baby Drake's head to hear “1,2,3 playtime!”, a cute sound effect, a dragon sound effect, or a random classical melody. The light will flash with the sound.



MELODIES:

- Rock-A-Bye Baby
- Brahms Lullaby
- Minuet in G
- Seasons
- Can-Can
- Three Little Kittens
- Ring Around the Rosie
- Cannon in D
- Nutcracker Suite

CARE AND MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat source.
3. Remove the batteries when the unit is not in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

IMPORTANT NOTE:

Creating and developing baby products is accompanied by a responsibility that we at **VTECH®** take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department at 1-800-521-2010 in the U.S., 1-800-267-7377 in Canada, or 01235-546810 in the U.K., with any problems and/or suggestions that you might have. A service representative will be happy to help you.

Note:

This equipment generates and uses radio frequency energy and if not installed and used properly, that is, in strict accordance with the manufacturer's instructions, it may cause interference to radio and television reception. It has been type tested and found to comply within the limits for a Class B computing device in accordance with the specifications in Sub-part J of Part 15 FCC Rules, which are designed to provide reasonable protection against such interference in a residential installation. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause interference with radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Re-orient the receiving antenna
- Relocate this product with respect to the receiver
- Move this product away from the receiver