


# Bop & Learn Guitar™

## User's Manual

### BATTERY INSTALLATION

1. Make sure the unit is turned OFF.
2. Locate the battery cover on the back of the unit. Use a coin or a screwdriver to loosen the screw.
3. Install 2 new 'AAA' (UM4/LR03) batteries following the diagram inside the battery box.
4. Replace the battery cover and tighten the screw to secure.



### BATTERY NOTICE

- Install batteries correctly observing the polarity (+, -) signs to avoid leakage.
- Do not mix old and new batteries.
- Do not mix batteries of different types: alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium).
- Remove the batteries from the equipment when the unit will not be used for an extended period of time.
- Always remove exhausted batteries from the equipment.
- Do not dispose of batteries in fire.
- Do not attempt to recharge ordinary batteries.
- The supply terminals are not to be short-circuited.
- Only batteries of the same and equivalent type as recommended are to be used.

**WE DO NOT RECOMMEND THE USE OF RECHARGEABLE BATTERIES.**


### INCLUDED IN THIS PACKAGE

- One VTech® Bop & Learn Guitar™
- One instruction manual

## PRODUCT FEATURES

### 1. ON/OFF SWITCH

To turn the unit **ON**, slide the **ON/OFF SWITCH** to the **ON** (●) position. To turn the unit **OFF**, slide the **ON/OFF SWITCH** to the **OFF** (●) position.




### 2. AUTOMATIC SHUT-OFF

To preserve the battery life, the **VTech® Bop & Learn Guitar™** will automatically power-down after approximately 30 seconds without input. The unit can be turned on again by pressing any button.

## ACTIVITIES

1. Slide the **on/off switch** to turn the unit on. You will hear a guitar sound, a song and a short phrase. The light will flash with the sound.



2. Press the **number buttons** to hear numbers, colors and insect names identified, as well as short tunes, sounds and melodies. The light will flash with the sound.



3. Move the **slider** to hear a variety of phrases, sounds, melodies and songs. The light will flash with the sound.



# MELODY LIST

1. Sing a Song of Sixpence
2. This Old Man
3. Hickory Dickory Dock
4. Shoo! Fly, Don't Bother Me
5. Happy Farmer
6. If You're Happy and You Know It

# SONG LYRICS

## Song 1 (To the tune of "Twinkle, Twinkle, Little Star")

Strum the guitar and learn with me,  
And we can count 1, 2, 3!

## Song 2 (To the tune of "Skip to My Lou")

So much here to learn and see,  
Why don't you come and play with me?

## Song 3 (To the tune of "Alouette")

Caterpillar come and learn with me.  
Spin me shake me, we'll have fun you'll see!

# CARE AND MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat source.
3. Remove the batteries when the unit is not in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

# TROUBLESHOOTING

If for some reason the program/activity stops working or malfunctions, please follow these steps:

1. Please turn the unit **OFF**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit **ON**. The unit should now be ready to play again.
5. If the product still does not work, replace with a new set of batteries.

If the problem persists, please call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada, and a service representative will be happy to help you.

For information on this product's warranty, please call **VTech®** at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada

## Note:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This Class B digital apparatus complies with Canadian ices-003.

Cet appareil numérique de la classe b est conforme à la norme nmb-003 du Canada.

Caution: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.