

vtech[®]

User's Manual

Sing & Squeak Bath Book™



© 2013 VTech
Printed in China
91-002828-000 

Dear Parent,

*Ever notice the look on your baby's face when they learn something new through their own discovery? These self-accomplished moments are a parent's greatest reward. To help fulfill them, VTech® created the **Infant Learning**® series of toys.*

*These unique interactive learning toys directly respond to what children do naturally – play! Using innovative technology, these toys react to baby's interactions, making each play experience fun and unique as they learn age-appropriate concepts like first words, numbers, shapes, colors and music. More importantly, VTech®'s **Infant Learning**® toys develop baby's mental and physical abilities by inspiring, engaging and teaching.*

At VTech®, we know that a child has the ability to do great things. That's why all of our electronic learning products are uniquely designed to develop a child's mind and allow them to learn to the best of their ability. We thank you for trusting VTech® with the important job of helping your child learn and grow!

Sincerely,

Your friends at VTech®

*To learn more about the **Infant Learning**® series and other VTech® toys, visit www.vtechkids.com*

INTRODUCTION

Thank you for purchasing the **VTech® Sing & Squeak Bath Book™** learning toy!

Bath time can also be reading time with the **Sing & Squeak Bath Book™**. This soft waterproof book actually floats in the tub! It plays three fun sing-along songs that teach baby first words, counting and body parts. There is a light-up button on the spine of the book that blinks to the melody of the sing-along songs.



INCLUDED IN THIS PACKAGE

- One detachable brush



- One Sing & Squeak Bath Book™



- One user's manual

WARNING:

All packing materials, such as tape, plastic sheets, packaging locks and tags are not part of this toy, and should be discarded for your child's safety.

ATTENTION:

Pour la sécurité de votre enfant, débarrassez-vous de tous les produits d'emballage tels que rubans adhésifs, feuilles de plastique, attaches et étiquettes. Ils ne font pas partie du jouet.


NOTE:

Please keep this instruction manual as it contains important information.

GETTING STARTED

BATTERY INSTALLATION

1. Make sure the unit is turned **OFF** and the battery cover, battery box and unit are all dry.
2. Locate the battery cover on the back of the unit. Use a screwdriver to loosen the two screws.



3. Install 2 new 'AAA' (AM-4/LR03) batteries following the diagram inside the battery box. (The use of new alkaline batteries is recommended for maximum performance.)
4. When closing the battery cover ensure that the two screws are tightened securely. This will avoid any water leakage.

BATTERY NOTICE

- Use new alkaline batteries for maximum performance.
- Use only batteries of the same or equivalent type as recommended.
- Do not mix different types of batteries: alkaline, standard (carbon-zinc) or rechargeable (Ni-Cd, Ni-MH), or new and used batteries.
- Do not use damaged batteries.
- Insert batteries with the correct polarity.
- Do not short-circuit the battery terminals.
- Remove exhausted batteries from the toy.
- Remove batteries during long periods of non-use.
- Do not dispose of batteries in fire.
- Do not charge non-rechargeable batteries.
- Remove rechargeable batteries from the toy before charging (if removable).
- Rechargeable batteries are only to be charged under adult supervision.

PRODUCT FEATURES

1. ON/OFF BUTTON

To turn the unit **ON**, press the **ON/OFF BUTTON**. To turn the unit **OFF**, press the **ON/OFF BUTTON** a second time.



2. VOLUME BUTTON


When the unit is first turned on the volume is set to the high volume position. To adjust the volume, press the **VOLUME BUTTON** once to decrease the volume. Press the **VOLUME BUTTON** as second time to increase the volume.



Please Note: For optimal sound quality we recommend holding the book upright while pressing the buttons rather than pressing the buttons while the book is floating on the water. When the speaker fills up with water the volume of the product will decrease. To correct the problem remove the book from the water and allow the water to drain away from the speaker.

3. DETACHABLE BRUSH

Snap the **DETACHABLE BRUSH** on to the ring on the spine of the book. For your child's safety, adult assembly is recommended.



4. AUTOMATIC SHUT-OFF

To preserve battery life, the **VTech® Sing & Squeak Bath Book™** will automatically power-down after approximately 60 seconds without input. The unit can be turned on again by pressing any button. Pressing the volume button will not turn the unit back on.


WARNING:

- **Batteries must be changed by an adult.**
- **Only use this product in water between 10 and 45 degrees celsius, 50 and 104 degrees Fahrenheit.**


- This product cannot be used in salt water.
- Do not leave this product submerged in water for a long period of time.
- This product should only be operated in water when fully assembled in accordance with the instructions.
- To prevent drowning, never leave a child unattended in the bath.
- Use a thermometer to check the temperature of the water before sitting a child in the bath. Toddlers have very sensitive skin and can burn easily if the water is too hot.
- When finished playing, remove the unit from the water and pour out any remaining water. Rinse the unit with clean water and wipe with a dry cloth. Suspend the unit in an upright position to dry.

ACTIVITIES

1. Press the **on/off button** to turn the unit on. You will hear a playful sing-along song, fun sounds and a phrase. The light will flash with the sound.
2. Press the **bubble button** to hear a playful sing-along song, fun sounds and a phrase. The light will flash with the sound.



3. Press the **duck button** to hear a playful sing-along song about body parts, fun sounds and a phrase. The light will flash with the sound.
4. Press the **music button** to hear ten different melodies. When a melody is playing, press the bubble or duck button to hear the animal sound sing along with the melody. The light will flash with the sound.



MELODY LIST

1. Row, Row, Row Your Boat
2. Animal Fair
3. Rub-a-dub-dub
4. My Bonnie
5. London Bridge
6. Sailing, Sailing
7. Sailor's Hornpipe
8. Au Claire de la Lune
9. One, Two, Buckle My Shoe
10. Pop! Goes the Weasel

SONG LYRICS

SONG 1

Bath time, bath time,
I need to get in the tub.
I can scrub and I can play.
Rubber ducky's waiting for me, hooray!

SONG 2

Bubbles, bubbles, everywhere,
Lots of bubbles fill the air.
One, two, three, four, five,
Bubbles float in the sky!

SONG 3

Splish, splash, I love the bath!
I wash my face and I clean my tummy.
I splash with my hands and play with my duck.
Bath time is lots of fun!

CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat source.
3. Make sure to empty the water out of all the elements of the unit and rinse thoroughly before drying so no sediment or cleaning products are left on the unit.
4. Make sure to dry all the elements of the unit before storing.
5. Remove the batteries when the unit is not in use for an extended period of time.
6. Do not drop the unit on hard surfaces.

TROUBLESHOOTING

If for some reason the program/activity stops working or malfunctions, please follow these steps:

1. Please turn the unit **OFF**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit **ON**. The unit should now be ready to play again.
5. If the product still does not work, replace with a new set of batteries.

If the problem persists, please call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada, and a service representative will be happy to help you.

For information on this product's warranty, please call **VTech**® 1-800-521-2010 in the U.S., or 1-877-352-8697 in Canada.

IMPORTANT NOTE:

Creating and developing **Infant Learning** products is accompanied by a responsibility that we at **VTech**® take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada, with any problems and/or suggestions that you might have. A service representative will be happy to help you.

Note:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no

guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS:
(1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND
(2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION.

THIS CLASS B DIGITAL APPARATUS COMPLIES WITH CANADIAN ICES-003.

CET APPAREIL NUMÉRIQUE DE LA CLASSE B EST CONFORME À LA NORME NMB-003 DU CANADA.

CLASS 1
LED PRODUCT