

vtech®

Parent's Guide



Touch & Learn
Activity Desk™ Deluxe
Expansion Pack

Preschool Super Skills



91-003224-011 US

INTRODUCTION

Thank you for purchasing the **Touch & Learn Activity Desk™ Deluxe Preschool Super Skills Expansion Pack**. This pack contains eight pages of learning content. Interact with the pages to explore popular preschool themes such as learning about feelings and emotions, the five senses, the planets, things that go, world music, rhythm, letters, letter sounds and counting.

INCLUDED IN THIS PACKAGE

- One **Preschool Super Skills** cartridge
- Four double-sided activity cards
- One parent's guide

WARNING:

All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties and packaging screws are not part of this toy and should be discarded for your child's safety.

ATTENTION:

Pour la sécurité de votre enfant, débarrassez-vous de tous les produits d'emballage tels que rubans adhésifs, feuilles de plastique, attaches, étiquettes et vis d'emballage. Ils ne font pas partie du jouet.

NOTE: Please keep this parent's guide as it contains important information.

GETTING STARTED

Step 1: Insert the Expansion Pack Cartridge

Make sure the unit is turned **OFF**. Insert the **Preschool Super Skills** cartridge into the **Cartridge Slot** located on the right side of the desk and push until it clicks into place as shown in the image below.



Step 2: Insert an Activity Card

Turn on the unit and insert any one of the activity cards from the **Preschool Super Skills** expansion pack by sliding the black tab into the **Activity Card Slot** on the desk.



- Please insert only one activity card at a time. Inserting more than one activity card may damage the card or the desk and may also result in incorrect card detection.
- Do not try to insert anything other than the activity cards into the **Activity Card Slot**. To avoid any interference, please keep the slot area clean and free from debris.
- Please wipe away any dust or chalk residue from the activity cards before inserting into the **Activity Card Slot**.
- Keep the activity cards on a flat surface when not in use. Do not bend or fold the activity cards.


ACTIVITY PAGES

Refer to the table below for details on each of the activity pages.

| | |
|--|---|
| Vowels | |
|  |  Touch & Learn Touch the letters and the objects to learn about vowels and vowel sounds. |
| |  Searching Fun Listen to the clues and find the correct letters and objects on the page. |
| |  Let's Sing! Listen to a fun song about vowels and then find the correct vowels on the page. |
| | Teaches: Letters, Letter Sounds, Vocabulary |
| Cosmic Adventure | |
|  |  Touch & Learn Touch the objects on the page to learn more about planets in our solar system. |
| |  Let's Pretend! Follow clues from your co-pilot and guide the spaceship around meteor showers as you venture through space looking for planets. |
| |  Alien Rescue Mission An alien is lost and needs your help! Use the translator to listen to the alien's clues so that you can help find him and lead him home. |
| | Teaches: Planets, Directions, Vocabulary |
| Counting Garden | |
|  |  Touch & Learn Touch the pictures to learn about fruits, vegetables, and counting to 10. |
| |  Searching Fun Listen to the clues and find the correct objects or numbers on the page. |
| |  Find the Animals Listen to the clues to find and count all of the animals. |
| | Teaches: Numbers, Counting, Vocabulary |



Things That Go



Touch & Learn

Touch the pictures to learn about which types of transportation travel by air, land and water.



Discover More

Learn fun facts about different types of things that go.



Travel Challenge

Listen to the travelers' clues to help them figure out what types of transportation they need.

Teaches: Vocabulary, Transportation by Land, Air and Water

The Five Senses



Touch & Learn

Touch the objects on the page to learn about the five senses.



Searching Fun

Listen to the clues and find the right objects or parts of the body that match the senses.



Let's Sing!

Listen to a fun song about the senses and match the senses you hear about to the correct part of the body.

Teaches: The Five Senses, Vocabulary

Feelings and Emotions



Touch & Learn

Touch the pictures to explore different feelings and emotions.



Searching Fun

Listen to the clues and find the kids in the classroom that match the description.









Let's Sing!

Listen to a fun song about feelings. Find the matching emotion on the page when the song stops and provides some clues.

Teaches: Feelings, Emotions, Vocabulary



| Drum Studio | |
|---|--|
|  |  <p>Drum Jammer Play the drums while you jam to a beat!</p> |
| |  <p>Touch & Learn Touch the drums to learn about their names and sounds. Touch the music posters to hear different music styles.</p> |
| |  <p>Follow the Beat Listen to the rhythm and repeat the beat by tapping the drums in the correct order.</p> |
| | <p>Teaches: Drum Names and Sounds, Numbers, Rhythm, Vocabulary</p> |
| World Music Festival | |
|  |  <p>Touch & Learn Touch the different instruments from around the world to hear how they sound.</p> |
| |  <p>Discover More Listen to fun facts about different instruments from around the world.</p> |
| |  <p>World Music Festival Tap different bands from around the world to hear examples of their music styles.</p> |
| <p>Teaches: World Music, Vocabulary</p> | |

CARE & MAINTENANCE

1. Please store and use in dry areas.
2. Keep the cartridge and activity cards clean by wiping them with a slightly damp cloth.
3. Keep the cartridge and activity cards out of direct sunlight and away from any direct heat sources.
4. Do not drop the cartridge on a hard surface and do not expose the cartridge or activity cards to excess moisture or water.
5. Keep the activity cards on a flat surface when not in use. Do not bend or fold the activity cards.

TECHNICAL SUPPORT

If you have a problem that cannot be solved by using this manual, we encourage you to visit us online or contact our Consumer Services Department with any problems and/or suggestions that you might have. A support representative will be happy to assist you.

Before requesting support, please be ready to provide or include the information below:

- The name of your product or model number (the model number is typically located on the back or bottom of your product).
- The actual problem you are experiencing.
- The actions you took right before the problem started.

Internet: Visit our website at vtechkids.com and fill out the Contact Us form located under the Customer Support link.

Phone: 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION.

CAN ICES-3 (B)/NMB-3(B)



PRODUCT WARRANTY

This Warranty is applicable only to the original purchaser, is non-transferable and applies only to "VTech" products or parts. This product is covered by a 3-month Warranty from the original purchase date, under normal use and service, against defective workmanship and materials.

This Warranty does not apply to (a) consumable parts, such as batteries; (b) cosmetic damage, including but not limited to scratches and dents; (c) damage caused by use with non-VTech products; (d) damage caused by accident, misuse, unreasonable use, immersion in water, neglect, abuse, battery leakage, or improper installation, improper service, or other external causes; (e) damage caused by operating the product outside the permitted or intended uses described by VTech in the owner's manual; (f) a product or part that has been modified (g) defects caused by normal wear and tear or otherwise due to the normal aging of the product; or (h) if any VTech serial number has been removed or defaced.

Prior to returning a product for any reason, please notify the VTech Consumer Services Department, by going to our web website vtechkids.com, filling out our Contact Us form located under the Customer Support link or calling

1-800-521-2010.

If the service representative is unable to resolve the issue, you will be provided instructions on how to return the product and have it replaced under Warranty. Return of the product under Warranty must adhere to the following rules: If VTech believes that there may be a defect in the materials or workmanship of the product and can confirm the purchase date and location of the product, we will at our discretion replace the product with a new unit or product of comparable value. A replacement product or parts assumes the remaining Warranty of the original product or 30 days from the date of replacement, whichever provides longer coverage.

THIS WARRANTY AND THE REMEDIES SET FORTH ABOVE ARE EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES, REMEDIES AND CONDITIONS, WHETHER ORAL, WRITTEN, STATUTORY, EXPRESS OR IMPLIED. IF VTECH CANNOT LAWFULLY DISCLAIM STATUTORY OR IMPLIED WARRANTIES THEN TO THE EXTENT PERMITTED BY LAW, ALL SUCH WARRANTIES SHALL BE LIMITED TO THE DURATION OF THE EXPRESS WARRANTY AND TO THE REPLACEMENT SERVICE AS DETERMINED BY VTECH IN ITS SOLE DISCRETION.

To the extent permitted by law, VTech will not be responsible for direct, special, incidental or consequential damages resulting from any breach of Warranty.

This Warranty is not intended to persons or entities outside the United States of America. Any disputes resulting from this Warranty shall be subject to the final and conclusive determination of VTech.



**Visit our website for more
information about our products,
downloads, resources and more.**

vtechkids.com



TM & © 2017 VTech Holdings Limited.
All rights reserved.
Printed in China.
91-003224-011 