

vtech[®]

User's Manual

Learn and Discover Driver™



© 2004 VTech

Printed in China

91-02080-000 (美)

Dear Parent:

*Ever notice the look on your baby's face when they learn something new through their own discovery? These self-accomplished moments are a parent's greatest reward. To help fulfill them, VTech® created the **Smart Start**®, series of toys.*

*These unique interactive learning toys directly respond to what children do naturally – play! Using innovative technology, these toys react to baby's interactions, making each play experience fun and unique as they learn age-appropriate concepts like first words, numbers, shapes, colors and music. More importantly, VTech®'s **Smart Start**®, toys develop baby's mental and physical abilities by inspiring, engaging and teaching.*

At VTech®, we know that a child has the ability to do great things. That's why all of our electronic learning products are uniquely designed to develop a child's mind and allow them to learn to the best of their ability. We thank you for trusting VTech® with the important job of helping your child learn and grow!

Sincerely,


Your Friends at VTech®

*To learn more about **Smart Start**®, and other VTech® toys, visit www.vtech.com*

INTRODUCTION

Thank you for purchasing **VTech® Learn and Discover Driver™** learning toy!

The **VTech® Learn and Discover Driver™** is an interactive learning toy for toddlers 6 months and up. This product is packed with fun phrases, colorful lights, sound effects and learning that will keep toddlers entertained for hours. Spin the three rollers and watch the vehicles and animals change, the possibilities are endless.



INCLUDED IN THIS PACKAGE


- One VTech® Learn and Discover Driver™ learning toy
- One instruction manual

WARNING: All packing materials, such as tape, plastic sheets, wire ties and tags are not part of this toy, and should be discarded for your child's safety.

GETTING STARTED

BATTERY INSTALLATION

1. Make sure the unit is turned **OFF**.
2. Locate the battery cover on the bottom of the unit. Use a screwdriver to loosen the screw.
3. Install 2 new “AA” (UM-3/LR6) batteries following the diagram inside the battery box. (The use of new alkaline batteries is recommended for maximum performance.)
4. Replace the battery cover and tighten the screw to secure the battery cover.



BATTERY NOTICE

- Install batteries correctly observing the polarity (+, -) signs to avoid leakage.
- Do not mix old and new batteries.
- Do not use batteries of different types.
- Remove exhausted or new batteries from the equipment when the unit will not be used for an extended period of time.

- Do not dispose of batteries in fire.
- Do not attempt to recharge ordinary batteries.
- The supply terminals are not to be short-circuited.
- Only batteries of the same and equivalent type as recommended are to be used.

WE DO NOT RECOMMEND THE USE OF RECHARGEABLE BATTERIES.

PRODUCT FEATURES


1. ON/OFF SWITCH

To turn the unit **ON**, slide the **ON/OFF SWITCH** to the **ON** (☀) position. To turn the unit **OFF**, slide the **ON/OFF SWITCH** to the **OFF** (●) position.



2. VOLUME CONTROL

To adjust the volume, slide the **VOLUME CONTROL SWITCH** located on the bottom of the unit to the (☞) position for **LOW VOLUME** or the (☞) position for **HIGH VOLUME**.




3. AUTOMATIC SHUT-OFF


To preserve battery life, the **VTech® Learn and Discover Driver™** learning toy will automatically power-down after several minutes without input. The driver can be turned on again by pressing any button. Please note, spinning the rollers will not turn the unit back on.

ACTIVITIES


1. Spin the **rollers** to line up different vehicle and animal combinations. Depending on the picture combinations, you will hear letters, shapes, colors and animal names identified. When three of the same vehicles are lined up, you will hear a sung song as a reward. The lights will flash with all the sound responses.




2. Move the **steering wheel** continuously for a few seconds to activate the traffic lights and hear a fun driving related phrase. Honk the horn to hear a horn sound effect and fun phrase. The lights will flash with all the sound responses.



3. Slide the **gear shifter** up or down to hear cool sound effects and phrases. The lights will flash with all the sound responses.



4. Press the **gas station**, **radio** and **police car** buttons to hear fun phrases, sound effects or music. The lights will flash with all the sound responses.



CARE AND MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat source.
3. Remove the batteries when the unit is not in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

TROUBLESHOOTING

If for some reason the program/activity stops working, please follow these steps:

1. Please turn the unit **OFF**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit **ON**. The unit should now be ready to play again.

If the problem persists, please call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-800-267-7377 in Canada, and a service representative will be happy to help you.

For information on this product warranty, please call **VTech®** at 1-800-521-2010 in the U.S. or 1-800-267-7377 in Canada.

IMPORTANT NOTE:

Creating and developing **Smart Start**[®] products is accompanied by a responsibility that we at **VTech**[®] take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department at 1-800-521-2010 in the U.S., or 1-800-267-7377 in Canada, with any problems and/or suggestions that you might have. A service representative will be happy to help you.

Note:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.