

vtech[®]


Instruction Manual

3-in-1 Race & Repair Hauler™



INTRODUCTION

Thank you for purchasing the **VTech® 3-in-1 Race & Repair Hauler™**. Welcome to the world of high-speed racing! This 3-in-1 Hauler is your ultimate playtime partner—drive it, transform it into Duo Racing mode, or activate Repair Shop mode for a variety of vehicle-based action. It comes with 3 mini vehicles, each with their own animal driver. Whether you're washing cars, fixing flat tires, fueling up, or tuning engines, Lion Repairs is here to help! Get ready to roll, race, and repair!




Note: This product is in Try-Me mode in the packaging. After opening the package, raising or lowering the Top Launcher or putting any included mini vehicle on the Recognition Point will exit Try-Me mode and proceed with normal play.

INCLUDED IN THE PACKAGE




3-in-1 Race &
Repair Hauler™



One long track B



Two track supports



One car wash roller



Three mini vehicles



4 screws




One Quick Start Guide



One label sheet

Unlock the Packaging Locks

- ① Rotate the packaging locks 90 degrees counterclockwise.
- ② Pull out the packaging locks and discard.



Note: This product is in Try-Me mode in the packaging. After opening the package, raising or lowering the Top Launcher or putting any included mini vehicle on the Recognition Point will exit Try-Me mode and proceed with normal play.

WARNING

All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties, cords and packaging screws are not part of this toy, and should be discarded for your child's safety.

NOTE

Please save this Instruction Manual as it contains important information.

ATTENTION

Pour la sécurité de votre enfant, débarrassez-vous de tous les produits d'emballage tels que rubans adhésifs, feuilles de plastique, attaches, étiquettes, cordons et vis d'emballage. Ils ne font pas partie du jouet.

NOTE

Il est conseillé de sauvegarder ce manuel d'utilisation car il comporte des informations importantes.



CAUTION:

Adult assembly required.

This package contains small screws. For your child's safety, do not let your child play with the toy until it is fully assembled.



ATTENTION :

Ce jouet doit être assemblé par un adulte.

Ce jouet contient des petites vis. Pour la sécurité de votre enfant, ne pas le laisser jouer avec le jouet tant que ce dernier n'est pas complètement assemblé par un adulte.



WARNING:

Adult assembly required for battery installation.
Keep batteries out of reach of children.




ATTENTION :

Les piles ou accumulateurs doivent être installés par un adulte.
Tenir les piles ou accumulateurs hors de portée des enfants.

INSTRUCTIONS

Battery Removal and Installation

1. Make sure the unit is turned Off.
2. Locate the battery cover on the bottom of the Hauler. use a screwdriver to loosen the screw and then open the battery cover.
3. Remove old batteries by pulling up on one end of each battery.
4. Install 2 new AAA (LR03) batteries following the diagram inside the battery box (For best performance, alkaline batteries or fully charged Ni-MH rechargeable batteries are recommended.)
5. Replace the battery cover and tighten the screw to secure.



IMPORTANT: BATTERY INFORMATION

- Insert batteries with the correct polarity (+ and -).
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Do not short-circuit the supply terminals.
- Remove batteries during long periods of non-use.
- Remove exhausted batteries from the toy.
- Dispose of batteries safely. Do not dispose of batteries in fire.

RECHARGEABLE BATTERIES:

- Rechargeable batteries are only to be charged under adult supervision.
- Do not charge non-rechargeable batteries.

IMPORTANT : INFORMATIONS CONCERNANT LES PILES


- Mettre en place les piles ou les accumulateurs en respectant les polarités + et –.
- Ne pas mélanger des piles ou des accumulateurs neufs avec des usagés.
- Ne pas mélanger différents types de piles : alcalines, zinc-carbone et rechargeables.
- Seules des piles du type recommandé doivent être utilisées.
- Ne pas mettre les bornes d'une pile ou d'un accumulateur en court-circuit (en reliant directement le + et le –).
- Retirer les piles ou les accumulateurs en cas de non-utilisation prolongée.
- Enlever les piles ou les accumulateurs usagés du jouet.
- Ne les jeter ni au feu ni dans la nature.






PILES RECHARGEABLES :





- Les accumulateurs ne doivent être chargés que sous la surveillance d'un adulte.
- Ne pas tenter de recharger des piles non rechargeables.




LABEL APPLICATION

Please adhere the labels to the playset securely as indicated on the following page:










ASSEMBLY INSTRUCTIONS

With the VTech® 3-in-1 Race & Repair Hauler™, safety comes first. To ensure your child's safety, adult assembly is required.

Initial Assembly


1. Press the arrow button to remove **Long Track A**, as shown below.



2. Insert one red **Track Support** into the Hauler, then insert the blue **Car Wash Roller** into that **Track Support**. Insert the other **Track Support** into the other side of the Hauler, then insert the **Car Wash Roller**, as shown below. Fasten the two **Track Supports** to the Hauler with four **Screws**.



3. Raise the **Top Launcher** up until it locks in place. Slide the grey **Long Track A** into the red **Track Supports**, then connect it to the red **Top Launcher**, as shown below.



4. Insert **Long Track B** into **Long Track A**, as shown below. An audible click will indicate the track is securely fastened.



Once you've completed the above steps, you are ready to play!

Main Configuration



TRANSFORMATION

Big Hauler Mode

1. Press the **Lift Button**, then lower the **Top Launcher** manually.



2. Fold **Long Track B** up onto the top of the hauler.



Once you've completed the above steps, Big Hauler mode is ready to play.




Reverse these steps to return to Duo Racing mode.

Repair Shop Mode

1. Press the two small buttons on **Long Track B** to release it, then insert the track into the slot on the side of the hauler near Lion.



2. Press the arrow button to release **Long Track A**. Connect it to the back of the hauler.



Once you've completed the above steps, Repair Shop mode is ready to play.




Reverse these steps to return to Big Hauler mode.

PRODUCT FEATURES

1. On/Off Switch

To turn the unit **On**, slide the **On/Off Switch** to the **On** (⏻) position. To turn the unit **Off**, slide the **On/Off Switch** to the **Off** (●) position.



2. Automatic Shut-Off


To preserve battery life, the **3-in-1 Race & Repair Hauler** will automatically enter Sleep mode after approximately **50** seconds without input. The unit can be awoken from Sleep mode by pressing any button, raising or lowering the top launcher, or putting any dummy car on the recognition point. If the unit powers down while playing, we suggest changing the batteries.

3. TRY ME MODE

Note: This product is in Try-Me mode in the packaging. After opening the package, raising or lowering the top launcher or putting any included mini car on the recognition point will exit Try-Me mode and proceed with normal play.

ACTIVITIES


1. Slide the **On/Off Switch** to On. You will hear sounds, fun phrases and a song. The lights will flash with the sounds.



2. Put a **Mini Vehicle** on the **Recognition Spot** to provide repair shop responses and to recognize the 3 **Mini Vehicles**, introducing animals, colors, and numbers. The lights will flash with the sounds.



3. Press the **LED Music Button** to hear songs and music. The lights will flash with the music. Park a **Mini Vehicle** on the **Recognition Spot** and press the button to hear vehicle-specific songs and upbeat melodies.



4. Press the **Number Button** to have Lion repair vehicles while simultaneously teaching numbers. The lights will flash with the sounds. Park a **Mini Vehicle** on the **Recognition Spot** and press the button to hear vehicle-specific responses.



5. Press the **Car Wash Button** to introduce a car wash activity with fun phrases and sounds. The lights will flash with the sounds. Park a **Mini Vehicle** on the **Recognition Spot** and press the button to hear vehicle-specific responses.



6. Press the **Maintenance Button** to trigger repair-related responses. The lights will flash with the sounds. Park a **Mini Vehicle** on the **Recognition Spot** and press the button for responses tailored to each vehicle.



7. Press **Lion** to hear fun repair shop responses, fixing cars and interacting with animals. The lights will flash with the sounds. Having a **Mini Vehicle** in the **Recognition Spot** will trigger vehicle-specific responses.



8. Lift the **Top Launcher** to trigger fun racing sounds. Once you're done, press the **Lift Button** to unlock the **Top Launcher** from its raised position, then lower the **Top Launcher** manually.



9. Put a **Mini Vehicle** on the **Top Launcher**, then lift the launcher up to send the **vehicle** down the ramp.



10. In Repair Shop mode, a **Mini Vehicle** on the **Recognition Spot** and push the **Mini Vehicle** or press the **Launcher Button** to launch a **vehicle** down the blue ramp.



11. Put a **Mini Vehicle** at the back of the Repair Shop, and push the vehicle to launch it down the ramp.



MELODIES

- ML01 Oats, Peas, Beans, and Barley Grow
- ML02 1, 2, 3, 4, 5 Once I Caught a Fish Alive
- ML03 Pat-A-Cake
- ML04 Rockin' Robin
- ML05 BINGO
- ML06 London Bridge
- ML07 Do You Know the Muffin Man?
- ML08 Hickory Dickory Dock
- ML09 A-Tisket A-Tasket
- ML10 Oh Where, Oh Where Has My Little Dog Gone
- ML11 While Strolling Through the Park One Day
- ML12 Hey, Diddle Diddle

SONGS

Song 1

Tune it! Fix it! Learn and play,
Adventure with us every day!

Song 2

Number 1, bright red, let's play
Tune it! Fix it! Learn and play,
Adventure with us every day!

Song 3

Blue 2, leading the way
Tune it! Fix it! Learn and play,
Adventure with us every day!

Song 4

Number 3 rules the raceway
Tune it! Fix it! Learn and play,
Adventure with us every day!

Song 5

One, two, three, four, five,
Tiger, take us on a drive!

Song 6

Number 1, bright red, let's play

Song 7

Blue 2, leading the way

Song 8

Number 3 rules the raceway

CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat sources.
3. Remove the batteries if the unit will not be in use for an extended period of time.
4. Do not drop the unit on a hard surface and do not expose the unit to moisture or water.

TROUBLESHOOTING

If for some reason the unit stops working or malfunctions, please follow these steps:

1. Please turn the unit **Off**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit **On**. The unit should now be ready to play again.
5. If the unit still does not work, install a new set of batteries.

IMPORTANT NOTE:

If the problem persists, please contact our **Consumer Services Department** at **1-800-521-2010** in the U.S. or **1-877-352-8697** in Canada, or by going to our website at **vtechkids.com** and filling out our **Contact Us** form located under the **Customer Support** link. Creating and developing **VTech®** products is accompanied by a responsibility that we take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to contact us with any problems and/or suggestions you might have. A service representative will be happy to help you.

NOTE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

CAUTION

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Supplier's Declaration of Conformity
47 CFR § 2.1077 Compliance Information

Trade Name: VTech®
Model: 5891
Product Name: 3-in-1 Race & Repair Hauler™
Responsible Party: VTech Electronics North America, L.L.C
Address: 1156 W. Shure Drive, Suite 200
Arlington Heights, IL 60004
Website: vtechkids.com

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES.
OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS:
(1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND
(2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED,
INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE
D OPERATION.

CAN ICES(B)/NMB(B)

**Visit our website for more
information about our products,
downloads, resources and more.**

vtechkids.com
vtechkids.ca

Read our complete warranty policy online at
vtechkids.com/warranty
vtechkids.ca/warranty

