


Starshine the Bright Lights Unicorn™



91-003544-004(9)

INTRODUCTION

Thank you for purchasing **Starshine the Bright Lights Unicorn**™. This enchanting unicorn features three modes of play, colorful charms and a light-up horn. Place the charms on the magic heart recognition points to decorate the unicorn and hear colors and fun phrases in English and Spanish, plus whimsical sounds. Squeeze her tail to flap her wings as she rolls along!



(Blue Butterfly, Green Diamond, Yellow Star, Red Cherries, Rainbow, Purple Heart, Orange Flower.)

INCLUDED IN THIS PACKAGE

- One Starshine the Bright Lights Unicorn™
- · One charm storage dish
- · Seven charms
- · One parent's guide

WARNING:

All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties and packaging screws are not part of this toy and should be discarded for your child's safety.

NOTE: Please keep this parent's guide as it contains important information.

ATTENTION:

Pour la sécurité de votre enfant, débarrassez-vous de tous les produits d'emballage tels que rubans adhésifs, feuilles de plastique, attaches, étiquettes et vis d'emballage. Ils ne font pas partie du jouet.

NOTE: Il est conseillé de conserver ce guide des parents car il comporte des informations importantes.

Unlock the packaging locks:



- Rotate the packaging locks counterclockwise 90 degrees.
- 2) Pull out the packaging locks.

Release the Charm:

- 1. Make sure the unit is OFF.
- 2. Carefully pull the Charm away from Starshine and cut the strings as illustrated.



Remove the strings from Starshine and throw them away.

GETTING STARTED

BATTERY INSTALLATION

- 1. Make sure the unit is turned OFF.
- 2. Locate the battery cover on the side of the unit.
- Use a screwdriver to loosen the screw and open the battery cover.
- Install 2 new AA (AM-3/LR6) batteries into the battery box as illustrated. (The use of new alkaline batteries is recommended for maximum performance.)
- 5. Replace the battery cover and tighten the screw to secure.





BATTERY NOTICE

- Use new alkaline batteries for maximum performance.
- Use only batteries of the same or equivalent type as recommended.
- Do not mix different types of batteries: alkaline, standard (carbonzinc) or rechargeable, or new and used batteries.
- Do not use damaged batteries.
- · Insert batteries with the correct polarity.
- Do not short-circuit the battery terminals.
- Remove exhausted batteries from the toy.
- · Remove batteries during long periods of non-use.
- · Do not dispose of batteries in fire.
- Do not charge non-rechargeable batteries.
- Remove rechargeable batteries from the toy before charging (if removable).
- Rechargeable batteries are only to be charged under adult supervision.

PRODUCT FEATURES

1. Off/Mode Selector

To turn the unit ON, slide the selector from OFF ${\mathfrak o}$ to Charms & Colors, Charms & Colors in Spanish or Music Time.

Spanish or Music Time.

To turn the unit OFF Φ, slide the selector to the



OFF & position. 2. Volume Switch

The **Volume Switch** is located on the side of the unicorn. To adjust the volume, slide the **Volume Switch** to the **Low Volume** or **High Volume** position.



3. Seven Charms

Place the **Seven Charms** on the **Magic Heart Recognition Points** to hear fun responses about the charms.



4. Magic Heart Recognition Points

Place a **Charm** on any of the three **Magic Heart Recognition Points** on Starshine to trigger fun responses and lights. She has **Magic Heart Recognition Points** on her crown, bracelet and side.



5. Magical Light-Up Horn

The **Magical Light-Up Horn** will light-up in multiple colors with the voice responses, songs and melodies.



6. Magical Tail

Squeeze her **Magical Tail** to flap her beautiful wings and hear fun responses and songs.



7. Blue Heart Button

Press the **Blue Heart Button** to hear questions, fun phrases about the unicorn and to play melodies.



8. Necklace Button

Press the **Necklace Button** to hear fun sounds and see the unicorn's horn light up.



9. Rolling Wheels

Starshine's hooves feature wheels so you can push her along.



10.Charm Storage Dish

Store the **Seven Charms** in the heart-shaped **Charm Storage Dish**.



11. Automatic Shut Off

To preserve battery life, Starshine the Bright Lights Unicorn™ will automatically power down after several minutes of no input. The unicorn can be turned on again by sliding the Off/ Mode Selector to Charms & Colors, Charms & Colors in Spanish or Music Time.

NOTE: If the unicorn powers down while playing, we suggest replacing with a new set of batteries.

ACTIVITIES:

1. Charms & Colors

- a. Place a **Charm** on any of the three **Magic Heart Recognition Points** to hear about colors, beginning letters and fun phrases.
- b. Press the **Blue Heart Button** to hear questions about the charms, then place the charms on one of the **Magic Heart Recognition Points** to answer the questions.

2. Charms & Colors in Spanish

- a. Place a **Charm** on any of the three **Magic Heart Recognition Points** to hear colors and phrases in Spanish.
- b. Press the **Blue Heart Button** or squeeze the **Magical Tail** to hear fun responses about the unicorn in Spanish.

3. Music Time

- a. Place a **Charm** on any of the three **Magic Heart Recognition Points** to hear fun sounds.
- b. Press the **Blue Heart Button** to play melodies, or squeeze the **Magical Tail** to play songs, then press the **Necklace Button** or place any of the **Seven Charms** on a **Magic Heart Recognition Point** to add sounds into the melodies and songs.

SONG LYRICS

Song 1:

I'm Starshine the unicorn,
Won't you come and shine with me!
Let's Go!

Song 2:

Let's play with all these colorful charms.

There's purple, orange and blue, yellow, green and red too.

So won't you

Put in the perfect charm for me?

Is it a star or lovely cherries?

They're so much fun for you and me!

Song 3:

¡Ponme mis adornos de color (y) brillaré como el sol! Diamante verde, morado corazón Arco iris multicolor. Adórname con tu imaginación ¡para divertirnos tú y yo!

Song 4:

Flying from here to there,
Got wings on my back and colors in my hair! Oh Yeah!
And magic under my feet!
It's really sweet!
I'm Starshine the unicorn,
Won't you come and shine with me!
Let's Go!

Song 5:

Fly with me, my best friend, To a magical world of colorful fun.

MELODY LIST

- 1. Twinkle, Twinkle Little Star
- 2. Sing a Song of Sixpence
- 3. Little Miss Muffet

CARE & MAINTENANCE

- 1. Keep the unit clean by wiping it with a slightly damp cloth.
- Keep the unit out of direct sunlight and away from any direct heat sources.
- 3. Remove the batteries when the unit is not in use for an extended period of time.
- Do not drop the unit on a hard surface and do not expose the unit to excess moisture.

TROUBLESHOOTING

If for some reason the unit stops working or malfunctions while playing with the **Charms**, please remove the **Charms** and place them back onto the unicorn.

If the unit still isn't functioning, or if for some reason the unit stops working, please follow these steps:

- 1. Turn the unit OFF.
- 2. Interrupt the power supply by removing the batteries.
- 3. Let the unit stand for a few minutes, then replace the batteries.
- 4. Turn the unit back **ON**. The unit will now be ready to play again.
- 5. If the unit still does not work, replace with an entire set of new batteries.

If the problem persists, please call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada, or by going to our website at vtechkids.com and filling out our Contact Us form located under the Customer Support link. A service representative will be happy to help you.

IMPORTANT NOTE:

Creating and developing **VTech®** products is accompanied by a responsibility that we at **VTech®** take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada, or by going to our website at vtechkids.com and filling out our Contact Us form located under the Customer Support link with any problems and/or suggestions that you might have. A service representative will be happy to help you.

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRED OPERATION.

CAN ICES-3 (B)/NMB-3(B)

CLASS 1 LED PRODUCT

Visit our website for more information about our products, downloads, resources and more.

vtechkids.com

Read our complete warranty policy online at vtechkids.com/warranty



TM & © 2018 VTech Holdings Limited.
All rights reserved.
Printed in China.
91-003544-004 (®)