

vtech®

Instruction Manual

Glitter Me
Kitten™



INTRODUCTION

Thank you for purchasing the **Glitter Me Kitten™**.

The kitten's lights will show you if it's hungry, sleepy, gassy, bored or itchy. Press its tummy to translate the meows into words. When you pet the kitten's head, it will place a magical glittery stamp on your hand!


Light-Up Head Button

Mouth Button

Back Button


Ink Pad

Tummy Button



Stamping Map

Off/Low Volume/High Volume Switch



INCLUDED IN THE PACKAGE

- **Glitter Me Kitten™**
- 1 milk bottle
- 1 ink pad for hand with cover
- 1 Quick Start Guide
- 1 stamping map (two pieces)

WARNING

All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties, cords and packaging screws are not part of this toy, and should be discarded for your child's safety.

NOTE

Please save this manual as it contains important information.

ATTENTION

Pour la sécurité de votre enfant, débarrassez-vous de tous les produits d'emballage tels que rubans adhésifs, feuilles de plastique, attaches, étiquettes, cordons et vis d'emballage. Ils ne font pas partie du jouet.


NOTE

Il est conseillé de conserver ce guide car il comporte des informations importantes.

GETTING STARTED

Battery Removal and Installation

1. Make sure the unit is turned **Off**.
2. Find the battery cover located on the bottom of the kitten, use a screwdriver to loosen the screw and open the battery cover.
3. Remove old batteries by pulling up on one end of each battery.
4. Install 3 new AA batteries following the diagram inside the battery box.
5. Replace the battery cover and tighten the screw to secure.





WARNING:

Adult assembly required for battery installation.
Keep batteries out of reach of children.



ATTENTION :

Les piles ou accumulateurs doivent être installés par un adulte.
Tenir les piles ou accumulateurs hors de portée des enfants.


IMPORTANT: BATTERY INFORMATION

- Insert batteries with the correct polarity (+ and -).
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Do not short-circuit the supply terminals.
- Remove batteries during long periods of non-use.
- Remove exhausted batteries from the toy.
- Dispose of batteries safely. Do not dispose of batteries in fire.

RECHARGEABLE BATTERIES

- Remove rechargeable batteries from the toy before charging.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not charge non-rechargeable batteries.

Unlock the Packaging Locks



- ① Rotate the packaging locks counterclockwise 90 degrees.
- ② Pull out the packaging locks and discard.

To Begin Playing With Glitter Me Kitten™

When you play with **Glitter Me Kitten™** for the first time, slide the switch from the **High Volume** position to the **Low Volume** position and wait for more than one second to exit Try-Me mode. You will hear three beeping sounds when you have exited Try-Me mode. You can then press any button to activate the unit and start playing.

How to Install the Ink Pad For Hand

With the **Glitter Me Kitten™**, adult assembly is required.

Please note that the unit comes with a pink decorative cover on the kitten's paw. This cover will need to be removed and the ink pad for hand installed so that the **Glitter Me Kitten™** can stamp hands.

1. Pull the decorative cover off the kitten's paw.
2. Take the ink pad for hand from the aluminum packaging and remove the plastic ink cover from the ink pad for hand.
3. Place the ink pad for hand on the kitten's paw, with the tip of the heart pointed toward the paw.
4. Press down firmly on both sides of the ink pad for hand. You will hear it click into place when inserted properly. The ink pad for hand is now ready to use.
5. Put the decorative cover and plastic ink cover together by aligning their latches, and store them on the bottom of the kitten, with the cover's latch facing **Off/Low/High Volume Switch** and decorative cover facing in.



- When not using the ink pad for hand for an extended period, we suggest taking it out, putting the ink cover back on and storing it in a cool, dry location.
- Clean the stamp holder with a wet cloth to remove any ink and place the decorative cover back on the kitten's paw.
- The ink is safe and washes off with soap and water.



WARNING

The ink pad is **ONLY** for stamping paw prints onto your hand. It is not intended for any other use. Please read all of the safety warnings in this manual before use.

NOTE: Before using the ink pad, please test a small amount of ink on the inside of your wrist to ensure there is no reaction or skin sensitivity.

PRODUCT FEATURES

- Off/Low/High Volume Switch**
To turn the unit **On**, slide the switch from **Off** to the Low Volume **||** or High Volume **|||** position. To turn the unit **Off**, slide the switch to **Off** position.



2. Light-Up Head Button

Press the **Head Button** for three responses:

- Press and hold for 2 seconds and the kitten will move her paw to give you a stamp.
- Press once to hear cute kitten sounds or listen for hints on how to respond to what the kitten needs.
- Press two times to hear the kitten sing songs. Keep an eye on the colors of the lights on her head, as they indicate the kitten's mood.



3. Tummy Button

- After pressing the **Back Button**, **Head Button** or **Mouth Button**, press the **Tummy Button** to hear what the kitten said.
- When the kitten meows, press the **Tummy Button** to translate the purrs or meows into a human voice.
- If you want to hear different voice lines, you can press the **Back Button**, **Head Button** or **Mouth Button** again and then press the **Tummy Button**.



4. **Back Button**

- a) Press to hear different kitten sounds.
- b) Quickly press **2 times** to hear the kitten sing playful songs.
- c) When the kitten is itchy, this button and the **Head Button** are great spots to scratch!




5. **Mouth Button and Milk Bottle**

- a) Press to hear different kitten sounds.
- b) Press **3 times** or **press and hold for** several seconds to feed your kitten when she feels hungry.
- c) Use the **Milk Bottle** to feed your kitten anytime or when your kitten feels hungry. Be careful to not feed her too much, or she will get the hiccups or need to burp.



6. **Stamping Map**

The Stamping Map shows the best position for your hand to receive a stamp. Put the two pieces of the map together on a desk or flat surface. Then place the kitten and your left hand on the map and press the kitten's head for 2 seconds.



7. **Automatic Shut-Off**

To preserve battery life, the **Glitter Me Kitten™** will shut off automatically after several minutes without input. The unit can be turned on again by sliding the **Off/Low/High Volume Switch** or by pressing any button. The unit will also automatically turn off when the batteries are very low.

ACTIVITIES


Glitter Me Kitten™ has five different statuses. When you play with her for a while or after she is left alone for a short period, she will change her status. The lights on the kitten's head represent different feelings:

Head Light Color	What It Means	What To Do
Yellow	Happy	Continue to play with your kitten.
Red	Loving. The kitten loves your care.	Continue to take care of your kitten.
Purple	Questioning. The kitten wonders if your action is correct.	Try another action to take care of your kitten.
Orange	Excited. The kitten is excited and ready to give you a stamp.	Put your hand under the kitten's paw to get a glitter stamp.
Pink	Awesome. The kitten feels awesome when she stamps your hand.	Enjoy the stamp that the kitten gave you.
Green, Slow Flashes	Sleepy	Pat the kitten's back or head 3 times to make her sleep.
Green & Blue	Hungry	Use the milk bottle to feed your kitten.
Orange & Blue	Has the hiccups or need to burp.	Pat the kitten's back 3 times or press her back for 3 seconds.

Blue, Slow Flashes	Bored	Play with the kitten by patting her head or back, or feed her with the milk bottle.
Purple & Blue	Itchy	Find out if the kitten's back or head is itchy and pat that spot 3 times to make the kitten comfortable.
Rainbow	Show time. The kitten wants to sing.	Your kitten will sing a song. Press the Tummy Button to alternate between meows and real words.

Stamp Feature

1. Put the two pieces of the Stamping Map together as illustrated in the picture.
2. Then put the map on a desk or flat surface, then place the kitten and your left hand according to the prints on the map. Try to keep your hand flat while the kitten stamps it.
3. Press and hold the button on the kitten's head for more than 2 seconds. A magical light will show on the kitten's head as it stamps.
4. When the kitten starts to stamp, you can use your hand to hold the kitten's head to prevent the kitten from moving or shifting. This will help the stamp transfer more thoroughly.



5. If the stamp does not seem to be transferring, an adult can remove the stamp pad and use a smooth object to spread the ink around the ink pad for hand.



WARNING:

1. NOT for children under 4 years old. KEEP OUT OF REACH of very young children.
2. Follow all instructions and use under adult supervision.
3. Not to be eaten. Use only as directed. FOR EXTERNAL USE ONLY. DO NOT USE on face. KEEP AWAY from eyes or lips. Rinse eyes with water immediately if product comes into contact with them.
4. DISCONTINUE USE if a rash develops.
5. DO NOT USE if the packaging is already opened or tampered with.

Glitter ink is NON-TOXIC. Conforms to ASTM D4236 and all FDA cosmetic safety regulations. It is laboratory tested and safe for use as recommended. As with all cosmetics, some individual skin types may experience minor skin irritation. If this occurs, discontinue use, and consult a physician if necessary.

IMPORTANT: The glitter ink is ONLY for printing on hands. DO NOT USE on clothing or any other items. AVOID contact with fabrics, carpets and upholstery. In case of contact with clothing, rinse with soap and water immediately.

SONG LYRICS

Best Day Ever

We spend the best day running,
We got the best day coming,
Best friends to the end, can't you see I love you.
Won't you play with me?
Oh, won't you stay with me?
We are the best, we are the best friends ever!

Hanging With My Friends

Hangin' with my friends and dancin' all the day away,
Hangin' with my friends, it's all glitter and lights!
Hear us singin', dancin' all the day away,
We'll be laughin'—all through the night!

Glitter and Sunshine

Pounce and sneak and run away,
Cats can play all through the day.
We've got a lot of fun things we can do,
Glitter and sunshine are waiting for you.

The Soft Kitten Purrs

Fast asleep, the soft kitten purrs,
Dream of people petting your fur.
Your leg twitches here, your lip curls up so,
You've caught that dream mouse on your own.

Ink Pad For Hand Ingredients:

Glycerin, Water (Aqua), Synthetic Fluorophlogopite, Sorbitol, Titanium Dioxide, Polysorbate 20, Caprylyl Glycol, Phenoxyethanol, Hydroxyacetophenone, Acacia Senegal Gum, Xanthan Gum, Tin Oxide, Triethanolamine, Benzoic Acid, Dehydroacetic Acid.

May Contain/Peut Contenir: BLUE 1 LAKE (CI 42090), RED 30 (CI 73360), RED 7 LAKE (CI 15850), RED 27 LAKE (CI 45410), RED 28 (CI 45410), RED 33 (CI 17200), BLUE 1 (CI 42090)

CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat sources.
3. Remove the batteries and the ink pad for hand if the unit will not be in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water

TROUBLESHOOTING

If for some reason the unit stops working or malfunctions, please follow these steps:

1. Turn the unit **Off**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit **On**. The unit should now be ready to use again.
5. If the unit still does not work, install a new set of batteries.

IMPORTANT NOTE:

If the problem persists, please call our **Consumer Services Department** at **1-800-521-2010** in the U.S., **1-877-352-8697** in Canada, or by going to our website **vtechkids.com** and filling out our **Contact Us** form located under the **Customer Support** link. Creating and developing VTech products is accompanied by a responsibility that we take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to contact us with any problems and/or suggestions you might have. A service representative will be happy to help you.

Note

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Supplier's Declaration of Conformity
47 CFR § 2.1077 Compliance Information

Trade Name: VTech®
Model: 5424
Product Name: Glitter Me Kitten™
Responsible Party: VTech Electronics North America, L.L.C.
Address: 1156 W. Shure Drive, Suite 200,
Arlington Heights, IL 60004
Website: vtechkids.com

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRED OPERATION.
CAN ICES-003(B)/NMB-003(B)

**Visit our website for more
information about our products,
downloads, resources and more.**

vtechkids.com
vtechkids.ca

Read our complete warranty policy online at
vtechkids.com/warranty
vtechkids.ca/warranty

