



LITTLE SMART

Baby Talk Discoveries™

USER'S MANUAL



© VTECH
Printed in China
91-01324-000 (美)

Dear Parent:

At VTECH® we know that a child has the ability to do great things.

That's why all of our electronic learning products are uniquely designed

to develop a child's mind and allow them to learn to the best of their

ability. Whether it's introducing numbers and letters, identifying colors

and shapes, or stimulating senses with lights and music, all VTECH®

infant and toddler learning products encourage your child's natural

growth and discovery skills. When it comes to providing electronic


learning products that enlighten, entertain and develop minds, at

VTECH® we see the potential in every child.

INTRODUCTION

Thank you for purchasing the **VTECH® LITTLE SMART Baby Talk Discoveries™** learning toy! This product is one of a family of high-quality **LITTLE SMART** electronic learning products. We at **VTECH®** are committed to providing the best possible products to entertain and educate your child. Should you have any questions or concerns, please call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-800-267-7377 in Canada.

LITTLE SMART Baby Talk Discoveries™ learning toy is perfectly designed for infants 12 months and up. Decorated with twinkling star lights and colorful buttons, it identifies familiar objects, faces and plays cheerful melodies. Family and friends can share this precious time with Baby by recording their own loving message for Baby to discover. **LITTLE SMART Baby Talk Discoveries™** is a charming way to introduce Baby to the world of speaking.




INCLUDED IN THIS PACKAGE

- One **LITTLE SMART Baby Talk Discoveries™** learning toy
- One instruction manual

WARNING: All packing materials, such as tape, plastic sheets, wire ties and tags are not part of this toy, and should be discarded for your child's safety.

BATTERY INSTALLATION

1. Make sure the unit is turned off.
2. Locate the battery cover on the back of the unit. Use a coin or screwdriver to loosen the screw.
3. Install 3 new "AA" (UM-3/LR6) batteries following the diagram inside the battery box. (The use of new, alkaline batteries is recommended for maximum performance.)
4. Replace the battery cover and tighten the screw to secure the battery cover.



BATTERY NOTICE

- Install batteries correctly observing the polarity (+, -) signs to avoid leakage.
- Do not mix old and new batteries.
- Do not use batteries of different types.
- Remove exhausted or new batteries from the equipment when the unit will not be used for an extended period of time.
- Do not dispose of batteries in fire.
- Do not attempt to recharge ordinary batteries.
- The supply terminals are not to be short-circuited.

WE DO NOT RECOMMEND THE USE OF RECHARGEABLE BATTERIES.

NOTE: If for some reason the program/activity stops working, then please follow these steps:


1. Please turn the unit off.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit on. The unit should now be ready to play again.

If the problem persists, please call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-800-267-7377 in Canada, and a service representative will be happy to help you.

TO BEGIN PLAY

1. Turn the **On/Off Switch** to the **On** (✱) **Position** to turn the unit on.


Note: The recording function (located on the back of the unit) must be off to begin play.




2. Slide the **Activity Selector** to either the **Talking Activity** (😊) or the **Music Activity** (🎵). Musical notes will play and the lights will blink.




3. To adjust the volume, slide the **Volume Control Switch** located on the back of the unit to (🔊) for **Low Volume** or (🗣️) for **High Volume**.



4. Press any button to begin play.



5. Turn the **On/Off Selector** to the **Off (●)** Position to turn the unit off.



ACTIVITIES

A. Talking Activity

1. When the unit is on, slide the **Activity Selector** to the **Talking Activity (☺)**. Musical notes will play and the lights will blink.



2. Press any button to hear a spoken word identified. Lights will flash with the voice.

“Baby” or your
own message



“Daddy”

“Mommy”



“Grandma”

“Grandpa”



“Ball”

“Milk”



“Teddy Bear”

“Bird”




“Puppy”

B. To Record a Personalized Message


1. You may record your own personalized message. On the back of the unit, turn the **Recording On/Off Switch** to the **On (*)** position. You will hear a short tune.




2. While pressing the **Record Button**, speak clearly into the microphone. The light on the back of the unit will light up for 5 seconds of recording. When the memory is full, the light will turn off and recording will stop.



3. Press the **Baby Button** on the front of the unit to hear your personalized message.



4. To record a new message, press the **Reset Button** and repeat the recording process.




5. Press the **Reset Button** on the back of the unit at any time to restore the built-in phrase.











Note: The recorded phrase will be erased when the battery is changed.

C. Music Activity

1. When the unit is on, slide the **Activity Selector** to the **Music Activity** (🎵). Musical notes will play and the lights will blink.



2. Press any button to hear a sound effect or melody. The stars will light up with all of the sounds.

Rock-a-bye Baby			Mulberry Bush
Mary Had a Little Lamb			Humpty Dumpty
Lavender's Blue			Ball Sound Effect
Oh Dear, What Can the Matter Be			Twinkle Twinkle
Bird Sound Effect			Dog Sound Effect

AUTOMATIC SHUT-OFF

To preserve battery life, the **VTECH® LITTLE SMART Baby Talk Discoveries™** learning toy will automatically turn off after 30 seconds without input. It can be turned on again by pressing the on button.

CARE AND MAIN MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat source.
3. Remove the batteries when the unit is not in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

IMPORTANT NOTE

Creating and developing infant/toddler products is accompanied by a responsibility that we at **VTECH®** take very seriously. We make every effort to ensure the accuracy of the information which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-800-267-7377 in Canada with any problems and/or suggestions that you might have. A service representative will be happy to help you.

Note:

This equipment generates and uses radio frequency energy and if not installed and used properly, that is, in strict accordance with the manufacturer's instructions, it may cause interference to radio and television reception. It has been type tested and found to comply within the limits for a Class B computing device in accordance with the specifications in Sub-part J of Part 15 FCC Rules, which are designed to provide reasonable protection against such interference in a residential installation. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause interference with radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- reorient the receiving antenna
- relocate this product with respect to the receiver
- move this product away from the receiver