



vtech[®]

Parent's Guide

Spin & Tweet Musical Birdhouse™




91-003694-001  

INTRODUCTION

Thank you for purchasing the **Spin & Tweet Musical Birdhouse™**.

Place the baby birds in their birdhouse nest and take them out again for interactive fun! The baby birds love to sing both alone and together when placed into the nest. Hear the sounds of the three instruments they play and learn about colors and numbers.



INCLUDED IN THIS PACKAGE

- One **Spin & Tweet Musical Birdhouse™**
- Three baby birds
- One parent's guide

WARNING:

All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties and packaging screws are not part of this toy, and should be discarded for your child's safety.

NOTE:

Please keep this parent's guide as it contains important information.


ATTENTION :

Pour la sécurité de votre enfant, débarrassez-vous de tous les produits d'emballage tels que rubans adhésifs, feuilles de plastique, attaches, étiquettes et vis d'emballage. Ils ne font pas partie du jouet.

NOTE :


Il est conseillé de conserver ce guide des parents car il comporte des informations importantes.

Unlock the packaging locks:



① Rotate the packaging locks counterclockwise 90 degrees.

② Pull out the packaging locks.




NOTE:

Please cut and discard the cord and the transparent film that attaches the birds to the bird house. The cord and the transparent film are not part of this toy and should be discarded for your child's safety.

GETTING STARTED

BATTERY INSTALLATION

1. Make sure the unit is turned **Off**.
2. Locate the battery cover on the bottom of the unit. Use a screwdriver to loosen the screw.
3. Install 2 new AA (AM-3/LR6) battery following the diagram inside the battery box. (The use of a new alkaline battery is recommended for maximum performance).
4. Replace the battery cover and tighten the screw to secure.






BATTERY NOTICE

- Use new alkaline batteries for maximum performance.
- Use only batteries of the same or equivalent type as recommended.
- Do not mix different types of batteries: alkaline, standard (carbon-zinc) or rechargeable, or new and used batteries.
- Do not use damaged batteries.
- Insert batteries with the correct polarity.
- Do not short-circuit the battery terminals.
- Remove exhausted batteries from the toy.
- Remove batteries during long periods of non-use.
- Do not dispose of batteries in fire.
- Do not charge non-rechargeable batteries.
- Remove rechargeable batteries from the toy before charging (if removable).
- Rechargeable batteries are only to be charged under adult supervision.

PRODUCT FEATURES

1. On/Off/Mode Selector

To turn the unit **On**, slide the **On/Off/Mode** selector to the Learning mode  or Music mode  position. To turn the unit **Off**, slide the **On/Off/Mode** selector to the **Off**  position.



2. Low/High Volume

Slide the **Low/High Volume** switch to choose a suitable volume to play.



3. Automatic Shut Off

To preserve battery life, the **Spin & Tweet Musical Birdhouse™** will automatically power down after approximately 30 seconds without input. The unit can be turned on again by pressing any button.

NOTE: If the unit powers off during play, we suggest changing the batteries.

ACTIVITIES

1. Piano Buttons

Press any of the three **Piano** buttons to learn about objects, feelings, sounds, melodies and more. In Learning mode, you can explore colors, objects and feelings. In Music mode, hear piano notes, fun melodies and sounds. In both modes, the lights will flash with the sounds.




2. Mommy Bird

Pull down the **Mommy Bird** to learn numbers, colors and counting in Learning mode. Hear sounds and different instruments in Music mode. In both modes, the lights will flash with the sounds.



3. Bird Nest

Put the three **Baby Birds** into the nest one at a time to learn numbers in Learning mode and hear sing-along songs, melodies and sounds in Music mode.



4. Magic Tree Trunk

Place a **Baby Bird** on the **Magic Tree Trunk** to hear the bird sing and say several phrases in Learning mode. In Music mode, listen to the instruments each bird plays.



MELODY LIST

1. Twinkle, Twinkle Little Star
2. Humpty Dumpty
3. London Bridge
4. Hey Diddle Diddle
5. Goodnight Ladies
6. Farmer in the Dell
7. Old MacDonald
8. Turkey in the Straw
9. Chicken Reel
10. Bingo
11. My Bonnie Lies Over the Ocean

12. Row, Row, Row Your Boat
13. Skip To My Lou
14. Three Little Kittens
15. Yankee Doodle

SONG LYRICS

Song 1

Girls and boys, come and play.
We're ready to sing with you today.

Song 2

A-tisket, a-tasket, three birdies in a basket.
Momma's near by, she wants us to fly.
Adventure is awaiting!

CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat sources.
3. Remove the batteries when the unit is not in use for an extended period of time.
4. Do not drop the unit on a hard surface and do not expose the unit to excess moisture.

TROUBLESHOOTING

If for some reason the program/activity stops working or malfunctions, please follow these steps:

1. Turn the unit **OFF**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit back **ON**. The unit will now be ready to play again.
5. If the unit still does not work, replace with an entire set of new batteries.

If the problem persists, please call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada, or by going to our website at vtechkids.com and filling out our Contact Us form located under the Customer Support link. A service representative will be happy to help you.

IMPORTANT NOTE:

Creating and developing **VTech®** products is accompanied by a responsibility that we at **VTech®** take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada, or by going to our website at vtechkids.com and filling out our Contact Us form located under the Customer Support link with any problems and/or suggestions that you might have. A service representative will be happy to help you.

Note:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Supplier's Declaration of Conformity

Trade Name: VTech®
Model: 5224
Product name: Spin & Tweet Musical Birdhouse™
Responsible Party: VTech Electronics North America, LLC
Address: 1156 W. Shure Drive, Suite 200,
Arlington Heights, IL 60004
Website: vtechkids.com

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION.

CAN ICES-3 (B)/NMB-3(B)

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Visit our website for more
information about our products,
downloads, resources and more.**

vtechkids.com

Read our complete warranty policy online at
vtechkids.com/warranty



TM & © 2019 VTech Holdings Limited.
All rights reserved.

Printed in China.

91-003694-001 (US) (CN)