



Parent's Guide

# Super Learning Flashlight



©2020 Frog Box/Entertainment One US Limited

91-003767-000-000 (US)

# INTRODUCTION

Thank you for purchasing the **PJ Masks Super Learning Flashlight**.

Flip through nine unique PJ Masks projections to play fun learning games featuring Catboy, Gekko, Owlette, and more. The **PJ Masks Super Learning Flashlight** includes three exciting modes that test your skills with ABCs, phonics, colors, numbers, counting and more!



# INCLUDED IN THIS PACKAGE

- One **PJ Masks Super Learning Flashlight**
- One parent's guide

## **WARNING:**

All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties and packaging screws are not part of this toy, and should be discarded for your child's safety.

## **NOTE:**

Please keep this parent's guide as it contains important information.

## **NOTE :**

Do not stare at the operating light source. Do not shine light in eyes.

## **ATTENTION :**

Pour la sécurité de votre enfant, débarrassez-vous de tous les produits d'emballage tels que rubans adhésifs, feuilles de plastique, attaches, étiquettes et vis d'emballage. Ils ne font pas partie du jouet.


## **NOTE :**

Il est conseillé de conserver ce guide des parents car il comporte des informations importantes.

## **NOTE :**

Ne pas regarder la lumière en face. Ne pas diriger la lampe torche directement dans les yeux.

## **Unlock the packaging lock:**




- ① Rotate the packaging lock 90 degrees counterclockwise.
- ② Pull out the packaging lock.

# GETTING STARTED

## Battery Removal and Installation

1. Make sure the unit is turned **Off**.
2. Locate the battery cover and use a screwdriver to loosen the screw and open the battery cover.
3. Remove old batteries by pulling up on one end of each battery.
4. Install 2 new AAA (AM-4/LR03) batteries following the diagram inside the battery box. (The use of new alkaline batteries is recommended for maximum performance.)
5. Replace the battery cover and tighten the screw to secure.



## BATTERY NOTICE

- Use new alkaline batteries for maximum performance
- Use only batteries of the same or equivalent type as recommended
- Do not mix different types of batteries: alkaline, standard (carbon-zinc) or rechargeable, or new and used batteries
- Do not use damaged batteries
- Insert batteries with the correct polarity
- Do not short-circuit the battery terminals
- Remove exhausted batteries from the toy
- Remove batteries during long periods of non-use
- Do not dispose of batteries in fire
- Do not charge non-rechargeable batteries
- Remove rechargeable batteries from the toy before charging (if removable)
- Rechargeable batteries are only to be charged under adult supervision

## MISE EN GARDE

- Utiliser des piles alcalines neuves pour des performances maximales
- Seules des piles du type recommandé doivent être utilisées
- Ne pas mélanger différents types de piles ou d'accumulateurs, ne pas mélanger des piles ou des accumulateurs neufs avec des usagés
- Ne pas utiliser des piles ou des accumulateurs endommagés
- Mettre en place les piles ou les accumulateurs en respectant les polarités + et -
- Ne pas mettre les bornes d'une pile ou d'un accumulateur en court-circuit (en reliant directement le + et le -)
- Enlever les piles ou les accumulateurs usagés du jouet
- Retirer les piles ou les accumulateurs en cas de nonutilisation prolongée
- Ne les jeter ni au feu ni dans la nature
- Ne pas tenter de recharger des piles non rechargeables
- Enlever les accumulateurs du jouet pour les recharger
- Les accumulateurs ne doivent être chargés que sous la surveillance d'un adulte

## PRODUCT FEATURES


### 1. On/Off/Volume Selector

To turn the unit **On**, slide the switch from **Off** to **Low** or **High** volume. Slide the switch to **Off** to turn the unit **Off**.

### 2. Three Character Buttons

Press one of the three character buttons to hear PJ Masks character voices and sound effects.

### 3. Unique Projections and Flashlight



Turn the top of the flashlight to view nine unique projected stills from the PJ Masks show or turn to Flashlight mode to find your way in the dark.



For the best view of the projections, please aim the flashlight at a blank wall in a dimly lit room, standing one to three feet away from the wall. You may need to adjust your distance so that the images are in clear focus.

### 4. Mode Selector

Slide the **Mode Selector** to select Super Learning, Discover or Time to Rhyme modes.

### 5. OK Button

Press the **OK Button** to confirm your selected projection.

### 6. Automatic Shut-Off

To preserve battery life, the **PJ Masks Super Learning Flashlight** will automatically shut **Off** and enter sleep mode after several minutes without input or when the batteries are very low. The unit can be woken up again by pressing the **OK Button** or by sliding either the **Mode Selector** or the **On/Off/Volume Selector**.

**NOTE:**

If the unit powers down while playing, please install a new set of batteries.

**NOTE:**

This product is in Try-Me mode in the packaging. After opening the package, move the **On/Off/Volume Selector** from **High** to **Low** volume and wait for one second. You will hear three beeps, indicating that the toy is now in normal play mode.

## ACTIVITIES:

### 1. Super Learning Mode

Teaches letters, phonics, colors and numbers with PJ Masks heroes, villains and famous scenes from the show.

### 2. Discover Mode

Use super learning skills to find answers by selecting the correct projected image on the flashlight.

### 3. Time to Rhyme Mode

Explore rhyming and PJ Masks trivia with these silly sentences.

## CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth. Never use solvents or abrasives.
2. Keep it out of direct sunlight and away from direct sources of heat.
3. Remove the batteries if the unit will not be in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

# TROUBLESHOOTING

If for some reason the unit stops working or malfunctions, please follow these steps:

1. Turn the unit **Off**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit sit for a few minutes, then replace the batteries.
4. Turn the unit **On**. The unit should now be ready to use again.
5. If the unit still does not work, install a new set of batteries.

## **IMPORTANT NOTE:**

If the problem persists, please call our **Consumer Services Department** at **1-800-521-2010** in the U.S., **1-877-352-8697** in Canada, or visit our website **vtechkids.com** and fill out our **Contact Us** form located under the **Customer Support** link. Creating and developing VTech® products is accompanied by a responsibility that we at VTech® take very seriously. We make every effort to ensure the accuracy of the information which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to contact us with any problems and/or suggestions you might have. A service representative will be happy to help you.

## **CAUTION:**

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

## **Note:**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio



communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

### **Supplier's Declaration of Conformity**

Trade Name: VTech<sup>®</sup>  
Model: 5262  
Product name: PJ Masks Super Learning Flashlight  
Responsible Party: VTech Electronics North America, LLC  
Address: 1156 W. Shure Drive, Suite 200  
Arlington Heights, IL 60004  
Website: vtechkids.com

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS:  
(1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND  
(2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRED OPERATION.

*CAN ICES-3 (B)/NMB-3(B)*



CLASS 1  
LED PRODUCT

**Visit our website for more  
information about our products,  
downloads, resources and more.**

***vtechkids.com***

**Read our complete warranty policy online at  
*vtechkids.com/warranty***



VTech and the VTech logo TM & © 2020 VTech Holdings Limited. All rights reserved.  
**Printed in China.**