

Pull & Learn Car Carrier[™]



© 2008 VTech Printed in China 91-002289-009 (**)



049701 IM 009.indd 1

Dear Parent.

Ever notice the look on your baby's face when they learn something new through their own discovery? These self-accomplished moments are a parent's greatest reward. To help fulfill them, VTech® created the Infant Learning® series of toys.

(

These unique interactive learning toys directly respond to what children do naturally - play! Using innovative technology, these toys react to baby's interactions, making each play experience fun and unique as they learn age-appropriate concepts like first words, numbers, shapes, colors and music. More importantly, VTecho's Infant Learning® toys develop baby's mental and physical abilities by inspiring, engaging and teaching.

At VTech®, we know that a child has the ability to do great things. That's why all of our electronic learning products are uniquely designed to develop a child's mind and allow them to learn to the best of their ability. We thank you for trusting VTech® with the important job of helping your child learn and grow!

Sincerely,

Your friends at **VTech**®


To learn more about **VTech**® toys, visit vtechkids.com

2

INTRODUCTION

Thank you for purchasing the VTech® Pull & Learn Car Carrier™ learning toy!

The VTech® Pull & Learn Car Carrier™ is an electronic playset for toddlers 12 months and up. The car carrier is loaded with three vehicles and three animal characters for busy toddlers! Hear fun phrases, sounds and music when the vehicles are rolled up or down the ramp of the car carrier. Insert the animals into the hot spot to hear the related animal name and sound identified. A variety of play features and buttons teach age appropriate curriculum. Load up and let's go!





INCLUDED IN THIS PACKAGE

- One VTech® Pull & Learn Car Carrier™ learning toy
- One instruction manual
- 7 Smart Parts Including 3 animals, 3 vehicles and 1 radio

Animals







Froa

Skunk

Bird

Vehicles







. .



Radio


WARNING: All packing materials, such as tape, plastic sheets, wire ties and tags are not part of this toy, and should

be discarded for your child's safety.



BATTERY INSTALLATION

- Make sure the unit is turned OFF.
- 2. Locate the battery cover on the bottom of the unit. Use a screwdriver to loosen the screw.
- 3. Install 2 new 'AA' (AM-3/LR6) batteries following the diagram inside the battery box.
- 4. Replace the battery cover and tighten the screw to secure.



BATTERY NOTICE

- Install batteries correctly observing the polarity (+. -) signs to avoid leakage.
- Do not mix old and new batteries.
- Do not mix batteries of different types: alkaline, standard (carbonzinc) or rechargeable (nickel-cadmium).
- Remove the batteries from the equipment when the unit will not be used for an extended period of time.
- Always remove exhausted batteries from the equipment.
- Do not dispose of batteries in fire.
- Do not attempt to recharge ordinary batteries.
- The supply terminals are not to be short-circuited.
- Only batteries of the same and equivalent type as recommended are to be used.

WE DO NOT RECOMMEND THE USE OF RECHARGEABLE BATTERIES.



PRODUCT FEATURES


1. ON/OFF/VOLUME CONTROL SWITCH

To turn the unit ON, slide the ON/OFF/
VOLUME CONTROL SWITCH to
the LOW VOLUME (◄) or the HIGH
VOLUME (◄)) position. To turn the
unit OFF, slide the ON/OFF/VOLUME
CONTROL SWITCH to the OFF (●)
position.



2. PULL CORD

To convert the unit from a push toy to a pull toy, remove the pull cord from the battery compartment and thread it through the eyelet on the bottom of the car carrier. For your child's safety we suggest you store the pull cord in the compartment until your child is walking and to supervise your child when playing with the pull cord.



3. AUTOMATIC SHUT-OFF

To preserve battery life, the VTech® Pull & Learn Car Carrier™ will automatically power-down after approximately 40 seconds without input. The unit can be turned on again by pressing any button.



ACTIVITIES


 Slide the on/off/volume control. switch to turn the unit on. You will hear a song and a welcoming phrase. The light will flash with the sound.



Press the **number buttons** to hear numbers, colors, short tunes and fun phrases. The light will flash with the sound.



3. Press the animal buttons to hear fun phrases, animal names and sounds and short tunes. The light will flash with sound.




4. Press the horn button to hear playful driving phrases, sounds and a song. The light will flash with the sound.








- Pick up the radio or place it back on the car carrier to hear fun phrases and sounds. The light will flash with the sound.
- 6. Push the **vehicles** over the sensor on the back of the car carrier to hear a variety of phrases, sounds and music. The light will flash with the sound.
- 7. Place an **animal** into the hot spot to hear the animal name, a sound or a short phrase. Press on the animal while on the hot spot to hear a fun phrase or a random melody. Press the hot spot button to hear a random question. The light will flash with the sound.
- Fold out or fold up the loading ramp to hear playful phrases and sounds. The light will flash with the sound.
- Push or pull the car carrier to hear a variety of vehicle sounds, phrases, songs and melodies. The light will flash with the sound.















MELODY LIST

- 1. This Old Man
- 2. Oh! Susanna
- 3. She'll Be Comin' 'Round the Mountain
- 4. London Bridge
- 5 Aiken Drum
- 6. Sing a Song of Sixpence
- 7. Sur le pont d'Avignon
- 8. Hot Cross Buns

SONG LYRICS

SONG 1 (to the tune of "Ring Around the Rosy")

Drivin' down the highway, Loaded up with cars.

Beep-Beep, Honk-Honk,

Beep-Beep, Honk-Honk

I'm on my way!

SONG 2 (to the tune of "Ring Around the Rosy")

Zip around the corner, In my little tow truck.

Beep-beep! Watch out!

I'm on my way!



CARE & MAINTENANCE

- Keep the unit clean by wiping it with a slightly damp cloth.
- 2. Keep the unit out of direct sunlight and away from any direct heat source.
- Remove the batteries when the unit will not be in use for an 3 extended period of time.
- 4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

TROUBLESHOOTING

If for some reason the program/activity stops working, please follow these steps:

- Please turn the unit **OFF**
- Interrupt the power supply by removing the batteries.
- 3. Let the unit stand for a few minutes, then replace the batteries.
- Turn the unit **ON**. The unit should now be ready to play again.
- If the product still does not work, replace with a new set of batteries. 5.

If the problem persists, please call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada, and a service representative will be happy to help you.

For information on this product's warranty, please call VTech® at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada.





Creating and developing Infant Learning products is accompanied by a responsibility that we at VTech® take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada, with any problems and/or suggestions that you might have. A service representative will be happy to help you.

Note:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help



This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This Class B digital apparatus complies with Canadian ices-003. Cet appareil numérique de la classe b est conforme à la norme nmb-003 du Canada.

Caution: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.





PRODUCT WARRANTY

This Warranty is applicable only to the original purchaser, is non-transferable and applies only to "VTech" products or parts. This product is covered by a 3-month Warranty from the original purchase date, under normal use and service.

against defective workmanship and materials. This Warranty does not apply to (a) consumable parts, such as batteries; (b) cosmetic damage, including but not limited to scratches and dents; (c) damage caused by use with non-VTech products; (d) damage caused by accident, misuse, unreasonable use, immersion in water, neglect, abuse, battery leakage, or improper installation, improper service, or other external causes; (e) damage caused by operating the product outside the permitted or intended uses described by VTech in the owner's manual; (f) a product or part that has been modified (g) defects caused by normal wear and tear or otherwise due to the normal aging of the product; or (h) if any VTech serial number has been removed or defaced.

Prior to returning a product for any reason, please notify the VTech Consumer Services Department, by sending an email to vtechkids@vtechkids.com or calling 1-800-521-2010. If the service representative is unable to resolve the issue, you will be provided instructions on how to return the product and have it replaced under Warranty. Return of the product under Warranty must adhere to the following rules:

If VTech believes that there may be a defect in the materials or workmanship of the product and can confirm the purchase data and location of the product, we will at our discretion replace the product with a new unit or product of comparable value. A replacement product or parts assumes the remaining Warranty of the original product or 30 days from the date of replacement, whichever provides longer coverage.

THIS WARRANTY AND THE REMEDIES SET FORTH ABOVE ARE EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES, REMEDIES AND CONDITIONS, WHETHER ORAL, WRITTEN, STATUTORY, EXPRESS OR IMPLIED. IF VTECH CANNOT LAWFULLY DISCLAIM STATUTORY OR IMPLIED WARRANTIES THEN TO THE EXTENT PERMITTED BY LAW, ALL SUCH WARRANTIES SHALL BE LIMITED TO THE DURATION OF THE EXPRESS WARRANTY AND TO THE REPLACEMENT SERVICE AS DETERMINED BY VTECH IN ITS SOLE DISCRETION.

To the extent permitted by law, VTech will not be responsible for direct, special, incidental or consequential damages resulting from any breach of Warranty.

This Warranty is not intended to persons or entities outside the United States of America. Any disputes resulting from this Warranty shall be subject to the final and conclusive determination of VTech.

