

vtech[®]

User's Manual

Counting Fun Elephant[™]



© 2010 VTech
Printed in China
91-112000-000-000

Dear Parent,

Ever notice the look on your baby's face when they learn something new through their own discovery? These self-accomplished moments are a parent's greatest reward. To help fulfill them, VTech® created the **Infant Learning**® series of toys.

These unique interactive learning toys directly respond to what children do naturally – play! Using innovative technology, these toys react to baby's interactions, making each play experience fun and unique as they learn age-appropriate concepts like first words, numbers, shapes, colors and music. More importantly, VTech®'s **Infant Learning**® toys develop baby's mental and physical abilities by inspiring, engaging and teaching.

At VTech®, we know that a child has the ability to do great things. That's why all of our electronic learning products are uniquely designed to develop a child's mind and allow them to learn to the best of their ability. We thank you for trusting VTech® with the important job of helping your child learn and grow!

Sincerely,


Your friends at VTech®

To learn more about the **Infant Learning**® series and other VTech® toys, visit www.vtechkids.com

INTRODUCTION

Thank you for purchasing the **VTech® Counting Fun Elephant™** learning toy.

VTech®'s Counting Fun Elephant™ combines learning with fun as your child distributes colorful balls through a ball popper. Twist the elephant's ear and watch the balls pop! It's up to a little bird perched nearby to decide which path the balls can take, either through the fountain or over the piano keys. While the toy teaches numbers and counting, the elephant's hand lights up and the piano plays music that keeps your child engaged for endless play time.




INCLUDED IN THIS PACKAGE

- One VTech® Counting Fun Elephant™
- One user's manual

WARNING: All packing materials, such as tape, plastic sheets, wire ties and tags are not part of this toy, and should be discarded for your child's safety.



Unlock the packing locks:



- ① Rotate the packing locks 90 degrees counter-clockwise
- ② Pull out the packing locks

WARNING:


For your child's safety, please do not put anything but the balls included with the product into the fountain or the elephant's trunk.



GETTING STARTED

BATTERY INSTALLATION

1. Make sure the unit is turned **OFF**.
2. Locate the battery cover on the bottom of the unit. Use a coin or a screwdriver to loosen the screw.
3. Install 4 new 'AA' (AM-3/LR6) batteries following the diagram inside the battery box. The use of new alkaline batteries is recommended for maximum performance.
4. Replace the battery cover and tighten the screw to secure.



BATTERY NOTICE

- The use of new alkaline batteries is recommended for maximum performance.
- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed from the toy before being charged (if removable).
- Rechargeable batteries are only to be charged under adult supervision (if removable).
- Do not mix old and new batteries.
- Do not mix batteries of different types: alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium).
- Only batteries of the same or equivalent type as recommended are to be used.
- Batteries are to be inserted with the correct polarity.
- Exhausted batteries are to be removed from the toy.
- The supply terminals are not to be short-circuited.

- The toy is not to be connected to more than the recommended number of power supplies.
- Do not dispose of batteries in fire.

ASSEMBLY INSTRUCTIONS

With the **VTech® Counting Fun Elephant™** safety comes first. To ensure your child's safety, adult assembly is required.



Back Tray



Front Unit

To attach the back tray to the front unit, insert the back tray into the two slots on the front unit. You will hear a 'click' sound, this indicates that the back tray is securely fixed into the front unit.



PRODUCT FEATURES

1. MODE SELECTOR

To turn the unit **ON**, slide the **MODE SELECTOR** to the Learning Mode (123) or Music Mode (🎵). To turn off the unit, slide the **MODE SELECTOR** to the **OFF** position (OFF).






2. AUTOMATIC SHUT-OFF

To preserve battery life, the **VTech® Counting Fun Elephant™** will automatically power-down after approximately 30 seconds without input. The unit can be turned on again by pressing any button.

ACTIVITIES

1. In **Learning Mode**, press the piano keys to learn numbers, animals and colors. The light will flash with the sounds.
2. In **Music Mode**, press the piano keys to hear animal sounds and melodies. The light will flash with the sounds.
3. In either mode, twist the elephant's ears to start the ball popper. Hear fun melodies as the balls pop up in the air. The light will flash with the sounds.
4. While the balls are popping, slide the bird to choose the balls' path. If the bird is on the left, the balls will go back into the elephant's trunk and through the popper. If the bird is on the right, the balls will drop down and roll over the piano keys. The light will flash with the sounds.



SUNG SONG LYRICS

Sung Song 1:

See the balls rolling along, it looks like fun!
Flying up and rolling down, until they're done.
Twist the ear, watch them pop, high in the air.
Popping, rolling, spinning, going, all with such flair!

Sung Song 2:

Listen to the music, feel the beat.
See the balls dancing -- look, it's so neat!

CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat source.
3. Remove the batteries when the unit will not be in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

TROUBLESHOOTING

If for some reason the program/activity stops working or malfunctions, please follow these steps:

1. Please turn the unit **OFF**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit **ON**. The unit should now be ready to play again.

5. If the product still does not work, replace with an entire set of new batteries.

If the problem persists, please call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada, and a service representative will be happy to help you.

For information on this product's warranty, please call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada.

IMPORTANT NOTE:

Creating and developing **Infant Learning** products is accompanied by a responsibility that we at **VTech®** take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department at 1-800-521-2010 in the U.S., or 1-877-352-8697 in Canada, with any problems and/or suggestions that you might have. A service representative will be happy to help you.

FCC Notice:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and

on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION.

THIS CLASS B DIGITAL APPARATUS COMPLIES WITH CANADIAN ICES-003.

CET APPAREIL NUMÉRIQUE DE LA CLASSE B EST CONFORME À LA NORME NMB-003 DU CANADA.

**CLASS 1
LED PRODUCT**