

vtech[®]

User's Manual

Discovery Nursery Farm™



© 2004 VTech
Printed in China

91-02097-002-000 (美)

Dear Parent:

Ever notice the look on your baby's face when they learn something new through their own discovery? These self-accomplished moments are a parent's greatest reward. To help fulfill them, **VTech**[®] created the **Infant Learning** series of toys.

These unique interactive learning toys directly respond to what children do naturally – play! Using innovative technology, these toys react to baby's interactions, making each play experience fun and unique as they learn age-appropriate concepts like first words, numbers, shapes, colors and music. More importantly, **VTech**[®]'s **Infant Learning** toys develop baby's mental and physical abilities by inspiring, engaging and teaching.

At **VTech**[®], we know that a child has the ability to do great things. That's why all of our electronic learning products are uniquely designed to develop a child's mind and allow them to learn to the best of their ability. We thank you for trusting **VTech**[®] with the important job of helping your child learn and grow!

Sincerely,


Your Friends at **VTech**[®]

To learn more about **Infant Learning** and other **VTech**[®] toys, visit www.vtech.com

INTRODUCTION

Thank you for purchasing the **VTech® Discovery Nursery Farm™** learning toy.

The **VTech® Discovery Nursery Farm™** is an interactive toy for toddlers 9 months and up. Press, push and roll the animals to learn animal names and sounds and music. The friendly animals, fun sounds and cheerful music allow little ones to have lots of fun while developing fine motor skills.



INCLUDED IN THIS PACKAGE


- One VTech® Discovery Nursery Farm™
- One instruction manual

WARNING: All packing materials, such as tape, plastic sheets, wire ties and tags are not part of this toy, and should be discarded for your child's safety.

GETTING STARTED

BATTERY INSTALLATION

1. Make sure the unit is turned **OFF**.
2. Locate the battery cover on the bottom of the unit. Use a coin or screwdriver to loosen the screw.
3. Install 2 new “AA” (LR6) batteries following the diagram inside the battery box. (The use of new alkaline batteries is recommended for maximum performance.)
4. Replace the battery cover and tighten the screw to secure the battery cover.



BATTERY NOTICE

- Install batteries correctly observing the polarity (+, -) signs to avoid leakage.
- Do not mix old and new batteries.
- Do not use batteries of different types.
- Remove exhausted or new batteries from the equipment when the unit will not be used for an extended period of time.
- Do not dispose of batteries in fire.


- Do not attempt to recharge ordinary batteries.
- The supply terminals are not to be short-circuited.
- Only batteries of the same and equivalent type as recommended are to be used.

WE DO NOT RECOMMEND THE USE OF RECHARGEABLE BATTERIES.

PRODUCT FEATURES

1. ON/OFF/VOLUME CONTROL SWITCH

To turn the unit **ON**, slide the **ON/OFF/VOLUME CONTROL SWITCH** to the **LOW VOLUME** (🔊) or the **HIGH VOLUME** (🔊) position. To turn the unit **OFF**, slide the **ON/OFF/VOLUME CONTROL SWITCH** to the **OFF** (●) position.



2. MODES OF PLAY


The two modes of play include **LEARNING** and **MUSIC**.

3. AUTOMATIC SHUT-OFF

To preserve battery life, the **VTech® Discovery Nursery Farm™** will automatically power-down after several minutes seconds without input. The unit can be turned on again by pressing any key.

ACTIVITIES


1. Slide the **on/off/volume control switch** to turn the unit on. You will hear a sung song followed by an inviting phrase. The light will flash with the sound.




2. Turn the book page to **Old MacDonald Had a Farm** to activate the learning mode. Turn the book page to **Mary Had a Little Lamb** to activate the music mode. You will hear a sung song and short phrase to introduce the mode. The sun will flash with the sounds.




3. Press the **animal buttons** to learn about animals and their sounds in the learning mode. In the music mode, you will hear a variety of melodies. Move the animals while a melody is playing to hear the animal sing along with the melody. Move the same animal again to remove the animal sound from the melody. The sun will flash along with the sound.




4. Rotate the **light-up sun** in the learning mode to hear fun sounds and phrases. In the music mode, you will hear pre-programmed melodies. If a melody is playing and the sun is rotated, you will hear a magical sound play over top of the melody. The sun will flash along with the sound.



5. Press the **piano keys** in the learning mode to learn about colors and numbers. In the music mode, press the piano keys to hear individual music notes. If a melody is playing and the piano keys are pressed, the melody will be played one note at a time until the melody is over. The sun will flash along with the sound.



6. Spin the **roller** to hear a duck related phrase and sounds in the learning mode and melodies in the music mode. In the music mode, if a melody is playing, spin the roller to increase the tempo of the melody. The sun will flash along with the sound.



MELODY LIST

1. Happy Farmer
2. Farmer in the Dell
3. Old MacDonald Had a Farm
4. Bingo
5. You Are My Sunshine
6. Mulberry Bush
7. This Little Pig Went to Market
8. Skip to My Lou
9. Little Bo Peep
10. Mary Had a Little Lamb
11. Teddy Bears' Picnic
12. If You're Happy and You Know It

CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat source.
3. Remove the batteries when the unit is not in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

TROUBLESHOOTING

If for some reason the program/activity stops working, please follow these steps:

1. Please turn the unit **OFF**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit **ON**. The unit should now be ready to play again.
5. If the product still does not work, replace with a new set of batteries.

If the problem persists, please call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada, and a service representative will be happy to help you.

IMPORTANT NOTE:

Creating and developing **Infant Learning** products is accompanied by a responsibility that we at **VTech®** take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada with any problems and/or suggestions that you might have. A service representative will be happy to help you.

Note:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION.

THIS CLASS B DIGITAL APPARATUS COMPLIES WITH CANADIAN ICES-003.

CET APPAREIL NUMÉRIQUE DE LA CLASSE B EST CONFORME À LA NORME NMB-003 DU CANADA.

Note:

This equipment induces a weak magnetic field that may affect watches, television sets or monitors. It is recommended to keep this unit away from metallic materials when playing.