



User's Manual

Magical Learn & Go



**4-7
Years**

vtech®

© Disney

Visit the Disney website at DisneyPrincess.com

© 2010 VTech

Printed in China

91-002484-001-000 美

Dear Parent,

At **VTech**[®], we know how important the first day of school is for your child. To help prepare preschoolers for this important event, **VTech**[®] has developed the **Preschool Learning**[™] series of interactive toys.

Preschool Learning[™] features fun characters and inviting school themes that use technology to capture a child's attention and teach important preschool skills like spelling, counting and the alphabet. These vital skills are taught in a way that's both fun and highly engaging to maintain a child's interest. Children will also be introduced to fun school subjects such as art class, music class and even recess! With **Preschool Learning**[™], learning is fun from day one!

At **VTech**[®], we know that a child has the ability to do great things. That's why all of our electronic learning products are uniquely designed to develop a child's mind and allow them to learn to the best of their ability. We thank you for trusting **VTech**[®] with the important job of helping your child learn and grow!

Sincerely,


Your friends at **VTech**[®]

To learn more about **Preschool Learning**[™] series and other **VTech**[®] toys, visit www.vtechkids.com

INTRODUCTION

Thank you for purchasing the **VTech® Magical Learn & Go!**

Join Cinderella, Belle, Snow White and Aurora on a learning journey full of magic. Eight engaging activities introduce age-appropriate curriculum including letters, words, shapes and logic. Features a fun message button to send and receive messages with the princesses. Classical style melodies and magical sounds add to the enjoyment.




INCLUDED IN THIS PACKAGE

- One VTech® Magical Learn & Go
- One User's Manual

WARNING: All packing materials, such as tape, plastic sheets, packing locks, wire ties and tags are not part of this toy, and should be discarded for your child's safety.

NOTE: Please keep instruction manual as it contains important information.

Unlock the packaging locks:



- ① Rotate the packaging locks 90 degrees counter-clockwise.
- ② Pull out the packaging locks.


Demo strip removal:

When the product is taken out of the packaging, please remove the demo strip from the bottom of the unit to activate normal play mode.

GETTING STARTED

BATTERY INSTALLATION

1. Make sure the unit is turned **OFF**.
2. Locate the battery cover on the bottom of the unit.



3. Install 3 new "AA" size (LR6/AM-3) batteries following the diagram inside the battery box. (The use of new alkaline batteries is recommended for maximum performance.)
4. Replace the battery cover.

BATTERY NOTICE

- The use of new alkaline batteries is recommended for maximum performance.
- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed from the toy before being charged (if removable).
- Rechargeable batteries are only to be charged under adult supervision (if removable).
- Do not mix old and new batteries.
- Do not mix batteries of different types: alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium).
- Only batteries of the same or equivalent type as recommended are to be used.
- Batteries are to be inserted with the correct polarity.
- Exhausted batteries are to be removed from the toy.
- The supply terminals are not to be short-circuited.
- The toy is not to be connected to more than the recommended number of power supplies.
- Do not dispose of batteries in fire.

WE DO NOT RECOMMEND THE USE OF RECHARGEABLE BATTERIES.

PRODUCT FEATURES

1. ON/OFF SWITCH

To turn the unit **ON**, slide the **ON/OFF SWITCH** to the **ON** position. To turn the unit **OFF**, slide the switch to the **OFF** position.



2. MODE BUTTONS

Press the **PRINCESS EXPLORE BUTTON** to learn and have fun with letters.



Press the **PRINCESS ACTIVITIES BUTTON** to choose an activity in that mode.



Press the **BE A PRINCESS BUTTON** to take part in a test and become a princess.



3. LETTER BUTTONS

Press the 26 **LETTER BUTTONS** to learn letters and answer questions in related activities.




4. MESSAGE BUTTON

Press the **MESSAGE BUTTON** to receive a message from Cinderella, Belle, Snow White or Aurora. Type your reply using the **LETTER BUTTONS** and press the **OK BUTTON** to send it!




5. MUSIC BUTTON

Press the **MUSIC BUTTON** to hear classical style melodies and see the princesses dance.



6. ARROW BUTTONS

Press the **ARROW BUTTONS** to make a selection. Press the **OK BUTTON** to confirm your choice.



7. REPEAT BUTTON

Press the **REPEAT BUTTON** to hear an instruction or question repeated.




8. AUTOMATIC SHUT-OFF

To preserve battery life, the **VTech® Magical Learn & Go** will automatically go into sleep mode after several minutes without input. Press any button to wake it up.

ACTIVITIES

MODE 1: PRINCESS EXPLORE



Press the **LETTER BUTTONS** to hear the letter and a word that begins with that letter identified and shown on the screen.



MODE 2: PRINCESS ACTIVITIES

1. LETTER BUBBLES

Pop the letter bubbles by pressing the corresponding **LETTER BUTTONS** as the letters are shown.



2. SHAPE BRIDGE

Help Chip cross the lake by finding the correct shapes. Use the **ARROW BUTTONS** to choose and press the **OK BUTTON** to confirm your choice.



3. PUZZLE BOX

Help Aurora return her things to their correct places. Use the **ARROW BUTTONS** to choose the correct shape that matches the object and press the **OK BUTTON** to confirm your choice.



4. THE ROYAL BALL

Help Suzy follow Cinderella's dance steps. Watch carefully as Cinderella dances. Help Suzy copy the dance steps by remembering the directions and pressing the corresponding **ARROW BUTTONS**.



MODE 3: BE A PRINCESS

Do you dream about being a princess? You will be asked to complete four random activities to test your princess knowledge. If you complete at least one activity correctly, you have passed the test! Input your princess name using the **LETTER BUTTONS** and press the **OK BUTTON** to confirm. Then use the **ARROW BUTTONS** and press the **OK BUTTON** to choose your princess picture to make your princess name card.



CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat source.
3. Remove the batteries when the unit is not in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

TROUBLESHOOTING

If for some reason the program/activity stops working, then please follow these steps:

1. Turn the unit OFF.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit back ON. The unit will now be ready to play again.
5. If the unit still does not work, replace with an entire set of new batteries.

If the problem persists, please call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada, and a service representative will be happy to help you.

IMPORTANT NOTE:

Creating and developing **Preschool Learning™** products is accompanied by a responsibility that we at **VTech®** take very seriously. We make every effort to ensure the accuracy of the information which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada with any problems and/or suggestions that you might have. A service representative will be happy to help you.

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution : changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

