



LITTLE SMART Sing 'n Smile Pals™

USER'S MANUAL



© VTECH
Printed in China
91-01115-000 (美)

Dear Parent:


At **VTech**[®] we know that children have the ability to do great things. That's why all of our electronic learning products are uniquely designed to develop a child's mind and allow them to learn to the best of their ability. Whether it's learning about letters, numbers, geography or algebra, all **VTech**[®] learning products incorporate advanced technologies and extensive curriculum to encourage children of all ages to reach their potential.

When it comes to providing interactive products that enlighten, entertain and develop minds, at **VTech**[®] we see the potential in every child.

INTRODUCTION

Thank you for purchasing the **VTECH® LITTLE SMART Sing 'n Smile Pals™** learning toy! This product is one of a family of **LITTLE SMART®** educational electronic learning products. We at **VTECH®** are committed to providing the best possible products to entertain and educate your child. Should you have any questions or concerns, please call our Consumer Services Department at 1-800-521-2010 in the U.S., 1-800-267-7377 in Canada and 01235-546810 in the UK.

The **LITTLE SMART Sing 'n Smile Pals™** learning toy is designed specifically for infants and toddlers. There are cute animal buttons, light-up number and shape buttons and a fun keyboard.




INCLUDED IN THIS PACKAGE

- One **LITTLE SMART Sing 'n Smile Pals™** learning toy.
- One instruction manual.

WARNING: All packing materials such as tape, plastic sheets, wire ties and tags are not part of this toy, and should be discarded for your child's safety.

BATTERY INSTALLATION

1. Make sure the unit is **Off**.
2. Locate the battery cover on the back of the unit. Use a coin or screwdriver to loosen the screw.
3. Install 2 'AA' (UM-3/LR6) batteries following the diagram inside the battery box. (The use of new, alkaline batteries is recommended for maximum performance.)
4. Replace the battery cover and tighten the screw to secure the battery cover.



BATTERY NOTICE

- Install batteries correctly observing the polarity (+, -) signs to avoid leakage.
- Always replace a whole set of batteries at one time.
- Do not use batteries of different types.
- Remove exhausted or new batteries when unit will not be used for an extended period of time.
- Do not dispose of batteries in fire.
- Do not attempt to recharge ordinary batteries.
- The supply terminals are not to be short-circuited.

WE DO NOT RECOMMEND THE USE OF RECHARGEABLE BATTERIES.

NOTE: If for some reason the program/activity stops working, then please follow these steps:

1. Please turn the unit off.
2. Interrupt the power supply by removing the batteries or disconnecting the adaptor.
3. Let the unit stand for a few minutes, then replace the batteries or reconnect the adaptor.
4. Turn the unit on. The unit will now be ready to play again.

If the problem persists, please call our Consumer Services Department and a service representative will be happy to help you.

TO BEGIN PLAY


1. Switch the **On/Off/Mode Switch** to the Talking position (😊) or the Music position (🎵) and the **LITTLE SMART Sing 'n Smile Pals™** will play a short tune and the lights will flash.



2. Press any button to begin play.



3. To adjust the volume, slide the **Volume Switch** up for high volume (🔊) or down for low volume (🔇). The **Volume Switch** is located on the bottom of the unit.



4. To turn the unit off, switch the **On/Off/Mode Switch** to the off position (●).



ACTIVITIES

Talking Mode

1. Switch the **On/Off/Mode Switch** to the Talking position (😊) and you will hear a short tune and the lights will flash.




2. Press or push an **Animal Button**. You will hear the animal identified and its sound effect. The lights will flash along with the sound.



3. Press a **Number/Shape Button**. You will hear the color and shape identified. The lights will flash along with the voice.



4. Press a **Keyboard/Letter key**. You will hear the letter identified. The **Melody Button** will flash along with the sound.



5. Press the **Melody Button**. You will hear one of the four melodies.


Press the **Melody Button** again and you will hear a different melody. The light will flash in time to the music.

There are four melodies:

- London Bridge
- Twinkle Twinkle Little Star
- Three Blind Mice
- Row, Row, Row Your Boat



6. Turn the **Melody Roller Ball** to control the speed of a melody and to enhance baby's understanding of cause and effect. The lights will flash along with the music.




Music Mode

1. Switch the **On/Off/Mode Switch** to the Music position (🎵) and you will hear a short tune and the lights will flash.



2. Press or push an **Animal Button**. You will hear the melody being “sung” with the animal’s sound effect. The lights will flash in time to the music.




3. Press a **Number/Shape Button**. You will hear the number identified. Then the animal’s sound effect will play the same number of times as the number button that was pressed. Also, the light will flash the same number of times to reinforce counting.




Press a **Number/Shape Button** while a melody is playing. You will hear the same response without the number identification.

4. Press a **Keyboard/Letter key**. You will hear one music note per key. The **Melody Button** will flash in time to the music.




5. Press the **Melody Button**. You will hear one of the four melodies. Press the **Melody Button** again and you will hear a different melody. The lights will flash in time to the music.



6. Turn the **Melody Roller Ball** to control the speed of a melody. The lights will flash along with the melody.

Remember: the faster the ball is turned, the faster the melody will play. Likewise, the slower that the ball is turned, the slower the melody will play.



Melody List:

- London Bridge
- Twinkle Twinkle Little Star
- Three Blind Mice
- Row, Row, Row Your Boat

AUTOMATIC SHUT-OFF

To preserve battery life, the **LITTLE SMART Sing 'n Smile Pals™** learning toy will automatically turn off after several minutes without input. The unit can be turned on again by pressing any button.

CARE AND MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat source.
3. Remove the batteries when the unit is not in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

IMPORTANT NOTE

Creating and developing Infant/Toddler products is accompanied by a responsibility that we at **VTECH**[®] take very seriously. We make every effort to ensure the accuracy of the information which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department at 1-800-521-2010 in the U. S., 1-800-267-7377 in Canada and 01235-546810 in the UK with any problems and/or suggestions that you might have. A service representative will be happy to help you.

Note:

This equipment generates and uses radio frequency energy and if not installed and used properly, that is, in strict accordance with the manufacturer's instructions, it may cause interference to radio and television reception. It has been type tested and found to comply with the limits for a Class B computing device in accordance with the specifications in Sub-part J of Part 15 FCC Rules, which are designed to provide reasonable protection against such interference in a residential installation. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- reorient the receiving antenna
- relocate this product with respect to the receiver
- move this product away from the receiver