

VTECH[®]
LITTLE SMART
PC Surprise[™]
USER'S MANUAL



©VTECH
Printed in China
91-01332-000[®]


Dear Parent:

At VTECH® we know that a child has the ability to do great things. That's why all of our electronic learning products are uniquely designed to develop a child's mind and allow them to learn to the best of their ability. Whether it's introducing numbers and letters, identifying colors and shapes, or stimulating senses with lights and music, all VTECH® infant and toddler learning products encourage your child's natural growth and discovery skills. When it comes to providing electronic learning products that enlighten, entertain and develop minds, at VTECH® we see the potential in every child.

INTRODUCTION

Thank you for purchasing the **VTECH® LITTLE SMART PC Surprise™** learning toy! This product is one of a family of high-quality **LITTLE SMART®** electronic learning toys. We at **VTECH®** are committed to providing the best possible products to entertain and educate your child. Should you have any questions or concerns, please call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-800-267-7377 in Canada.

The **LITTLE SMART PC Surprise™** learning toy is a fun and interactive desktop computer designed for toddlers 18 months and up. Baby will be rewarded with a fun surprise for pressing and turning all the buttons. The spinning CD, animated screen and colored lights are just a few of the fun features. The **LITTLE SMART PC Surprise™** is learning fun that computes!




INCLUDED IN THIS PACKAGE

- One LITTLE SMART PC Surprise™ learning toy.
- One instruction manual.

WARNING: All packing materials, such as tape, plastic sheets, wire ties and tags are not part of this toy, and should be discarded for your child's safety.

BATTERY INSTALLATION

1. Make sure the unit is turned **OFF**.
2. Locate the battery cover on the bottom of the unit. Use a coin or screwdriver to loosen the screw.
3. Install 2 new "AA" (UM-3/LR6) batteries following the diagram inside the battery box. (The use of new, alkaline batteries is recommended for maximum performance.)
4. Replace the battery cover and tighten the screw to secure the battery cover.



BATTERY NOTICE

- Install batteries correctly observing the polarity (+, -) signs to avoid leakage.
- Do not mix old and new batteries.

- Do not use batteries of different types.
- Remove exhausted or new batteries from the equipment when the unit will not be used for an extended period of time.
- Do not dispose of batteries in fire.
- Do not attempt to recharge ordinary batteries.
- The supply terminals are not to be short-circuited.

WE DO NOT RECOMMEND THE USE OF RECHARGEABLE BATTERIES.


NOTE: If for some reason the program/activity stops working, then please follow these steps:

1. Please turn the unit **OFF**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit **ON**. The unit should now be ready to play again.


If the problem persists, please call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-800-267-7377 in Canada, and a service representative will be happy to help you.

TO BEGIN PLAY

1. Slide the **ON/OFF SWITCH** to the **ON** position (*) to turn the unit **ON**. You will be greeted with a short tune and a phrase. The lights on the screen will flash with all the sound effect, music and talking activities.



2. To adjust the volume, slide the **VOLUME CONTROL SWITCH** located on the bottom of the unit to () for **LOW VOLUME** or () for **HIGH VOLUME**.



3. Slide the **ON/OFF SWITCH** to the **OFF** position (●) to turn the unit **OFF**.



NOTE: To preserve battery life, the **LITTLE SMART PC Surprise™** will turn off automatically after 30 seconds without input. The unit can be turned on again by pressing any button.


ACTIVITIES

A. Talking Mode


1. Slide the **MODE SELECTOR SWITCH** to the **TALKING MODE** (😊) position. You will hear “Hi, There!” followed by a short tune. The lights on the screen will flash with the sound.




2. Move the **MOUSE** in any direction to hear “Let’s play!” followed by a spring sound effect. The bird on the screen will move up and down and the lights will flash with the sound.




3. Turn the **TIMER** clockwise or counter clockwise to hear the numbers 1-4 identified followed by a counting clock sound effect. The girl on the screen will do a cartwheel in the direction the **TIMER** is turned and the lights will flash with the sound.





4. Press the **ALPHABET BUTTON** to hear "A, B, C, D" followed by a cute giggle sound effect. The rabbit will pop-up on the screen and the lights will flash with the sound.




5. Slide the **COLOR CHANGE BUTTON** to hear a magical sound effect and see the lights on the screen change color.



6. Press the **CD SPIN BUTTON** () to hear "Let's dance" followed by a random melody. The **CD** will spin and the lights on the screen and disk will flash with the music.



7. Press the **MELODY BUTTON** (🎵) to hear a random melody. The lights on the screen and disk will flash with the music.



EIGHT FUN MELODIES


- Three Blind Mice
- Hickory Dickory Dock
- Sing a Song of Sixpence
- Three Little Kittens
- I've Been Working on the Railroad
- Ring Around a Rosy
- This Old Man
- Alphabet Song

B. Music Mode


1. Slide the **MODE SELECTOR SWITCH** to the **MUSIC MODE** (🎵) position to hear a short tune followed by “Hello”. The lights on the screen will flash with the sound.




2. Move the **MOUSE** in any direction to hear a spring sound effect followed by a random melody. The bird on the screen will move up and down. The lights will flash with the sound.




3. Turn the **TIMER** clockwise or the counter clockwise to hear musical notes. The girl on the screen will do a cartwheel in the direction the **TIMER** is turned and the lights will flash with the music notes.





4. Press the **ALPHABET BUTTON** to hear a cute giggle sound effect. The rabbit will pop-up on the screen and the lights will flash with the music.





5. Slide the **COLOR CHANGE BUTTON** to hear a magical sound effect and see the lights on the screen change color.



6. Press the **CD SPIN BUTTON** () to hear "Let's Sing" followed by a random melody. The **CD** will spin and the lights on the screen and disk will flash with the music.



7. Press the **MELODY BUTTON** () to hear a random melody. The lights on the screen and disk will flash with the music.



CARE AND MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat source.
3. Remove the batteries when the unit is not in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

IMPORTANT NOTE

Creating and developing the infant/toddler products is accompanied by a responsibility that we at **VTech®** take very seriously. We make every effort to ensure the accuracy of the information which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-800-267-7377 in Canada with any problems and/or suggestions that you might have. A service representative will be happy to help you.

Note:

This equipment generates and uses radio frequency energy and if not installed and used properly, that is, in strict accordance with the manufacturer's instructions, it may cause interference to radio and television reception. It has been type tested and found to comply within the limits for a Class B computing device in accordance with the specifications in Sub-part J of Part 15 FCC Rules, which are designed to provide reasonable protection against such interference in a residential installation. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause interference with radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- reorient the receiving antenna
- relocate this product with respect to the receiver
- move this product away from the receiver