

User's Manual

Sit-to-Stand Smart Cruiser[™]



2014/4/15 9:47:51

Dear Parent,

Ever notice the look on your baby's face when they learn something new through their own discovery? These self-accomplished moments are a parent's greatest reward. To help fulfill them, VTech® created the Infant Learning® series of toys.

These unique interactive learning toys directly respond to what children do naturally – play! Using innovative technology, these toys react to baby's interactions, making each play experience fun and unique as they learn age-appropriate concepts like first words, numbers', shapes, colors and music. More importantly, VTech®'s Infant Learning[®] toys develop baby's mental and physical abilities by inspiring, engaging and teaching.

At **VTech**[®], we know that a child has the ability to do great things. That's why all of our electronic learning products are uniquely designed to develop a child's mind and allow them to learn to the best of their ability. We thank you for trusting **VTech**® with the important job of helping your child learn and grow!


sincerely, Your friends at **VTech**®

To learn more about the **Infant Learning**® series and other **VTech**® toys, visit www.vtechkids.com

INTRODUCTION

Thank you for purchasing the VTech[®] Sit-to-Stand Smart Cruiser[™] learning toy.

Cruise into the learning zone on the **Sit-to-Stand Smart Cruiser**[™] by **VTech**[®]. This 2-in-1 toy has an interactive steering wheel that includes driving, learning and music modes. Turn on the engine, move the gear shifter or press the horn to hear realistic driving sound effects. Choose one of six places and your child can pretend to drive to fun locations. The Sit-to-Stand Smart Cruiser[™] also has a front activity panel with fun manipulative features and under seat storage your child can fill with small toys for more fun on the go!



INCLUDED IN THIS PACKAGE

- User's manual
- 18 screws




- 1 VTech[®] Sit-to-Stand Smart Cruiser[™] steering wheel activity panel
- 1 vehicle body
- Handle bars



- 1 set of front wheels (includes an axle, two large brackets and two wheels)
- 1 set of back wheels (includes an axle, two small brackets and two wheels)
- 1 seat bracket
- 1 seat

Included In This Package

- WARNING: All packing materials, such as tape, plastic sheets, packaging locks and tags are not part of this toy, and should be discarded for your child's safety.
- ATTENTION: Pour la sécurité de votre enfant, débarrassez-vous de tous les produits d'emballage tels que rubans adhésifs, feuilles de plastique, attaches et étiquettes. Ils ne font pas partie du jouet.




NOTE: Please keep this instruction manual as it contains important information.

GETTING STARTED

BATTERY INSTALLATION

- 1. Make sure the unit is turned OFF.
- Locate the battery cover on the bottom of the Activity Panel. Use a coin or a screwdriver to loosen the screw.
- Install 2 new 'AA' (AM-3/LR6) batteries following the diagram inside the battery box. (The use of new alkaline batteries is recommended for maximum performance.)
- 4. Replace the battery cover and tighten the screw to secure.



Getting Started

BATTERY NOTICE

- Use new alkaline batteries for maximum performance.
- Use only batteries of the same or equivalent type as recommended.
- Do not mix different types of batteries: alkaline, standard (carbonzinc) or rechargeable (Ni-Cd, Ni-MH), or new and used batteries.
- Do not use damaged batteries.
- · Insert batteries with the correct polarity.
- Do not short-circuit the battery terminals.
- · Remove exhausted batteries from the toy.
- · Remove batteries during long periods of non-use.
- Do not dispose of batteries in fire.
- Do not charge non-rechargeable batteries.
- Remove rechargeable batteries from the toy before charging (if removable).
- Rechargeable batteries are only to be charged under adult supervision.

ASSEMBLY INSTRUCTIONS

With the VTech[®] Sit-to-Stand Smart Cruiser[™], safety comes first. To ensure your child's safety, adult assembly is required.

ATTENTION: The maximum weight limit for this product is 42 pounds. It is not recommended for children older than 36 months.

 Insert the handle bars into the slot on the top of the vehicle body. Turn the vehicle body over and secure the handle bars with two of the screws.



- Insert the front wheels (includes an axle, two large brackets and two wheels) into the slot on the front of the vehicle body. Secure each bracket with 4 screws.
- Insert the back wheels (includes an axle, two small brackets and two wheels) into the slot on the back of the vehicle body. Slide the two brackets out to lock the axle into place. Secure each bracket with 2 screws.
- 4. Insert the seat bracket into the top of the seat.

 Put the seat bracket on the top of the vehicle body, then turn the vehicle body over and secure the seat bracket with 4 screws.







PRODUCT FEATURES

1. ON/OFF/VOLUME CONTROL SWITCH

To turn the unit ON, slide the ON/ OFF/VOLUME CONTROL SWITCH to the LOW VOLUME (())) or HIGH VOLUME (())) position. To turn the unit OFF, slide the ON/OFF/VOLUME CONTROL SWITCH to the OFF (()) position.



2. MODE SELECTOR SWITCH

Slide the MODE SELECTOR SWITCH to the LEARNING MODE (ABC), DRIVING MODE () or MUSIC MODE () position.



3. AUTOMATIC SHUT-OFF

To preserve battery life, the **VTech[®] Sit-to-Stand Smart Cruiser**[™] will automatically power-down after approximately 60 seconds without input. The unit can be turned on again by pressing any button.

Product Features

ACTIVITIES

- Slide the on/off/volume control switch to turn the unit on. You will hear a welcoming phrase, playful sounds, short tunes and a sung song, depending on the selected mode. The lights will flash with the sound.
- Press the animal buttons to hear animal names, animal sounds, names of locations around town or melodies, depending on the selected mode. The lights will flash with the sound.
- Slide the car back and forth to hear fun sounds or short tunes, depending on the selected mode. Stop sliding the car to hear fun sounds, playful phrases and short tunes, depending on the selected mode. The lights will flash with the sound.
- 4. Push or pull the **gear shift** to hear fun sound and phrases or short tunes, depending on the selected mode. The lights will flash with the sound.









Activities

- 5. Press the **horn button** to hear a variety of horn sounds and short tunes. The lights will flash with the sound.
- Press the left and right arrow buttons to hear the sounds, directional phrases or short tunes, depending on the selected mode. The lights will flash with the sound.
- Turn the ignition key to hear sounds and phrases or sung songs, depending on the selected mode. The light will flash with the sound.
- 8. Insert the Sit-to-Stand Smart Cruiser[™] steering wheel activity panel onto the handle bars to hear a playful sound, short tune and phrase. By connecting the activity panel to the handle bars, the motion sensor will be activated. Turn the activity panel to hear a variety of melodies, short tunes and fun sounds. The lights will flash with the sound. Removing the activity panel from the handle bars will disable the motion sensor.











10

vities

MELODY LIST:

- 1. London Bridge
- 2. Yankee Doodle
- 3. Sailing, Sailing
- 4. Clementine
- 5. Mulberry Bush
- 6. Three Blind Mice
- 7. Old McDonald
- 8. Farmer in the Dell
- 9. Chicken Reel
- 10. This Old Man
- 11. Baa, Baa, Black Sheep
- 12. Little Bo Peep
- 13. BINGO
- 14. Where Has My Little Dog Gone?
- 15. Pussy Cat, Pussy Cat
- 16. Three Little Kittens
- 17. Little Robin Red Breast
- 18. Listen to the Mocking Bird

SUNG SONG LYRICS

SONG 1

Turn the key, spin the wheel, Drive the car to and fro.

SONG 2

Buckle up, we're ready to go. Don't forget to look both ways, before you go!

CARE & MAINTENANCE

- 1. Keep the unit clean by wiping it with a slightly damp cloth.
- 2. Keep the unit out of direct sunlight and away from any direct heat source.
- 3. Remove the batteries when the unit will not be in use for an extended period of time.
- 4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

TROUBLESHOOTING

If for some reason the program/activity stops working or malfunctions, please follow these steps:

- 1. Please turn the unit OFF.
- 2. Interrupt the power supply by removing the batteries.
- 3. Let the unit stand for a few minutes, then replace the batteries.
- 4. Turn the unit ON. The unit should now be ready to play again.
- 5. If the product still does not work, replace with an entire set of new batteries.

If the problem persists, please call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada, and a service representative will be happy to help you.

For information on this product's warranty, please call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada.

IMPORTANT NOTE:

Creating and developing **Infant Learning** products is accompanied by a responsibility that we at **VTech®** take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department at 1-800-521-2010 in the U.S., or 1-877-352-8697 in Canada, with any problems and/or suggestions that you might have. A service representative will be happy to help you.

NOTE :

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRED OPERATION.

CAN ICES-3 (B)/NMB-3(B)

Caution: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

CLASS 1 LED PRODUCT